RESTRICTED

SECTION 54 – LEVELLING AND VERTICAL CURVES

Levels

- 1163. Procedure for setting out levels. When the grade line has not previously been fixed by paper location, the procedure is:
 - a. Take levels along the centre line, at each chainage peg.
 - b. Plot the longitudinal section.
 - c. Decide the final grade line, after considering earthwork quantities and permissible gradients (see para 218).
 - d. Drive grade pegs, usually as side stakes, at a fixed distance from the centre line.
- 1164. Checking will be simplified and time saved by:
 - a. Setting grade pegs with the top of the peg at correct finished crown level.
 - b. Establishing proper bench marks. In deliberate work these should be sited not more than 4 miles apart, and at all bridge sites.

Vertical Curves

- 1165. Vertical and horizontal curves should not coincide.
- 1166. The most important requirement is the sight distance available to drivers (see Section 14).




Figure 11-22 – Approximate Method of Setting Out a Vertical Curve.

RESTRICTED

- 1167. The following is a simple method of determining the approximate formation levels on a vertical curve (see Figure 11.22):
 - a. On a longitudinal section of the road length concerned fix the TC and CT so that the chord joining them is equal to the sight distance required. Draw in the chord.
 - b. From the TC and CT produce the tangents to intersect at I.
 - c. From I drop a perpendicular to cut the chord at P.
 - d. On the line IP fix a point Q, such that PQ is not more than 3 ft 9 ins.
 - e. Draw a curve through TC, Q and CT, so that no point on the curve is higher than PQ.
 - f. Scale off the formation levels at the required points on the curve.