CIRS BOOTH · CHINMAYA AMRIT MAHOTSAV

Video kiosk technician sheet

The kiosk is a full-screen web page that plays 18 videos. Use the first option that works on this screen. The USB pen drive contains everything: the app, the videos, the showreel and these sheets.

A Android with Chrome (preferred)

1. Open Chrome and go to the kiosk link: `https://me-shivamo.github.io/cirs/`
2. Tap **Download videos** (about 1.3 GB). No Wi-Fi? Open the link once on a phone hotspot, then tap **Load from USB stick** → pen drive → `CIRS-KIOSK/videos/hd` → ⋮ **Select all** → **Open**.
3. When it says all 18 are saved, tap **Add to Home screen**, then **Start**.
4. **Android settings:** set the display sleep timeout to the maximum (or Developer options → *Stay awake*), lock landscape, set media volume, and turn on Do Not Disturb. Turn off the panel's own power-saving / OSD sleep timer.
5. **Optional lock:** Settings → Security → *App pinning*, then pin Chrome or the CIRS Videos app.

B Android without Chrome, or to lock the screen: Fully Kiosk Browser

1. Install **Fully Kiosk Browser** from the Play Store, or the APK from fully-kiosk.com.
2. **Start URL:** the kiosk link above. Web Content Settings: *Autoplay videos* ON, JavaScript ON. Web Browsing Settings: *Pull to refresh* OFF.
3. **Device Management:** *Keep screen on* ON, *Launch on boot* ON. Kiosk Mode needs a PLUS licence; without it, use App pinning.
4. Then follow steps 2–3 of option A inside Fully Kiosk.

C/D Windows PC or laptop

1. Copy `CIRS-KIOSK` from the pen drive to `C:\CIRS-KIOSK`.
2. Double-click `START-KIOSK.bat`. It opens full screen and restarts the browser if it closes. Stop it with `STOP-KIOSK.bat`.
3. To start automatically at power-on, run `INSTALL-AUTOSTART.bat`. This also disables sleep.
4. **Laptop + touch panel:** connect HDMI **and** the USB touch cable. Press **Win+P** → *Second screen only*. If touches land on the wrong display: Control Panel → *Tablet PC Settings* → *Setup* → *Touch input*, then tap the panel.

F Touch not working: showreel

Play `CIRS-Showreel.mp4` (pen drive root) in the panel's or TV's media player and set **Repeat / Loop**. All 18 videos play with title cards, about 64 minutes.

G Visitors' phones

The QR standee opens `…/?visitor`: the same topics, streamed to the phone.

Staff screen (status, self-test, fixes)

Hold **"Keep Smiling"** (top right) for 5 seconds, or press **Ctrl+Shift+S** on a keyboard. PIN **2026**.

- **Run self-test:** plays 1 second of every video and shows ✓/✗ for each one.
- **Video quality → Lite:** use this if videos stutter on a slow screen. It needs the Lite copies, which are on the pen drive in `videos/lite`.
- **Mode → Loop only:** plays the videos one after another and ignores touches. Use it if touch is unreliable.
- **Volume**, **Download / repair videos**, **Load from USB stick**, **Check for updates**, **Restart app**.
- Send a photo of this screen to the developer. It shows the device, storage and which videos are saved.

Behaviour (normal)

- **When nobody touches the screen for 90 seconds:** a silent showreel starts. Any touch returns to the topics.
- **When a video is paused:** it returns to the topics after 45 seconds.
- **When a video can't load:** after about 8 seconds, it shows a message and goes back.
- **Every few hours, when idle:** the page refreshes itself.