Aufg:	4b	4c	4d	5a	5b	5c	5d	5g	5h	6a
Pin 1										
Pin 2										
Pin 3		Taster		Taster	Taster	Taster	Taster	Taster	Taster	Taster
Pin 4										
Pin 5				Taster	Taster	33			Taster	Taster
Pin 6						4.				
Pin 7	Taster									
Pin 8										
Pin 9			LED Grün				Led Grün	LED Grün		LED Grün
Pin 10			LED Gelb							LED Gelb
Pin 11			LED Rot				LED Rot	LED Rot		LED Rot
Pin 12										
Pin 13	LED	LED		LED	LED				LED	
Pin A0										
Pin A1		1		2 /			į.			-
Pin A2										
Pin A3										
Pin A4										
Pin A5										7.