Setup Modules Save Load Close

Kassow Robot Module (ID: 1) ready

(1) Stereo Camera Input Module (Windows) (ID: 2) unready

Camera Pose Injector (ID: 3) ready

Stereo Camera Calibration (Robot) (ID: 4) unready

Pen Tracking (Multi-Cam) (ID: 5) ready

Scene Detection (Stereo Camera) (ID: 6) ready

Usecase Weld (ID: 7) ready

Usecase Pick and Place (ID: 8) ready

Add New

Stereo Camera Input Module (Windows)

Module configures and captures a side-by-side stereo MJPEG stream from a Windows camera. Set your desired stereo resolution (total width and height), target framerate, framerate tolerance and camera index, then activate the module. On activation, the module enumerates MJPEG-capable cameras, filters modes by resolution and framerate (within the given tolerance), and uses the selected index to pick a device from the remaining devices (if 3 cameras remain from original 7, use indexes 0,1 and 2 to select which one). A typical workflow is to start with your target resolution, framerate, reasonably high framerate tolerance and camera index 0 (only change camera index if you have multiple cameras with the same resolution, to select the correct camera), ensure the module activates (if it does not, resolution is likely not supported), then iteratively lower the tolerance or adjust framerate if activation fails (persistent failure usually means the framerate is unsupported). With auto exposure enabled the module should always activate (only resolution, framerate/tolerance and camera index can prevent activation). Once a working mode is found, you can disable auto exposure and experiment with manual exposure values; the supported exposure range and chosen values are reported in logs, not in the GUI. Manual exposure values outside the supported range will prevent activation.

PARAMETERS

Resolution Width [px]	2560
Resolution Height [px]	800
Framerate [FPS]	60

Remove Module

Deactivate (2) Activate