
Aergo
Setup
New
Save
Load
Cut
Copy
Paste
Start
Simulate
Stop
Pause
Resume
PROGRAM
AVAILABLE
MOVE_A
MOVE_J
MOVE_L
MOVE_T
(1)
(2)
(3)
(4)
(5)
(6)
Move To Position
Set Position
Reload Visualization
Scan Scene