
Aergo
Setup
New
Save
Load
Cut
Copy
Paste
Start
Simulate
Stop
Pause
Resume
PROGRAM
PICK
(2)
AVAILABLE
PICK
(1)
WELD
AUTOMATIC PARAMETERS
Scene Request
Click to set
Pick Position
Click to set
Place Position
Click to set
(3)
(4)
eload Visualization
Scan Scene
ADVANCED
(5)
Confirm