
Aergo
Setup
New
Save
Load
Cut
Copy
Paste
Start
Simulate
(5)
Stop
Pause
Resume
(6)
(7)
PROGRAM
(2)
WELD
AVAILABLE
(1)
PICK
WELD
AUTOMATIC PARAMETERS
Scene Scan
(3)
Click to set
Welding Trajectory
Click to set
Move To Position
Set Position
(8)
Reload Visualization
Scan Scene
ADVANCED
(4)
Confirm