ADDITIONAL INFORMATION

1. Additional INFO AVBL FM website: Fly Neighbourly Policy, Weather, RWY camera.
2. High ground 1NM SE of airstrip.
3. Gliding OPS HJ DLY at AD. Cable launching to 3,500FT AMSL. Winch located 120M NW of RWY14 THR. Winch flashing beacon indicates launch in progress. Gliding OPS phone: 0417 565 514 or 0409 277 328.
4. Hang gliders and paragliders operate around and on AD.
5. RWS and grass areas can be soft after rain.
6. Animal hazards (kangaroos and birds) exist.

CHARTS RELATED TO THE AERODROME

WAC 3470.

MOUNT BUNDEY

ELEV 150

FULL NOTAM SERVICE NOT AVBL



NT		UTC +9:30	YMDY
125324S	1315426E	VAR 2 DEG E	UNCR

AD OPR Range Control Headquarters, CSIC - NT/K, Robertson Barracks, Palmerston, NT, 0830. PH Mount Bundey Range Control 0427 166 790.

REMARKS

1. PPR from Range control.
2. Caution: This aerodrome is not subject to routine serviceability inspection or NOTAM advice of unserviceabilities. Additional aerodrome data is available from the contact telephone numbers above.
3. CIV ACFT (excluding EMERG ACFT) shall not plan to use YMDY.
4. EMERG ACFT are to contact Mt Bundey Range control for both planned and short notice/ EMERG use.
5. Aircraft required to be in possession of Mount Bundey Special map to allow clearance onto the range. Clearances will be issued with respect to military grid reference system eastings and northings or with respect to named sectors/roads.

HANDLING SERVICES AND FACILITIES

No Fuel AVBL.

PASSENGER FACILITIES

Composting toilet and rain water tanks between parking apron and runway.

APRONS AND TAXIWAYS

TWY 95M x 15M, Parking area 50M x 115M.

ATS AND AERODROME COMMUNICATION FACILITIES

FIA	BRISBANE CENTRE	124.1

LOCAL TRAFFIC REGULATIONS

1. Contact Mt Bundey Range Control prior to DEP to CFM FREQ RQMNTS. Range Safety radios only manned when restricted areas are active.
2. C130 to conduct MAX RAD turns at turning areas.
3. Parking area NE of THR RWY 12.
4. Helicopter forward arming and refuelling point may be located on TWY, within parking APN or on RWY.
5. HEL pad suitable for UH/LOH day or night operations at GR067764. Surface bitumen. Lit water tower near HEL pad.

Information may be continued on the next page: PTO

FLIGHT PROCEDURES

1. Range Safety must be contacted before entering R224A/B or R228A.
2. Aircraft must monitor the VHF FM range safety frequency or be in formation with aircraft that is continuously monitoring VHF FM range safety FREQ.
3. Prefer fixed wing aircraft to approach and depart restricted areas from/to NE.
4. Fixed wing traffic to conduct circuits to NE of airfield.
5. Straight in approach is available IAW AIP and range clearance.
6. Circuit calls to be made on 126.7 MHz.
7. Noise Sensitive Area. Aircraft are not to fly lower than 1,500FT AGL within a 5NM radius of Anaburroo Station (125450S 1314020E), 260/13.9NM from ARP.
8. MIL ACFT may conduct OPS within R224A using Light Enhancement Devices and may not display external lighting.
9. A/G FREQ 126.05 when Range in use.

CTAF 126.7

ADDITIONAL INFORMATION

1. AD located within R224A.
2. MIL users consult *Aircraft Pavement Strength Evaluation Manual* (adf.ces@defence.gov.au) and *Airfield Survey Database* (airfield.surveyagency@defence.gov.au) for latest data.

CHARTS RELATED TO THE AERODROME

1. WAC 3109.
2. Mount Bundey training area special, AUSPEC0027, Edition 3-AAS.

MOUNT COOLON

ELEV 785

FULL NOTAM SERVICE NOT AVBL



QLD		UTC +10	YMCL
212313S	1471956E	VAR 8 DEG E	UNCR

AD OPR Whitsunday Regional Council, PO Box 104, Proserpine, QLD, 4800. Mobile 0417 762 235.

PASSENGER FACILITIES

Telephone facilities not AVBL

ATS AND AERODROME COMMUNICATION FACILITIES

FIA	BRISBANE CENTRE	128.55 2000FT

CTAF 126.7

ADDITIONAL INFORMATION

Animal hazard exists.

CHARTS RELATED TO THE AERODROME

WAC 3234, 3235.