COMP 3980: Assignment_2

Tim Makimov, A00903109

Terry Kang, A00937143

Set: 30



User Guide

How to set up

- 1. Connect RFID reader to computer using USB connector
- 2. Start the program by running RFIDReader.exe

How to Connect and Scan

- 1. Click Connect button
- 2. After Device is discovered and connected tap the tag on the reader to scan it.

How to Disconnect

1. Click "Disconnect" or press ESC key to eliminate connection.

How to Exit

1. Click "Exit" or 'x' button to close the program