PERIPHERALS AND POWER SUPPLY

Day 3: Peripheral Troubleshooting

1. Five Common Issues with USB Keyboards or Mice

1. **Keyboard or mouse is not working.** Solution: Unplug the USB device and connect it again. Try another USB port.
2. **Some keyboard keys are not working.** Solution: Check if dust is stuck under the keys and clean the keyboard properly.
3. **Mouse cursor is not moving.** Solution: Reconnect the mouse and check it in another USB port.
4. **Keyboard or mouse works slowly.** Solution: Restart the laptop and close unnecessary programs.
5. **USB device connects and disconnects repeatedly.** Solution: Check the USB cable and port. If possible, try another device.

2. Troubleshooting Bluetooth Headphones

If my Bluetooth headphones are not connecting to my phone, I will follow these steps:

6. First, I will check whether the headphones have enough battery.
7. I will turn on Bluetooth on my phone from Settings.
8. I will check that the headphones are switched on and in pairing mode.
9. I will open Settings, select Bluetooth, and check the list of available devices.
10. If the headphones are connected to another device, I will disconnect them from that device.
11. If the headphones are already saved on my phone, I will select them and tap Forget or Unpair.
12. I will put the headphones into pairing mode again and select their name from the available devices.
13. I will check whether the status says Connected and play music to test the sound.
14. If they still do not connect, I will turn Bluetooth off and on again and restart my phone.
15. Finally, I will try connecting the headphones to another phone to find out whether the problem is with the headphones or my phone.

3. Checklist for an External Webcam Not Detected in Zoom on Windows 10

16. **Check the USB connection.** Unplug the webcam and connect it again. I will also try another USB port.
17. **Check Device Manager.** Open Device Manager and look under Cameras or Imaging devices. Check whether the webcam is listed or has a warning symbol.
18. **Check camera privacy settings.** Go to Settings > Privacy > Camera and make sure camera access is turned on.
19. **Check app permissions.** Make sure apps are allowed to access the camera and desktop apps can use the camera.
20. **Check Zoom settings.** Open Zoom, go to Settings > Video, and select the correct webcam from the camera list.
21. **Restart and test the webcam.** Close other apps that may be using the camera, restart Zoom, and test again. If needed, restart the laptop.

4. Troubleshooting a Printer Showing Offline

If a printer shows Offline on a Windows PC, I will follow these steps:

22. First, I will check whether the printer is switched on and connected properly to the computer or Wi-Fi.
23. I will open Settings on the PC and select Devices.
24. I will click Printers & scanners and select my printer.
25. I will click Manage and look for the option to run the troubleshooter, if available.
26. The Windows Troubleshooter will check for common printer problems related to the connection, settings, and drivers.
27. It may show the problem it finds and suggest a solution. I will follow the instructions given by the troubleshooter.
28. After completing the steps, I will print a test page to check whether the printer is working.

Information provided by the Troubleshooter:

- It checks for common printer problems.
- It may identify connection or configuration issues.
- It provides suggestions to fix detected problems.
- It may report whether the problem was fixed or if further action is needed.

Conclusion

By following these simple troubleshooting steps, we can find and fix many common problems with keyboards, mice, Bluetooth headphones, webcams, and printers.