

Robocup

Documentation


Connection Diagrams




| Page | Description |
|-------------|--------------------------------------|
| 03 | Power |
| 04 A | Color Sensor |
| | B DC Motor Drive PWM |
| 05 C | DC Motor Drive Encoder |
| | D DC Motor Drive Main |
| 06 E | IMU |
| | F IR Camera |
| 07 G | IR Distance Sensor Digital |
| | H IR Distance Sensor Analogue |
| 08 I | Joystick |
| | J LED RGB |
| 09 K | LED Smart |
| | L LED Traffic |
| 10 M | Load Cell |
| | N Mag Sensor |
| 11 O | Microswitch |
| | P RFID |
| 12 Q | Servo |
| | R Smart Servo Single |
| 13 S | Smart Servo Multi |
| | T Stepper |
| 14 U | Switch Electromagnet |
| | V Switch Solenoid |
| 15 W | TOF I2C |
| | X TOF Serial |
| 16 Y | Ultrasound Digital |




Power




Color Sensor




DC Motor Drive PWM




DC Motor Drive Encoder




DC Motor Drive Main




IMU




IR Camera




IR Distance Sensor Digital




IR Distance Sensor Analogue




Joystick




LED RGB




LED Smart




LED Traffic




Load Cell




Mag Sensor




Microswitch




RFID




Servo




Smart Servo Single




Smart Servo Multi




Stepper




Switch Electromagnet




Switch Solenoid



TOF I2C



TOF Serial



Ultrasound Digital

