

RDWC 2-Pot Build Guide

A two-site recirculating deep water culture system

Difficulty: Beginner–Intermediate • Build time: A weekend

This RDWC build links two grow buckets to a shared control/reservoir bucket. Because all buckets share the same water, you dose and check pH/EC in one place and every plant gets the same feed. A great step up once you are comfortable with a single bucket.

Parts list

5-gallon buckets with lids	3 (2 grow + 1 control/reservoir)
6" mesh net-pot lids	2
3/4" uniseal or bulkhead fittings	6
3/4" flexible tubing / PVC	~7 ft (to link buckets in a loop)
Submersible water pump	1 × 400+ GPH submersible
Air pump	1 × Dual-outlet air pump (~10W)
Air stones (large)	3 (one per bucket + control)
Airline tubing	~9 ft
Clay pebbles (hydroton)	1 × 10L bag
Net cups (if not using mesh lids)	2
Hydroponic nutrients	1 starter set
pH & EC meter + pH Up/Down	1 set

Tools

- Cordless drill
- 2" or 3" hole saw (for net-pot lids, if not pre-cut)
- 1-1/2" hole saw or step bit (for uniseal fittings)
- Tape measure and marker
- Utility knife
- Bucket of clean water (to leak-test)

Assembly

1. Lay out your buckets: place the control/reservoir bucket where you can easily reach it, with the grow bucket(s) around it.
2. Drill the linking holes: near the base of each bucket, cut a 1-1/2" hole for the 3/4" uniseal. Keep all holes at the same height so water levels equalize.
3. Fit the uniseals and connect the buckets in a loop with 3/4" tubing or PVC, running through the control bucket. Push fittings in fully for a watertight seal.
4. Install the mesh net-pot lids on the grow bucket(s).
5. Place the air stones — one in each of the 2 grow bucket(s) and one in the control bucket — and run airline tubing back to the air pump.
6. Set the water pump in the control bucket to circulate solution through the loop (or plumb it to your return line).

7. Leak-test with plain water: run the system for an hour and check every fitting before adding plants or nutrients.
8. Add clay pebbles to the net pots, seat your seedlings, then fill with pH-balanced nutrient solution until it just touches the bottom of the net pots.
9. Turn on the air pump (24/7) and the water pump, and you are growing.

First run & maintenance

- Check pH every 1–2 days and keep it at 5.5–6.5.
- Keep the reservoir cool — under 68°F (20°C) — to hold oxygen and prevent root rot.
- Top up with pH-balanced plain water as the level drops; do a full change every 1–2 weeks.
- Watch the roots: bright white = healthy; brown/slimy = raise oxygen and lower temperature.

Safety & legal

Keep all electrical connections (pumps, timers) off the floor and use a drip loop. Grow and consume only what is legal in your area, and keep your setup away from children and pets. This guide is provided for educational purposes by Elevated Masses LLC.

