## **CS224 – Spring 2019 - Lab #7** (Version 2, May 11, 2019 13:02 am)

## **Programming PIC32 Microcontroller**

**Dates:** The same for all sections. Wednesday May 15. 13:30. You do the work at home, no need to come to the lab. You have to do the work individually: It is NOT A TEAM WORK.

#### **Purpose:**

The new version of the lab assignment only involves C to MIPS assembly language conversion. Purpose of the practice is understanding the fundamental principles of PIC32 programming that involves I/O and bit operations on this microcontroller.

#### **Summary**

Introduction to PIC32 programming.

#### **DUE DATE: SAME FOR ALL SECTIONS:**

1. Please bring and drop your work into the box(es) provided in front of TA office room number EA-407 by 13:30 on Wednesday May 15.

YES paper submission this time too.

 Please upload your work to the Unilica by 13:30 on Wednesday May 15. Use filename StudentID\_FirstName\_LastName\_SecNo\_LabNo.txt Only a NOTEPAD FILE (txt file) is accepted.

You are required to read the instructions provided on this document. No excuses will be accepted.

YES paper submission this time too. YES paper submission this time too. YES paper submission this time too. YES paper submission this time too.

No late submission will be accepted. No late submission will be accepted. No late submission will be accepted. No late submission will be accepted.

Upload txt. Upload txt.

### C to MIPS Assembly Language Conversion (100 points)

At the top of your submission provide the following information.

CS224 Section No.: ... Spring 2019 Lab No.: Your Full Name/Bilkent ID:

Convert the C programs 1 & 2 into MIPS assembly language.

For register addresses of PIC32 please refer to the class handout or the PIC32 datasheets (see the Lab7 Unilica folder).

In the body make sure that you clearly indicate what is provided for what:

- Clearly indicate the programs. At the beginning of each program provide your name and section in a comment line.
- 2. Use consistent and meaningful format in your MIPS code. Neat and understandable presentation is important during grading.
- 3. In your conversion from C to MIPS for each C statement first give the C statement as a MIPS comment line then provide the symbolic MIPS instruction(s) you generate for that C statement. Do this for each C statement so that your TA will be able to follow your presentation. If this is not provided 50 points will be taken off from your grade upfront.
- 4. If a C code line does not require any code in MIPS, like declarations etc., just provide the C code.
- 5. In your presentation delete the comments of the C code.

## Program No. 1 (40 points)

```
void initspi(void) {
    char junk;
    SPI2CONbits.ON = 0; // disable SPI to reset any previous state
    junk = SPI2BUF; // read SPI buffer to clear the receive buffer
    SPI2BRG = 7;
    SPI2CONbits.MSTEN = 1;// enable master mode
    SPI2CONbits.CKE = 1; // set clock-to-data timing
    while(!SPI2CONbits.DONESSEN); // Check the SSEN bit
    SPI2CONbits.ON = 1; // turn SPI on
}
```

## Program No. 2 (60 points)

```
// This code shows and rotates the pattern (10001000) right or stops based on the
input coming from the user. The pattern is to be shown on the LEDs.
int stop = 0;
int initial = 0b01110111; //Initial pattern. Note that 0 means on, while 1 means off.
int right = 1;
void main() {
   TRISD = 0x0; // All bits of PORTD are output. ~0 means output~
// Three bits of PORTA are inputs but only one of them is used in this example as a
stop button, others are redundant. ~1 means input~
      TRTSA = 0b111:
// From PORTD, outputs will be sent to LEDs. Make sure that you physically connected
them by looking at the Figure 1, in the directives document.
// Initial pattern is sent to the LEDs through PORTD.
    PORTD = initial;
    while(1){
             int lsb;
              \ensuremath{//} Stop button is the push-button which is labeled as 1 on the board.
             if(PORTABits.RA1 == 0) { // If stop button clicked
                  stop = !stop;
                  if(!stop){
// If process restarted, copy initial pattern into PORTD.
```

#### **APPENDIX**

# HOW TO FIND MEMORY ADDRESSES OF REGISTERS AND HOW TO ACCESS THEIR BITS: AN EXAMPLE

Translate the following C code into MIPS assembly code, as the PIC32 compiler would based on the p32xxxx header file. You can refer to the Table 4-16 from the PIC32 datasheet. Use only real MIPS instructions.

```
int readadc (void) {
                     AD1CON1bits.SAMP = 0;
                     while (!AD1CON1bits.DONE);
                     AD1CON1bits.SAMP = 1;
                     AD1CON1bits.DONE = 0;
                     return (ADC1BUF0);
readadc:
              lui $t0, 0xBF80
                                            // load AD1CON1 address into $t0
               ori $t0, $t0, 0x9000
                                                 // (0xBF809000 from Table 4-16)
               lw $t1, 0 ($t0)
                                                   // get AD1CON1 value into register $t1
                                      // AND mask to clear bit 1 (SAMP bit)
               andi $t1, $t1, 0xFFFD
                                                   // store value back to AD1CON1
               sw $t1, 0 ($t0)
while:
               lw $t1, 0 ($t0)
                                                   // get AD1CON1 value into register $t1
               andi $t2, $t1, 0x0001
                                            // AND mask to clear all bits except bit 0
                                             // (DONE bit)
               beq $t2, $0, while
                                            // spin in while loop until DONE = 1
               ori $t1, $t1, 0x0002
                                           // OR mask to set bit 1 (SAMP bit)
```

What is the address of ADCON1: Find AD1CON1 in the data sheets of PIC32 (see the documents folder in Unilica for the data sheets, or web). On that table take the number on the left upper corner (BF80) from the table contains AD1CON1 and take the number horizontally aligned with AD1CON1 (9000) and concatenate them, it becomes 0XBF809000. See the firts 3 lines of the MIPS code above.

**How to access AD1CON1bits.SAMP:** Bit names of AD1CON1 are horizontally available next to AD1CON1 on the right hand side in two narrow lines/rows. Lower line shows the bit positions 0 to 15 and the upper line shows the bit position 16 to 31/ Notice the notation 31/15 to 16/0. Bit position of SAMP is 2. For clearing the SAMP bit see the 4th line of the MIPS code.

100	1	E 4-16:	7	JO KLC	C REGISTER MAP															7
Salah Andre	The second		Bit Range	31/15	30/14	29/13	28/12	27/11	26/10	25/9	24/8	23/7	22/6	21/5	20/4	19/3	18/2	17/11	16/0	
Ė		D. COM (II)	31:15		111-1-1			S:-14	1-1-1-2		2,	6:9	1-4- · · ·		12	10 -01		1	1/-	V
Ja	9000	(D1CON1(1)	15:0	ON	FRZ	SIDL	0.,- (4)	· - 100		FORM<2:0>			SSRC<2:0		CLRASAM	٠٠ استوال	ASAM	SAMP	DONE	1
	9010	AD1CON2(1)	31:16	110	1.1300 . 11	.:	وأأرست ومرا	11: -11:	5 mm - and		diame.		-10- 111	100 to 100 per	Y 12.	m 100 154	111-111	-		11 0
1	3010		15:0	VCFG2	VCFG1	VCFG0	OFFCAL	13.47	CSCNA	100-00		BUFS	1 4 - 15 C	70	SMPI	<3:0>	Tab 132	BUFM	ALTS	- 0
	9020	D1CON3(1)	31:16	ADRC	03,-76		100- 200	7.1-20	SAMC<4:03	THE RESERVE OF THE PARTY OF THE	1237-120	11,	10 10 10 1	111.00	ADCS		1 11 - 12	1227-66	1	0
			31:16	CHONB										CHOS	10SA<3:0>					
	9040	AD1CHS <sup>(1)</sup>	15:0	12-11	::;	111-11	10- a	<del></del>		111-11	20-100	<del>-</del> 32011	465-1	860-18		23-13		15-16	·i	. 0
1	9060	AD1PCFG <sup>(1</sup>	31:16	1.40-144	2:1	10-1	P - 11	4	00-my 5	Home	310/- v.si	4 (	100 mg	411-41	-	21-40	90; m	ali-ter	3:-1	. 0
	3000	1011010	15:0	PCFG15	PCFG14	PCFG13	PCFG12	PCFG11	PCFG10	PCFG9	PCFG8	PCFG7	PCFG6	PCFG5	PCFG4	PCFG3	PCFG2	PCFG1	PCFG0	0
	9050	AD1CSSL(1	31:16	000146	000144	000140	CSSL12	CSSL11	0000140	00010	CSSL8	CSSL7	CSSL6	CSSL5	CSSL4	CSSL3	CSSL2	15:-00	00010	: 01
11			15:0	CSSL15	CSSL14	CSSL13	COSEIZ	COSTIL	CSSL10	CSSL9				CSSES	LSSL4 1	LSSLS	CSSLZ	CSSL1	CSSLO	00
1	9070	ADC1BUF	15:0	1						ADC Re	sult Word 0	(ADC18UFC	><31:0>)							00
11	9080	ADC1BUF	31:16		ADC Result Word 1 (ADC18UF1<21:0>)															
Н	9000	ADCIBUR	15:0			200				AUGRO	Still Word 1	MUCTBOF	-31.0-1							0.0
1	9090	ADC1BUF	2 31:16							ADC Re	sult Word 2	(ADC1BUF2	(<31:0>)							00
	-		34:16			-				-				-			-		15	00
	90A0	ADC1BUR	15:0						_	ADC Re	sult Word 3	(ADC1BUF3	(<31;0×)							00
	SOR	ADC1BUS	31:1							ADC Re	suit Word 4	(ADC1BUF4	(<31:0>)	-31010						00
ш	100	11001001	15:0	000																
ш	900	0 ADC1BU	5 31:1		ADC Result Word 5 (ADC18UFS<31:D>)															
II.	000	0 4004014	3111							ADC PA	Abrel & fue	ADCIBLIER	1431(Ob)							000
II	900	D ADC1BU	150		ADC Result Word 6 (ADC18UF8<31,0>)															
II	90E	D ADC1BU	F7 31:1							ADC Re	sult Word 7	(ADC1BUF7	<31:0>)						-	000
11	-		150			-	-				Constitution of the last	at a factor of the	CONTRACTOR OF	-		-	-	-	_	0000
	90F	O ADC1BU	F8 15:							ADC Re	suit Word 8	(ADC1BUF8	<31:0>)						- 5-	0000
	910	00 ADC1BL	31:		9.99			1000	47	ADC Re	suit Word 9	(ADC18UE9	c31:0>1		100				-	1000
	311	- CIBC	15		Von vasim mana (von tenta attn)													0000		
- 11	91	10 ADC1BU	JFA 31:							ADC Re	sult Word A	(ADC1BUFA	<31:0×)							0000
			251							100000	200		2000							000
and the land for	91	9120 ADC18UF8 (31:0) ADC Result Word 8 (ADC18UF8-31:0>)											000							