# tymp legio

## _travelers guide
## _for boinging across the galaxy

| 2 switches · 3 ways | 3 cv inputs | 6 hp |
|---|---|---|

[ pitch ] press  [ pitch ] hold  › then  noon = 12 o'clock  tags = the panel drawing

synthetic drum voice · boing, cat and boot modes · ducks whatever comes into quack

← back to the legio starsystem

= hold

## 01 what it is — ty_01

| | |
|---|---|
| drum voice | punchy synthetic hits |
| three modes | boing, cat, boot |
| ducking | quack audio dips under the hits |
| in L R | quack · audio in · L feeds R if alone |
| out L R | stereo out, up to 16 V peak to peak |
| platform | a legio firmware · other firmwares |

## 02 pitch — ty_02 · enc

| | |
|---|---|
| [ enc ] turn | fine tune |
| [ enc ] press + turn | coarse tune |
| enc jack | pitch jack · –2 to +5 V |

## 10 first flight — ty_10 · the manual's tutorial

1. triggers into trig
2. out to the mixer
3. pick a s1 mode
4. shape 1 + 2
5. flip s2 for variations

## 03 decay · wack — ty_03 · knobs 1 + 2

| | |
|---|---|
| 1 [ decay ] | voice decay · also the quack duck time |
| 2 [ wackitude ] | timbre |

## 04 mode · tang — ty_04 · s1 · s2 · top → bottom

| | |
|---|---|
| s1 boing | hats, bells, metal · no ducking |
| s1 cat | snares, toms, noise · quack ducks |
| s1 boot | kicks, subs, lasers · quack ducks |
| s2 tang | a variation inside each mode |

## __fig.01 : signal path — in → out





as the manual describes it

## 05 jacks — ty_05 · trig · cv · audio

| | |
|---|---|
| trig hit | fires the voice + the duck · near +1.6 V |
| in quack L R | audio in, ducked in cat and boot · L feeds R |
| out L R | up to 16 V peak to peak |
| cv | pitch –2 to +5 V · decay + wack 0 – 5 V |

## __fig.02 : the drum chain — out → mix in

any order · no mixer needed




## 08 patch ideas — ty_08 · the manual

**ducked bed** — cat · boot
a pad or loop into quack

**metal** — boing
hats and bells, quack passes untouched

**subs** — boot
long decay, low pitch

## __fig.03 : the panel

numbers match the legend




- enc **pitch** · fine tune
- 1 **decay** · voice decay
- 2 **wack** · timbre
- s1 **mode** · boing · cat · boot
- s2 **tang** · up · mid · down
- trig **hit** · fires the voice + the duck
- cv **pitch** · **1** · **2** · pitch –2…+5 V · others …
- in **quack L / R** · L feeds R if alone
- out **out L / R** · stereo out

## 09 specs — ty_09

| | |
|---|---|
| size | 6 hp · 1.5 in deep |
| power | 140 mA +12 V · 22 mA –12 V |
| cv in | 0 – 5 V · pitch –2 to +5 V |
| trig | rising edge near +1.6 V |
| boot LEDs | blue / green |
| calibrate | power on with nothing in pitch cv to recalibrate |

design homage to the house of x / powers of x data pages — designed by tom muller with jonathan hickman · panel drawing after the noise engineering legio overlay template
not affiliated with noise engineering or marvel

conceived by mellotom · legio-tymp-navigator ... 00.10_01
created with claude