lacrima versio

_travelers guide
_for crying in the nebula

3	3	7
drive spots	filter shapes	knobs · 2 switches · hit

[hit] press **[hit]** hold › then noon = 12 o'clock numbers = the numbered panel

envelope-followed filter + drive · the devil's autowah · stereo chorus · a free firmware for any versio

← back to the versio starsystem

cyan = hold

01 what it is

lv_01

an autowah	envelope follower, a screaming state-variable filter, drive, stereo chorus and audio-rate mod
in 1 in 2	stereo in
out 1 out 2	stereo out
every knob	an offset added to its cv jack, 0 – 5 V
swap in	free on any versio · how to swap

02 the filter

lv_02 · knobs 3 · 4 · 5

3 [l/b/h]	morphs lowpass → bandpass → highpass
4 [freq]	base cutoff
5 [q]	resonance · enough to self-oscillate

10 first flight

lv_10 · the classic wah

1. a synth line, drum loop or recording into **in 1** · **out 1** **out 2** to your mixer
2. **2** [sat] **4** [freq] **5** [q] **7** [mod] min
3. **1** [blend] noon · **6** [env] max
4. raise q until the filter talks
5. add sat · try pre, bet, aft
6. **xyz** i or ii for width

03 envelope

lv_03 · knob 6 · fig.01

6 [env]	how far the envelope moves the cutoff · noon none
right of noon	louder input opens the filter
left of noon	louder input closes it
[hit]	fires the envelope by hand

__fig.01 : env

knob 6 · bipolar



04 blend · sat · mod

lv_04 · knobs 1 · 2 · 7

1 [blend]	dry left · wet right · chorus ignores blend
2 [sat]	saturation · where it sits is set by abc
7 [mod]	audio-rate modulation · top third adds octaves

__fig.04 : signal path

as far as the manual says



the envelope (6 env, hit) moves the cutoff · 7 mod adds audio-rate wobble


05 switches

lv_05 · abc · xyz

abc left	[pre] drive at the input
abc mid	[bet] drive between the two filters
abc right	[aft] drive after the filters
xyz left	[0] chorus off
xyz mid	[i] slow chorus
xyz right	[ii] faster chorus

__fig.02 : where the drive goes

abc · pre · bet · aft



07 hit

lv_07 · fsu = hit

[hit]	trigger the envelope follower
fsu jack	gate in · above 2 V · the manual doesn't say more
boot	cyan · yellow · yellow · magenta = lacrima is loaded

08 two patches

lv_08 · from the manual · abc · xyz

classic wah — any · i / ii
a dynamic source in · sat, freq, q, mod min · blend noon · env max · q until it talks · then sat and abc for flavour

self-oscillating drums — pre · 0
trigger patterns into in 1 (+ in 2) · freq + mod min · q, sat, env max · each trigger pings a ringing sweep · tune with freq + env

__fig.06 : what the LEDs say

at boot



__fig.03 : the panel

numbers match the legend



1	blend · dry ↔ wet
2	sat · drive
3	l/b/h · lp → bp → hp
4	freq · cutoff
5	q · self-oscillates
6	env · close ← · → open
7	mod · audio-rate · top = 8va
abc	drive · pre · bet · aft
xyz	chorus · 0 · i · ii
fsu	hit · fire the envelope
in	in 1 / 2 · stereo in
out	out 1 / 2 · stereo out

09 specs

lv_09

cv in	0 – 5 V
fsu gate	above 2 V
audio in	clips near 16 V peak to peak
size	10 hp · 1.5 in deep
power	70 mA +12 V · 70 mA –12 V · no 5 V

design homage to the house of x / powers of x data pages — designed by tom muller with jonathan hickman · panel art: noise engineering
not affiliated with noise engineering, mathias kettner or marvel