# ruina versio

## _travelers guide
## _for ruining planets

| 5 | 128 | 7 |
|---|---|---|
| kinds of damage | dB of smoosh | knobs · 2 switches · smoosh |

[ smoosh ] press  [ smoosh ] hold  › then  noon = 12 o'clock  numbers = the numbered panel

stereo multi-distortion · fold, doom, rectify, saturate · smoosh · a free firmware for any versio

← back to the versio starsystem

magenta = hold

## 01 what it is

rv_01

| | |
|---|---|
| a distortion box | stereo wavefolding, octave-down doom, phase, multiband saturation, rectifying and a notch |
| in 1 in 2 | stereo in · in 1 alone feeds both sides |
| out 1 out 2 | stereo out |
| every knob | an offset added to its cv jack, 0 – 5 V |
| swap in | free on any versio · how to swap · video |

## 02 fold · doom · 8vize

rv_02 · knobs 2 · 4 · 7

| | |
|---|---|
| 2 [ fold ] | wavefolder, after the infinifolder |
| 4 [ doom ] | sub-octave chorus · louder and more out of tune as it rises |
| doom top 1/4 | overtone buzz joins in |
| 7 [ 8vize ] | full-wave rectifier, after pura ruina |

## 10 first flight

rv_10 · the least distorted start

1. a saw into in 1 · out 1 out 2 to your mixer
2. 3 [ center ] 6 [ drive ] 5 [ phase ] 7 [ 8vize ] at noon
3. 4 [ doom ] + 2 [ fold ] fully left · 1 [ blend ] fully right
4. both switches left (und · off)
5. bring in fold, doom, drive, 8vize · then phase
6. last: center + the notch, the chains, then [ smoosh ]


## 03 drive · center

rv_03 · knobs 6 + 3 · fig.01

| | |
|---|---|
| 6 [ drive ] | multiband saturation, after seca ruina |
| ccw · cw | lowest band alone · highest band alone · blends through four bands between |
| 3 [ center ] | width + place of the middle band · also the notch frequency in trk |

### __fig.01 : drive bands

knob 6 · multiband




## 04 phase · blend

rv_04 · knobs 5 + 1

| | |
|---|---|
| 5 [ phase ] | shifts left against right · width and phasing |
| 1 [ blend ] | dry left · both at noon · only the wreckage right |

## 05 switches

rv_05 · abc · xyz · fig.02

| | |
|---|---|
| abc left | [ und ] fold → doom → rectify → saturate |
| abc mid | [ x ] fold → saturate → rectify → doom |
| abc right | [ ovr ] fold → doom → rectify → saturate → fold again |
| xyz left | [ off ] no notch |
| xyz mid | [ on ] notch fixed at 1 kHz |
| xyz right | [ trk ] notch follows center |

### __fig.02 : the three chains

abc · und · x · ovr




## 07 smoosh

rv_07 · fsu = smoosh

| | |
|---|---|
| [ smoosh ] | 128 dB of gain while held |
| fsu jack | a gate does the same · above 2 V |
| boot | cyan · cyan · magenta · magenta = ruina is loaded |

## 08 three patches

rv_08 · from the manual

**first patch** — und · off
a saw into in 1 · center, drive, phase, 8vize at noon · doom + fold fully left · blend fully right · then fold, doom, drive, 8vize, phase, center, the switches, smoosh

**drum crusher** — any
blend noon · fold + doom left · distort with drive, center, 8vize · hit smoosh

**smoosh sequencing** — any
gate patterns into smoosh on a simple wave · or mult the drum trigger · or random triggers

### __fig.04 : signal path

from the manual




the manual doesn't give the exact place of notch + phase

### __fig.06 : what the LEDs say

at boot

boot — ruina is loaded

### __fig.03 : the panel

numbers match the legend




1. **blend** · dry ↔ wet
2. **fold** · wavefolder
3. **center** · middle band · notch
4. **doom** · sub-octave chorus
5. **phase** · L vs R
6. **drive** · multiband sat
7. **8vize** · rectifier

abc **chain** · und · x · ovr
xyz **notch** · off · on · trk
fsu **smoosh** · 128 dB gain
in **in 1 / 2** · in 1 feeds both if alone
out **out 1 / 2** · stereo out

## 09 specs

rv_09

| | |
|---|---|
| cv in | 0 – 5 V |
| fsu gate | above 2 V |
| audio in | clips near 16 V peak to peak |
| size | 10 hp · 1.5 in deep |
| power | version a 70 mA +12 V · 70 mA –12 V · version b 125 mA · 10 mA · no 5 V |