

sn_found_verify_failed_Modificado

INFORMACIÓN BASE DEL SISTEMA EXPERTO

TIPO:

Modo de Falla

USO:

Diagnóstico y tratamiento del error sn_found_verify_failed detectado durante la estación de Provisioning.

APLICA CUANDO:

- La unidad falla en Provisioning.
- En Radix aparece el estatus sn_found_verify_failed.
- Existen problemas de validación o almacenamiento de logs.
- Se requiere determinar la acción correctiva asociada al canal afectado.

AREA:

PROVISIONING

REPARACION

DEBUG

DIAGNOSTICO

IST

KEYWORDS:

sn_found_verify_failed

Provisioning

Radix

Dauntless

Memory

Channel Block

Ghostfish

Functional Failure

U46_0

U47_0

RESUMEN:

Este modo de falla se identifica en Radix como sn_found_verify_failed. El procedimiento indica enviar la unidad a desensamblar y reemplazar el Dauntless defectuoso junto con la memoria asociada para evitar bloqueos del canal.

USO RAPIDO:

1. Confirmar falla sn_found_verify_failed en Radix.
2. Enviar unidad a desensamble.
3. Identificar canal afectado.
4. Reemplazar Dauntless defectuoso.
5. Reemplazar memoria asociada.
6. Registrar reparación.
7. Reingresar unidad al flujo de validación.

ACCION CORRECTIVA:

- Desensamble de unidad.
- Cambio de Dauntless defectuoso.
- Cambio de memoria relacionada.
- Validación posterior en flujo de pruebas.

CASO DOCUMENTADO:

Serial: FLG2620-00255

Observación: Cambiar U46_0 y U47_0.

RELACIONADO CON:

- Provisioning
- Radix
- Diagnóstico funcional
- Fallas de canal
- Reparación de PCBA

SALIDA ESPERADA:

Recuperación del canal afectado y validación exitosa de Provisioning sin recurrencia del error sn_found_verify_failed.

sn_found_verify_failed

Este modo de falla se ve reflejado en radix de la siguiente manera

FAILED	sn_found_verify_failed
--------	------------------------

Se debe mandar a desensamble y se tiene que cambiar el dauntless que falla así como la memoria para evitar que se bloquee el canal.

FLG2620-00255

FLG2620-00255 Repair Count 2

Test Information
Station PROVISIONING_STATUS yee admin Finish Time 2026-05-26 14:42:38.05
Failure List **Provisioning_Logs_Fail**

Enter Defect information for above failure. After that click Add button to get back to Test Detail screen

Defect List

Assembly - Functional failure

Description **Assembly - Functional failure**

☐ Load All Part Number ☒ Load All RefDesignator

RefDesignator
PCBA0

Part Number
PLO-GFC-1210549-04-FG [A]

Assy, PCBA/SCP, 4up, Ghostfish,Delta VPWR, SEC HB

Remark
unidad en seguimiento, cambiar U46_0 y U47_0

Defect Type

Defect List

- Mechanical - Routing, Delam [Mechanical - Routing, Delam]
- Visual - Foreign Material, Excess Solder Mask, Missing Fiducial [Visual - Foreign Material, Excess Solder Mask, Missing Fiducial]
- Mechanical - Contamination/Foreign Material [Mechanical - Contamination/Foreign Material]
- Mechanical - Missing Feature [Mechanical - Missing Feature]
- Label - Missing / Damaged or Not Legible [Label - Missing / Damaged or Not Legible]
- Label - Duplicate SN [Label - Duplicate SN]
- Assembly - Wrong Part [Assembly - Wrong Part]
- Assembly - Missing part or hardware [Assembly - Missing part or hardware]
- Assembly - Fasteners improperly torqued [Assembly - Fasteners improperly torqued]
- Assembly - Fit issue [Assembly - Fit issue]
- Assembly - Functional failure [Assembly - Functional failure]
- Welding - Missing [Welding - Missing]
- Welding - Fractured [Welding - Fractured]
- No Output (NOP) [No Output (NOP)]
- Wrong Output [Wrong Output]
- No Input [No Input]
- System Can Not Detect [System Can Not Detect]

FLG2620-00255 Repair Count 2

Test Information
Station PROVISIONING_STATUS yee admin Finish Time 2026-05-26 14:42:38.05
Failure List **Provisioning_Logs_Fail**

Enter Defect information for above failure. After that click Add button to get back to Test Detail screen

Defect List

Assembly - Functional failure

Description **Assembly - Functional failure**

☐ Load All Part Number ☒ Load All RefDesignator

RefDesignator
PCBA0

Part Number
PLO-GFC-1210549-04-FG [A]

Assy, PCBA/SCP, 4up, Ghostfish,Delta VPWR, SEC HB

Remark
unidad en seguimiento, cambiar U46_0 y U47_0

Defect Type

Defect List

- Mechanical - Routing, Delam [Mechanical - Routing, Delam]
- Visual - Foreign Material, Excess Solder Mask, Missing Fiducial [Visual - Foreign Material, Excess Solder Mask, Missing Fiducial]
- Mechanical - Contamination/Foreign Material [Mechanical - Contamination/Foreign Material]
- Mechanical - Missing Feature [Mechanical - Missing Feature]
- Label - Missing / Damaged or Not Legible [Label - Missing / Damaged or Not Legible]
- Label - Duplicate SN [Label - Duplicate SN]
- Assembly - Wrong Part [Assembly - Wrong Part]
- Assembly - Missing part or hardware [Assembly - Missing part or hardware]
- Assembly - Fasteners improperly torqued [Assembly - Fasteners improperly torqued]
- Assembly - Fit issue [Assembly - Fit issue]
- Assembly - Functional failure [Assembly - Functional failure]
- Welding - Missing [Welding - Missing]
- Welding - Fractured [Welding - Fractured]
- No Output (NOP) [No Output (NOP)]
- Wrong Output [Wrong Output]
- No Input [No Input]
- System Can Not Detect [System Can Not Detect]