

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode             | Type                   | System                               | System | Function |                 |                  |                  |                |                  |
|--------------|------------------|------------------------|--------------------------------------|--------|----------|-----------------|------------------|------------------|----------------|------------------|
|              |                  |                        |                                      |        | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function |
| Agricultural | Fastrac Tractors | 2000-3000              | Diagnostics                          |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Fastrac Tractors | 3000 Series 2          | 3000 Diagnostics                     |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Fastrac Tractors | 3000 Series 3          | Diagnostics                          |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Fastrac Tractors | 3000 Series 4          | Diagnostics                          |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Fastrac Tractors | 4000 Series            | Diagnostics                          |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Fastrac Tractors | 4000 Series            | EHFS Tool                            |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Fastrac Tractors | 7000 Series            | 7000 Diagnostics                     |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Fastrac Tractors | 8000 Series 3          | 8000 Series 3 Diagnostics            |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Fastrac Tractors | 8000 Series 4          | 8000 Series 4 Diagnostics            |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Fastrac Tractors | 8250 Series 2          | 8250 Series 2 Diagnostics            |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Telemasters      | TM220                  | CWL/TM Cluster Diagnostics           |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Telemasters      | TM220                  | Hydraulic Controller Diagnostics     |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Telemasters      | TM220                  | Immobiliser Diagnostics              |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Telemasters      | TM220                  | LiveLink Diagnostics                 |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Telemasters      | TM220                  | T3 40kph Diagnostics                 |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Telemasters      | TM220                  | T4 40Kph Controller Diagnostics      |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Telemasters      | TM320 T4i              | Hydraulics Diagnostics               |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Telemasters      | TM320 T4i              | Transmaster Transmission Diagnostics |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Telemasters      | TM320 Tier 4 Final Mk1 | Hydraulics Diagnostics               |        | ✓        | ✓               | ✓                | ✓                | -              | -                |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                | Type                   | System                               | System | Function |                 |                  |                  |                |                                    |
|--------------|---------------------|------------------------|--------------------------------------|--------|----------|-----------------|------------------|------------------|----------------|------------------------------------|
|              |                     |                        |                                      |        | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                   |
| Agricultural | Telemasters         | TM320 Tier 4 Final Mk1 | Transmaster Transmission Diagnostics |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Agricultural | Telemasters         | TM320 Tier 4 Final Mk1 | VSFC Diagnostics                     |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Agricultural | Telemasters         | TM320 Tier 4 Final Mk2 | Hydraulics Diagnostics               |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Agricultural | Telemasters         | TM320 Tier 4 Final Mk2 | Immobiliser Diagnostics              |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Agricultural | Telemasters         | TM320 Tier 4 Final Mk2 | LiveLink Diagnostics                 |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Agricultural | Telemasters         | TM320 Tier 4 Final Mk2 | Transmaster Transmission Diagnostics |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Agricultural | Telemasters         | TM320 Tier 4 Final Mk2 | VSFC Diagnostics                     |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Agricultural | Telemasters         | TM420 Tier 4 Final     | Hydraulics Diagnostics               |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Agricultural | Telemasters         | TM420 Tier 4 Final     | Immobiliser Diagnostics              |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Agricultural | Telemasters         | TM420 Tier 4 Final     | LiveLink Diagnostics                 |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Agricultural | Telemasters         | TM420 Tier 4 Final     | Transmaster Transmission Diagnostics |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Agricultural | Telemasters         | TM420 Tier 4 Final     | VSFC Diagnostics                     |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Agricultural | Telescopic Handlers | 2007+                  | JCB Dieselmax engine setup           |        | -        | -               | -                | -                | -              | General Injtor Calibration         |
| Agricultural | Telescopic Handlers | 2007+                  | Service hours reset                  |        | -        | -               | -                | -                | -              | Service Hours<br>Service Hours T4i |
| Agricultural | Telescopic Handlers | 2007+                  | 526-SLC Setup                        |        | -        | -               | -                | -                | -              | Flowshare Current Settings         |
| Agricultural | Telescopic Handlers | 2007+                  | Boom angle calibration               |        | -        | -               | -                | -                | -              | Angle Sensor Calibration           |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                | Type   | System                               | System                         | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                             |
|--------------|---------------------|--------|--------------------------------------|--------------------------------|----------|-----------------|------------------|------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|              |                     |        |                                      |                                | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                            |
| Agricultural | Telescopic Handlers | 2007+  | JCB Engine Diagnostics               |                                | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests<br>Fuel System Diagnostics Test - Cranking<br>Fuel System Diagnostic Test - Engine Running<br>Fuel System Diagnostics<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Compoment Test |
| Agricultural | Telescopic Handlers | 2007+  | Loadall Diagnostics                  |                                | -        | -               | -                | ✓                | -              | -                                                                                                                                                                                                                                                           |
| Agricultural | Telescopic Handlers | 2007+  | Loadall LLMI Diagnostics             |                                | -        | ✓               | ✓                | ✓                | -              | -                                                                                                                                                                                                                                                           |
| Agricultural | Telescopic Handlers | 2007+  | Loadall 527 Transmission Diagnostics |                                | -        | -               | -                | ✓                | -              | -                                                                                                                                                                                                                                                           |
| Agricultural | Telescopic Handlers | 2007+  | Immobiliser Diagnostics              | Immobiliser                    | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                                                                                                                                           |
| Agricultural | Telescopic Handlers | Tier 4 | Machine buzzer mute                  |                                | -        | -               | -                | -                | -              | Machine buzzer mute                                                                                                                                                                                                                                         |
| Agricultural | Telescopic Handlers | Tier 4 | Setup/Calibration tools              |                                | -        | -               | -                | -                | -              | Boom Angle Calibration<br>Heater Fan Setup<br>EH Valve Tuning                                                                                                                                                                                               |
| Agricultural | Telescopic Handlers | Tier 4 | Service/reset tool                   |                                | -        | -               | -                | -                | -              | Service Hours Reset                                                                                                                                                                                                                                         |
| Agricultural | Telescopic Handlers | Tier 4 | Immobiliser Diagnostics              | Immobiliser                    | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                                                                                                                                           |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/Agri Diagnostics    | Loadall Fault Code Reader - T4 | -        | ✓               | ✓                | -                | -              | -                                                                                                                                                                                                                                                           |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/Agri Diagnostics    | Loadall Diagnostics - T4       | -        | -               | -                | ✓                | -              | -                                                                                                                                                                                                                                                           |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/Agri Diagnostics    | Powershift Diagnostics - T4    | -        | -               | -                | ✓                | -              | -                                                                                                                                                                                                                                                           |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                | Type   | System                                           | System                                | Function |                 |                  |                  |                |                  |
|--------------|---------------------|--------|--------------------------------------------------|---------------------------------------|----------|-----------------|------------------|------------------|----------------|------------------|
|              |                     |        |                                                  |                                       | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/Agri Diagnostics                | Loadall LLMI Diagnostics - T4         | -        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/Agri Plus and Super Diagnostics | Loadall Fault Code Reader - T4        | -        | ✓               | ✓                | -                | -              | -                |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/Agri Plus and Super Diagnostics | Loadall Diagnostics - T4              | -        | -               | -                | ✓                | -              | -                |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/Agri Plus and Super Diagnostics | Transmaster Diagnostics               | -        | -               | -                | ✓                | -              | -                |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/Agri Plus and Super Diagnostics | Loadall Pump Control Diagnostics - T4 | -        | -               | -                | ✓                | -              | -                |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/Agri Plus and Super Diagnostics | Loadall LLMI Diagnostics - T4         | -        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/Agri-Pro Diagnostics            | Loadall Fault Code Reader - T4        | -        | ✓               | ✓                | -                | -              | -                |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/Agri-Pro Diagnostics            | Loadall Diagnostics - T4              | -        | -               | -                | ✓                | -              | -                |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/Agri-Pro Diagnostics            | DualTECH VT Transmission Diagnostics  | -        | -               | -                | ✓                | -              | -                |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/Agri-Pro Diagnostics            | Loadall Pump Control Diagnostics - T4 | -        | -               | -                | ✓                | -              | -                |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/Agri-Pro Diagnostics            | Loadall LLMI Diagnostics - T4         | -        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/527-58 Diagnostics              | Loadall Fault Code Reader - T4        | -        | ✓               | ✓                | -                | -              | -                |
| Agricultural | Telescopic Handlers | Tier 4 | Diagnostics Tool/527-58 Diagnostics              | Loadall Diagnostics - T4              | -        | -               | -                | ✓                | -              | -                |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                | Type                   | System                              | System                                  | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                             |
|--------------|---------------------|------------------------|-------------------------------------|-----------------------------------------|----------|-----------------|------------------|------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|              |                     |                        |                                     |                                         | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                            |
| Agricultural | Telescopic Handlers | Tier 4                 | Diagnostics Tool/527-58 Diagnostics | Hydrostatic Transmission                | -        | -               | -                | ✓                | -              | -                                                                                                                                                                                                                                                           |
| Agricultural | Telescopic Handlers | Tier 4                 | Diagnostics Tool/527-58 Diagnostics | Loadall LLMI Diagnostics - T4           | -        | ✓               | ✓                | ✓                | -              | -                                                                                                                                                                                                                                                           |
| Agricultural | Telescopic Handlers | Tier 4                 | Engine Tools                        | JCB Ecomax Engine Setup for Loadall JVT | -        | -               | -                | -                | -              | General Injector Calibration<br>Actuators<br>Immobiliser<br>APS                                                                                                                                                                                             |
| Agricultural | Telescopic Handlers | Tier 4                 | Engine Tools                        | JCB Ecomax Engine setup                 | -        | -               | -                | -                | -              | General Injector Calibration<br>Actuators<br>Immobiliser<br>APS                                                                                                                                                                                             |
| Agricultural | Telescopic Handlers | Tier 4                 | Engine Tools                        | JCB Engine Diagnostics                  | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests<br>Fuel System Diagnostics Test - Cranking<br>Fuel System Diagnostic Test - Engine Running<br>Fuel System Diagnostics<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Compoment Test |
| Agricultural | Telescopic Handlers | 525-60 Compact Loadall | Setup/Calibration                   |                                         | -        | -               | -                | -                | -              | Boom angle calibration                                                                                                                                                                                                                                      |
| Agricultural | Telescopic Handlers | 525-60 Compact Loadall | Kohler TCR Engine                   | JCB Diesel by Kohler Diagnostics        | ✓        | ✓               | ✓                | ✓                | ✓              | -                                                                                                                                                                                                                                                           |
| Agricultural | Telescopic Handlers | 525-60 Compact Loadall | Immobiliser                         | Immobiliser Diagnostics                 | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                                                                                                                                           |
| Agricultural | Telescopic Handlers | 525-60 Compact Loadall | Service/reset tool                  |                                         |          |                 |                  |                  |                | Service Hours Reset                                                                                                                                                                                                                                         |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                    | Type                   | System                           | System                         | Function |                 |                  |                  |                |                  |
|--------------|-------------------------|------------------------|----------------------------------|--------------------------------|----------|-----------------|------------------|------------------|----------------|------------------|
|              |                         |                        |                                  |                                | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function |
| Agricultural | Telescopic Handlers     | 525-60 Compact Loadall | Machine Diagnostics              | Loadall Fault Code Reader - T4 | -        | ✓               | ✓                | -                | -              | -                |
| Agricultural | Telescopic Handlers     | 525-60 Compact Loadall | Machine Diagnostics              | Loadall Diagnostics - T4       | -        | -               | -                | ✓                | -              | -                |
| Agricultural | Telescopic Handlers     | 525-60 Compact Loadall | Machine Diagnostics              | Loadall LLMI Diagnostics - T4  | -        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Telescopic Handlers     | 525-60 Compact Loadall | Machine Diagnostics              | Hydrostatic Transmission       | -        | -               | -                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Compact                | CWL/TM Cluster Diagnostics       |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Compact                | Immobiliser Diagnostics          |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Compact                | LiveLink Diagnostics             |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Compact                | T3 40kph Diagnostics             |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Compact                | T4 40Kph Controller Diagnostics  |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Large                  | LiveLink2 Diagnostics            |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Large                  | Machine Diagnostics              |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Large                  | T4F Diagnostics                  |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Large                  | Wheel Loader Diagnostics         |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Medium                 | LiveLink Diagnostics             |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Medium                 | LiveLink2 Diagnostics            |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Medium                 | MWLS Diagnostics                 |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Medium                 | T4F Diagnostics                  |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Telemasters            | CWL/TM Cluster Diagnostics       |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels | Telemasters            | Hydraulic Controller Diagnostics |                                | ✓        | ✓               | ✓                | ✓                | -              | -                |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                             | Type                            | System                               | System              | Function |                 |                  |                  |                |                  |
|--------------|----------------------------------|---------------------------------|--------------------------------------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------|
|              |                                  |                                 |                                      |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function |
| Agricultural | Wheeled Loading Shovels          | Telemasters                     | Hydraulics Diagnostics               |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels          | Telemasters                     | Immobiliser Diagnostics              |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels          | Telemasters                     | LiveLink Diagnostics                 |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels          | Telemasters                     | LiveLink Diagnostics                 |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels          | Telemasters                     | T3 40kph Diagnostics                 |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels          | Telemasters                     | T4 40Kph Controller Diagnostics      |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels          | Telemasters                     | Transmaster Transmission Diagnostics |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Agricultural | Wheeled Loading Shovels          | Telemasters                     | VSFC Diagnostics                     |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Articulated Dump Trucks          | Diagnostics                     |                                      |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Backhoe Loaders                  | Backhoe Loader 3DX Series India | LiveLink Diagnostics                 |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Backhoe Loaders                  | Backhoe Loader 3DX Series India | Machine ECU Diagnostic               |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Backhoe Loaders                  | Backhoe Loaders                 | Immobiliser Diagnostics              |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Backhoe Loaders                  | Backhoe Loaders                 | LiveLink Diagnostics                 |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Backhoe Loaders                  | Backhoe Loaders                 | Machine Diagnostics                  |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Backhoe Loaders                  | Compact Backhoe Loaders         | Immobiliser Diagnostics              |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Backhoe Loaders                  | Compact Backhoe Loaders         | LiveLink Diagnostics                 |                     | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Backhoe Loaders                  | Compact Backhoe Loaders         | 801-8065                             | Machine Diagnostics | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Compact Excavators (Mini / Midi) | 8000 Series Machines            | 801-8065                             | Diagnostics         | ✓        | ✓               | ✓                | ✓                | -              | -                |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                             | Type                 | System                  | System                  | Function |                 |                  |                  |                |                     |
|--------------|----------------------------------|----------------------|-------------------------|-------------------------|----------|-----------------|------------------|------------------|----------------|---------------------|
|              |                                  |                      |                         |                         | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function    |
| Construction | Compact Excavators (Mini / Midi) | 8000 Series Machines | 801-8065                | Immobiliser Diagnostics | ✓        | ✓               | ✓                | ✓                | -              | -                   |
| Construction | Compact Excavators (Mini / Midi) | 8000 Series Machines | 801-8065                | Vehicle setup           | -        | -               | -                | -                | -              | Vehicle setup       |
| Construction | Compact Excavators (Mini / Midi) | 8000 Series Machines | 8080-8085               | Machine Diagnostics     | ✓        | ✓               | ✓                | ✓                | -              | -                   |
| Construction | Compact Excavators (Mini / Midi) | 8000 Series Machines | 8080-8085               | Diagnostics             | ✓        | ✓               | ✓                | ✓                | -              | -                   |
| Construction | Compact Excavators (Mini / Midi) | 8000 Series Machines | 8080-8085               | Immobiliser Diagnostics | ✓        | ✓               | ✓                | ✓                | -              | -                   |
| Construction | Compact Excavators (Mini / Midi) | 8000 Series Machines | 8080-8085               | Vehicle setup           | -        | -               | -                | -                | -              | Vehicle setup       |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines         | I5C-1 - I9C-1-High Spec | Diagnostics             | ✓        | ✓               | ✓                | ✓                | -              | -                   |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines         | I5C-1 - I9C-1-High Spec | Immobiliser Diagnostics | ✓        | ✓               | ✓                | ✓                | -              | -                   |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines         | I5C-1 - I9C-1-High Spec | LiveLink Diagnostics    | ✓        | ✓               | ✓                | ✓                | -              | -                   |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines         | I5C-1 - I9C-1-High Spec | Vehicle setup           | -        | -               | -                | -                | -              | Vehicle setup       |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines         | I5C-1 - I9C-1-High Spec | Service hours reset     | -        | -               | -                | -                | -              | Service hours reset |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines         | I5C-1 - I9C-1-Low Spec  | Immobiliser Diagnostics | ✓        | ✓               | ✓                | ✓                | -              | -                   |



## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                             | Type         | System                 | System                            | Function |                 |                  |                  |                |                                          |
|--------------|----------------------------------|--------------|------------------------|-----------------------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------|
|              |                                  |              |                        |                                   | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                         |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines | I5C-1 - I9C-1-Low Spec | LiveLink Diagnostics              | ✓        | ✓               | ✓                | ✓                | -              | -                                        |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines | 48Z1-1 - 57C-1         | Service hours reset               | -        | -               | -                | -                | -              | Service hours reset                      |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines | 48Z1-1 - 57C-1         | Kohler TCR Engine                 | ✓        | ✓               | ✓                | ✓                | ✓              | -                                        |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines | 48Z1-1 - 57C-1         | JCB Diesel by Kohler Engine Setup | -        | -               | -                | -                | -              | General Injector Calibration Immobiliser |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines | 48Z1-1 - 57C-1         | LiveLink Diagnostics              | ✓        | ✓               | ✓                | -                | -              | -                                        |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines | 48Z1-1 - 57C-1         | Diagnostics                       | ✓        | ✓               | ✓                | ✓                | -              | -                                        |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines | 48Z1-1 - 57C-1         | Immobiliser Diagnostics           | -        | ✓               | ✓                | -                | -              | -                                        |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines | 65R-1 - 100C-1         | Service hours reset               | -        | -               | -                | -                | -              | Service hours reset                      |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines | 65R-1 - 100C-1         | Kohler TCR Engine                 | ✓        | ✓               | ✓                | ✓                | ✓              | -                                        |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines | 65R-1 - 100C-1         | JCB Diesel by Kohler Engine Setup | -        | -               | -                | -                | -              | General Injector Calibration Immobiliser |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines | 65R-1 - 100C-1         | LiveLink Diagnostics              | ✓        | ✓               | ✓                | -                | -              | -                                        |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines | 65R-1 - 100C-1         | Diagnostics                       | ✓        | ✓               | ✓                | ✓                | -              | -                                        |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                             | Type         | System                 | System                  | Function |                 |                  |                  |                |                                                                                                                                             |
|--------------|----------------------------------|--------------|------------------------|-------------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|              |                                  |              |                        |                         | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Construction | Compact Excavators (Mini / Midi) | NXG Machines | 65R-1 - 100C-1         | Immobiliser Diagnostics | -        | ✓               | ✓                | -                | -              | -                                                                                                                                           |
| Construction | Excavators                       | AMS Machines | Diagnostics            |                         | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                           |
| Construction | Excavators                       | AMS Machines | T2/T3 Diagnostics      |                         | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                           |
| Construction | Excavators                       | AMS Machines | T4i Diagnostics        |                         | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                           |
| Construction | Excavators                       | AMS Machines | JCB Engine Diagnostics | Tier II/ Tier III       | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests                                                                                                                      |
| Construction | Excavators                       | AMS Machines | JCB Engine Diagnostics | Tier 3 Equiv 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Construction | Excavators                       | AMS Machines | JCB Engine Diagnostics | Tier 3 Equiv 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Construction | Excavators                       | AMS Machines | JCB Engine Diagnostics | Tier II 6 cylinder      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Construction | Excavators                       | AMS Machines | JCB Engine Diagnostics | Tier III 6 cylinder     | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Construction | Excavators                       | AMS Machines | JCB Engine Diagnostics | Tier IVi 55kW           | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3.compared with the last version, the new added function is marked in red color.

| Series       | Mode       | Type         | System                 | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------------|------------|--------------|------------------------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|              |            |              |                        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Construction | Excavators | AMS Machines | JCB Engine Diagnostics | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override                                                                                                                |
| Construction | Excavators | AMS Machines | JCB Engine Diagnostics | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Construction | Excavators | AMS Machines | JCB Engine Diagnostics | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode       | Type                  | System                                | System   | Function |                 |                  |                  |                |                                                                  |
|--------------|------------|-----------------------|---------------------------------------|----------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------|
|              |            |                       |                                       |          | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                 |
| Construction | Excavators | AMS Machines          | JCB Engine Diagnostics                | 430 55kW | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                    |
| Construction | Excavators | DECU Machines         | Vehicle Diagnostics                   |          | ✓        | ✓               | ✓                | ✓                | -              | -                                                                |
| Construction | Excavators | DECU Machines         | Immobiliser migration                 |          | -        | -               | -                | -                | -              | General<br>Read Injector Codes<br>Write Injector Codes           |
| Construction | Excavators | DECU Machines         | ISUZU ecm setup tool                  |          | -        | -               | -                | -                | -              | QR Codes<br>Rewrite Engine Serial Number<br>Rewrite Q Tone       |
| Construction | Excavators | DECU Machines         | JCB 4 Cylinder Dieaelmax Engine setup |          | -        | -               | -                | -                | -              | General<br>Read Injector Codes<br>Write Injector Codes           |
| Construction | Excavators | DECU Machines         | JCB 4 Cylinder Ecomax engine setup    |          | -        | -               | -                | -                | -              | General<br>Injtor Calibration<br>Actuators<br>Immobiliser<br>APS |
| Construction | Excavators | DECU Machines         | JCB 6 Cylinder engine setup           |          | -        | -               | -                | -                | -              | General<br>Injtor Calibration<br>Actuators<br>Immobiliser        |
| Construction | Excavators | Excavators (Hydradig) | Immobiliser Diagnostics               |          | ✓        | ✓               | ✓                | ✓                | -              | -                                                                |
| Construction | Excavators | Excavators (Hydradig) | LiveLink Diagnostics                  |          | ✓        | ✓               | ✓                | ✓                | -              | -                                                                |
| Construction | Excavators | Excavators (Hydradig) | Vehicle Diagnostic                    |          | ✓        | ✓               | ✓                | ✓                | -              | -                                                                |
| Construction | Excavators | Excavators (Hydradig) | Service hours reset                   |          |          |                 |                  |                  |                | Service hours reset                                              |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode       | Type                  | System                  | System              | Function |                 |                  |                  |                |                                                                                                                                             |
|--------------|------------|-----------------------|-------------------------|---------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|              |            |                       |                         |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Construction | Excavators | Excavators (Hydradig) | JCB Ecomax engine setup |                     | -        | -               | -                | -                | -              | General<br>Injector Calibration<br>Actuators<br>Immobiliser<br>APS                                                                          |
| Construction | Excavators | Excavators (Hydradig) |                         | Tier II/ Tier III   | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests                                                                                                                      |
| Construction | Excavators | Excavators (Hydradig) |                         | Tier 3 Equiv 55kW   | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Construction | Excavators | Excavators (Hydradig) |                         | Tier 3 Equiv 56+kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Construction | Excavators | Excavators (Hydradig) |                         | Tier II 6 cylinder  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Construction | Excavators | Excavators (Hydradig) |                         | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Construction | Excavators | Excavators (Hydradig) |                         | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode       | Type                  | System               | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------------|------------|-----------------------|----------------------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|              |            |                       |                      |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Construction | Excavators | Excavators (Hydradig) |                      | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override                                                                                                                |
| Construction | Excavators | Excavators (Hydradig) |                      | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Compoment Test |
| Construction | Excavators | Excavators (Hydradig) |                      | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Compoment Test |
| Construction | Excavators | Excavators (Hydradig) |                      | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                                                                                                                                              |
| Construction | Excavators | X Series              | LiveLink Diagnostics |                     | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                                                                                                                                          |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode       | Type     | System             | System              | Function |                 |                  |                  |                |                                                                                                                                             |
|--------------|------------|----------|--------------------|---------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|              |            |          |                    |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Construction | Excavators | X Series | Vehicle Diagnostic |                     | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                           |
| Construction | Excavators | X Series |                    | Tier II/ Tier III   | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests                                                                                                                      |
| Construction | Excavators | X Series |                    | Tier 3 Equiv 55kW   | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Construction | Excavators | X Series |                    | Tier 3 Equiv 56+kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Construction | Excavators | X Series |                    | Tier II 6 cylinder  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Construction | Excavators | X Series |                    | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Construction | Excavators | X Series |                    | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Construction | Excavators | X Series |                    | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode       | Type     | System                  | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------------|------------|----------|-------------------------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|              |            |          |                         |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Construction | Excavators | X Series |                         | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Construction | Excavators | X Series |                         | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Construction | Excavators | X Series |                         | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                                                                                                                                              |
| Construction | Excavators | X Series | JCB Ecomax engine setup |                     | -        | -               | -                | -                | -              | General<br>Injector Calibration<br>Actuators<br>Immobiliser<br>APS                                                                                                                                                                                         |



## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                    | Type                    | System                               | System | Function |                 |                  |                  |                |                      |
|--------------|-------------------------|-------------------------|--------------------------------------|--------|----------|-----------------|------------------|------------------|----------------|----------------------|
|              |                         |                         |                                      |        | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function     |
| Construction | Excavators              | India DECU Machines     | Throttle calibration tool            |        | -        | -               | -                | -                | -              | Write Throttle Value |
| Construction | Excavators              | India DECU Machines     | Camera setup                         |        | -        | -               | -                | -                | -              | -                    |
| Construction | Rough Terrain Forklifts | Tier 4 RTFL             | Diagnostics                          |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |
| Construction | Rough Terrain Forklifts | Tier 4 RTFL             | Immobiliser Diagnostics              |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |
| Construction | Rough Terrain Forklifts | Tier 4 RTFL             | LiveLink Diagnostics                 |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |
| Construction | Site Dumpers            | LiveLink Diagnostics    |                                      |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |
| Construction | Site Dumpers            | Machine Diagnostics     |                                      |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |
| Construction | Telemasters             | TM220                   | CWL/TM Cluster Diagnostics           |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |
| Construction | Telemasters             | TM220                   | Hydraulic Controller Diagnostics     |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |
| Construction | Telemasters             | TM220                   | Immobiliser Diagnostics              |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |
| Construction | Telemasters             | TM220                   | LiveLink Diagnostics                 |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |
| Construction | Telemasters             | TM220                   | T3 40kph Diagnostics                 |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |
| Construction | Telemasters             | TM220                   | T4 40Kph Controller Diagnostics      |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |
| Construction | Telemasters             | TM320 T4i               | Hydraulics Diagnostics               |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |
| Construction | Telemasters             | TM320 T4i               | Transmaster Transmission Diagnostics |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |
| Construction | Telemasters             | TM320 Tier 4 Final Mk 1 | Hydraulics Diagnostics               |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |
| Construction | Telemasters             | TM320 Tier 4 Final Mk 1 | Transmaster Transmission Diagnostics |        | ✓        | ✓               | ✓                | ✓                | -              | -                    |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                | Type                   | System                               | System | Function |                 |                  |                  |                |                                    |
|--------------|---------------------|------------------------|--------------------------------------|--------|----------|-----------------|------------------|------------------|----------------|------------------------------------|
|              |                     |                        |                                      |        | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                   |
| Construction | Telemasters         | TM320 Tier 4 Final Mk1 | VSFC Diagnostics                     |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telemasters         | TM320 Tier 4 Final Mk2 | Hydraulics Diagnostics               |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telemasters         | TM320 Tier 4 Final Mk2 | Immobiliser Diagnostics              |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telemasters         | TM320 Tier 4 Final Mk2 | LiveLink Diagnostics                 |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telemasters         | TM320 Tier 4 Final Mk2 | Transmaster Transmission Diagnostics |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telemasters         | TM320 Tier 4 Final Mk2 | VSFC Diagnostics                     |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telemasters         | TM420 Tier 4 Final     | Hydraulics Diagnostics               |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telemasters         | TM420 Tier 4 Final     | Immobiliser Diagnostics              |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telemasters         | TM420 Tier 4 Final     | LiveLink Diagnostics                 |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telemasters         | TM420 Tier 4 Final     | Transmaster Transmission Diagnostics |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telemasters         | TM420 Tier 4 Final     | VSFC Diagnostics                     |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telescopic Handlers | 2007+                  | Loadall 527 Transmission Diagnostics |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telescopic Handlers | 2007+                  | Loadall Diagnostics                  |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telescopic Handlers | 2007+                  | Loadall LLMI Diagnostics             |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telescopic Handlers | 2007+                  | RAS Diagnostics                      |        | ✓        | ✓               | ✓                | ✓                | -              | -                                  |
| Construction | Telescopic Handlers | 2007+                  | Service hours reset                  |        |          |                 |                  |                  |                | Service Hours<br>Service Hours T4i |
| Construction | Telescopic Handlers | 2007+                  | 526-SLC Setup                        |        |          |                 |                  |                  |                | Flowshare Current Settings         |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                | Type   | System                                             | System                         | Function |                 |                  |                  |                |                              |
|--------------|---------------------|--------|----------------------------------------------------|--------------------------------|----------|-----------------|------------------|------------------|----------------|------------------------------|
|              |                     |        |                                                    |                                | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function             |
| Construction | Telescopic Handlers | 2007+  | Boom angle calibration                             |                                |          |                 |                  |                  |                | Angle Sensor Calibration     |
| Construction | Telescopic Handlers | 2007+  | Man paltform recovery reset                        |                                |          |                 |                  |                  |                | Recovery Mode Reset          |
| Construction | Telescopic Handlers | 2007+  | JCB Dieselmax engine setup                         |                                |          |                 |                  |                  |                | General Injector Calibration |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction 3 Lever Diagnostics | Loadall Fault Code Reader - T4 | -        | ✓               | -                | -                | -              | -                            |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction 3 Lever Diagnostics | Loadall Diagnostics - T4       | -        | -               | -                | ✓                | -              | -                            |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction 3 Lever Diagnostics | Powershift Diagnostics - T4    | -        | -               | -                | ✓                | -              | -                            |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction 3 Lever Diagnostics | Loadall LLMI Diagnostics - T4  | ✓        | ✓               | ✓                | ✓                | -              | -                            |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction EH Diagnostics      | Loadall Fault Code Reader - T4 | -        | ✓               | -                | -                | -              | -                            |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction EH Diagnostics      | Loadall Diagnostics - T4       | -        | -               | -                | ✓                | -              | -                            |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction EH Diagnostics      | Auxilliary ECU                 | -        | -               | -                | ✓                | -              | -                            |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction EH Diagnostics      | Expansion ECU                  | -        | -               | -                | ✓                | -              | -                            |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction EH Diagnostics      | Radio System                   | -        | -               | -                | ✓                | -              | -                            |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction EH Diagnostics      | Powershift Diagnostics - T4    | -        | -               | -                | ✓                | -              | -                            |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                | Type   | System                                            | System                                  | Function |                 |                  |                  |                |                                                                 |
|--------------|---------------------|--------|---------------------------------------------------|-----------------------------------------|----------|-----------------|------------------|------------------|----------------|-----------------------------------------------------------------|
|              |                     |        |                                                   |                                         | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction EH Diagnostics     | Loadall LLMI Diagnostics - T4           | ✓        | ✓               | ✓                | ✓                | -              | -                                                               |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction 527-58 Diagnostics | Loadall Fault Code Reader - T4          | -        | ✓               | -                | -                | -              | -                                                               |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction 527-58 Diagnostics | Loadall Diagnostics - T4                | -        | -               | -                | ✓                | -              | -                                                               |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction 527-58 Diagnostics | Hydrostatic Transmission                | -        | -               | -                | ✓                | -              | -                                                               |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/Construction 527-58 Diagnostics | Loadall LLMI Diagnostics - T4           | ✓        | ✓               | ✓                | ✓                | -              | -                                                               |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/North America(P90) Diagnostics  | Loadall Fault Code Reader - T4          | -        | ✓               | -                | -                | -              | -                                                               |
| Construction | Telescopic Handlers | Tier 4 | Diagnostics Tools/North America(P90) Diagnostics  | RAS Diagnostics                         | -        | -               | -                | ✓                | -              | -                                                               |
| Construction | Telescopic Handlers | Tier 4 | Engine Tools - Ecomax                             | JCB Ecomax Engine setup                 | -        | -               | -                | -                | -              | General Injector Calibration<br>Actuators<br>Immobiliser<br>APS |
| Construction | Telescopic Handlers | Tier 4 | Engine Tools - Ecomax                             | JCB Ecomax Engine Setup for Loadall JVT | -        | -               | -                | -                | -              | General Injector Calibration<br>Actuators<br>Immobiliser<br>APS |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                | Type   | System                       | System                     | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                             |
|--------------|---------------------|--------|------------------------------|----------------------------|----------|-----------------|------------------|------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|              |                     |        |                              |                            | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                            |
| Construction | Telescopic Handlers | Tier 4 | Engine Tools - Ecomax        | JCB Engine Diagnostics     | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests<br>Fuel System Diagnostics Test - Cranking<br>Fuel System Diagnostic Test - Engine Running<br>Fuel System Diagnostics<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Compoment Test |
| Construction | Telescopic Handlers | Tier 4 | Engine Tools - 430 Dieselmax | 430 Dieselmax Engine Setup | -        | -               | -                | -                | -              | General<br>Injector Calibration<br>Immobiliser                                                                                                                                                                                                              |
| Construction | Telescopic Handlers | Tier 4 | Engine Tools - 430 Dieselmax | JCB Engine Diagnostics     | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests<br>Fuel System Diagnostics Test - Cranking<br>Fuel System Diagnostic Test - Engine Running<br>Fuel System Diagnostics<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Compoment Test |
| Construction | Telescopic Handlers | Tier 4 | Setup / Calibration Tools    |                            | -        | -               | -                | -                | -              | Boom Angle Calibration<br>Heater Fan Setup<br>EH Valve Tuning                                                                                                                                                                                               |
| Construction | Telescopic Handlers | Tier 4 | Service / Reset Tools        |                            | -        | -               | -                | -                | -              | Service Hours Reset<br>Man Platform Recovery Reset                                                                                                                                                                                                          |
| Construction | Telescopic Handlers | Tier 4 | Immobiliser Tools            | Immobiliser Diagnostics    | -        | ✓               | ✓                | -                | -              | -                                                                                                                                                                                                                                                           |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                    | Type                   | System                     | System                           | Function |                 |                  |                  |                |                        |
|--------------|-------------------------|------------------------|----------------------------|----------------------------------|----------|-----------------|------------------|------------------|----------------|------------------------|
|              |                         |                        |                            |                                  | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function       |
| Construction | Telescopic Handlers     | 525-60 Compact Loadall | Setup/Calibration          |                                  | -        | -               | -                | -                | -              | Boom Angle Calibration |
| Construction | Telescopic Handlers     | 525-60 Compact Loadall | Service / Reset Tools      |                                  | -        | -               | -                | -                | -              | Service Hours Reset    |
| Construction | Telescopic Handlers     | 525-60 Compact Loadall | Immobiliser Tools          | Immobiliser Diagnostics          | -        | ✓               | ✓                | -                | -              | -                      |
| Construction | Telescopic Handlers     | 525-60 Compact Loadall | Kohler TCR Engine          | JCB Diesel by Kohler Diagnostics | ✓        | ✓               | ✓                | ✓                | ✓              | -                      |
| Construction | Telescopic Handlers     | 525-60 Compact Loadall | Machine Diagnostics        | Loadall Fault Code Reader - T4   | -        | ✓               | ✓                | -                | -              | -                      |
| Construction | Telescopic Handlers     | 525-60 Compact Loadall | Machine Diagnostics        | Loadall Diagnostics - T4         | -        | -               | -                | ✓                | -              | -                      |
| Construction | Telescopic Handlers     | 525-60 Compact Loadall | Machine Diagnostics        | Hydrostatic Transmission         | -        | -               | -                | ✓                | -              | -                      |
| Construction | Telescopic Handlers     | 525-60 Compact Loadall | Machine Diagnostics        | Loadall LLMI Diagnostics - T4    | -        | ✓               | ✓                | ✓                | -              | -                      |
| Construction | Teletruks               | LPG Teletruk           | Diagnostics                |                                  | ✓        | ✓               | ✓                | ✓                | -              | -                      |
| Construction | Teletruks               | LPG Teletruk           | LiveLink Diagnostics       |                                  | ✓        | ✓               | ✓                | ✓                | -              | -                      |
| Construction | Teletruks               | Tier 4 Teletruk        | Diagnostics                |                                  | ✓        | ✓               | ✓                | ✓                | -              | -                      |
| Construction | Teletruks               | Tier 4 Teletruk        | LiveLink Diagnostics       |                                  | ✓        | ✓               | ✓                | ✓                | -              | -                      |
| Construction | Vibratory Compactors    | Interim Tier 4         | Diagnostics                |                                  | ✓        | ✓               | ✓                | ✓                | -              | -                      |
| Construction | Vibratory Compactors    | Interim Tier 4         | Immobiliser Diagnostics    |                                  | ✓        | ✓               | ✓                | ✓                | -              | -                      |
| Construction | Vibratory Compactors    | Interim Tier 4         | LiveLink Diagnostics       |                                  | ✓        | ✓               | ✓                | ✓                | -              | -                      |
| Construction | Vibratory Compactors    | VM116                  | LiveLink Diagnostics       |                                  | ✓        | ✓               | ✓                | ✓                | -              | -                      |
| Construction | Wheeled Loading Shovels | Compact                | CWL/TM Cluster Diagnostics |                                  | ✓        | ✓               | ✓                | ✓                | -              | -                      |
| Construction | Wheeled Loading Shovels | Compact                | Immobiliser Diagnostics    |                                  | ✓        | ✓               | ✓                | ✓                | -              | -                      |
| Construction | Wheeled Loading Shovels | Compact                | LiveLink Diagnostics       |                                  | ✓        | ✓               | ✓                | ✓                | -              | -                      |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                    | Type        | System                           | System | Function |                 |                  |                  |                |                  |
|--------------|-------------------------|-------------|----------------------------------|--------|----------|-----------------|------------------|------------------|----------------|------------------|
|              |                         |             |                                  |        | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function |
| Construction | Wheeled Loading Shovels | Compact     | T3 40kph Diagnostics             |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Compact     | T4 40Kph Controller Diagnostics  |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Global WLS  | Wheel Loader Diagnostics         |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Large       | LiveLink2 Diagnostics            |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Large       | Machine Diagnostics              |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Large       | T4F Diagnostics                  |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Large       | Wheel Loader Diagnostics         |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Medium      | LiveLink Diagnostics             |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Medium      | LiveLink2 Diagnostics            |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Medium      | MWLS Diagnostics                 |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Medium      | T4F Diagnostics                  |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Telemasters |                                  |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Telemasters | CWL/TM Cluster Diagnostics       |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Telemasters | Hydraulic Controller Diagnostics |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Telemasters | Hydraulics Diagnostics           |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Telemasters | Immobiliser Diagnostics          |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Telemasters | LiveLink Diagnostics             |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Telemasters | LiveLink Diagnostics             |        | ✓        | ✓               | ✓                | ✓                | -              | -                |
| Construction | Wheeled Loading Shovels | Telemasters | T4 40Kph Controller Diagnostics  |        | ✓        | ✓               | ✓                | ✓                | -              | -                |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series       | Mode                    | Type        | System                               | System | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------------|-------------------------|-------------|--------------------------------------|--------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|              |                         |             |                                      |        | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Construction | Wheeled Loading Shovels | Telemasters | Transmaster Transmission Diagnostics |        | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                                                                                                                                          |
| Construction | Wheeled Loading Shovels | Telemasters | VSFC Diagnostics                     |        | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                                                                                                                                          |
| Waste        | Telescopic Handlers     | Tier 3      | JCB DieselmX Engine setup            |        | -        | -               | -                | -                | -              | General Injector Calibration                                                                                                                                                                                                                               |
| Waste        | Telescopic Handlers     | Tier 3      | Service Hours Reset                  |        | -        | -               | -                | -                | -              | Service Hours<br>Service Hours T4i                                                                                                                                                                                                                         |
| Waste        | Telescopic Handlers     | Tier 3      | 526-SLC Setup                        |        | -        | -               | -                | -                | -              | Flowshare Current Settings                                                                                                                                                                                                                                 |
| Waste        | Telescopic Handlers     | Tier 3      | Boom angle calibration               |        | -        | -               | -                | -                | -              | Angle Sensor Calibration                                                                                                                                                                                                                                   |
| Waste        | Telescopic Handlers     | Tier 3      | JCB Engine Diagnostics               |        | ✓        | ✓               | ✓                | ✓                | ✓              | DieselmX Engine Tests<br>Fuel System Diagnostics Test - Cranking<br>Fuel System Diagnostic Test - Engine Running<br>Fuel System Diagnostics<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Waste        | Telescopic Handlers     | Tier 3      | Loadall Diagnostics                  |        | -        | -               | -                | ✓                | -              | -                                                                                                                                                                                                                                                          |
| Waste        | Telescopic Handlers     | Tier 3      | Loadall LLMI Diagnostics             |        | -        | ✓               | ✓                | ✓                | -              | -                                                                                                                                                                                                                                                          |
| Waste        | Telescopic Handlers     | Tier 3      | Loadall 527 Transmission Diagnostics |        | -        | -               | -                | ✓                | -              | -                                                                                                                                                                                                                                                          |
| Waste        | Telescopic Handlers     | Tier 3      | Immobiliser Diagnostics              |        | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                                                                                                                                          |



## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode                | Type   | System                         | System | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                             |
|--------|---------------------|--------|--------------------------------|--------|----------|-----------------|------------------|------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |                     |        |                                |        | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                            |
| Waste  | Telescopic Handlers | Tier 4 | Machine Buzzer Mute            |        | -        | -               | -                | -                | -              | Machine Buzzer Mute                                                                                                                                                                                                                                         |
| Waste  | Telescopic Handlers | Tier 4 | JCB Ecomax engine setup        |        | -        | -               | -                | -                | -              | General Injector Calibration<br>Actuators<br>Immobiliser<br>APS                                                                                                                                                                                             |
| Waste  | Telescopic Handlers | Tier 4 | Service hours reset            |        | -        | -               | -                | -                | -              | Service hours reset                                                                                                                                                                                                                                         |
| Waste  | Telescopic Handlers | Tier 4 | Boom angle calibration         |        | -        | -               | -                | -                | -              | Boom angle calibration                                                                                                                                                                                                                                      |
| Waste  | Telescopic Handlers | Tier 4 | Heater fan setup               |        | -        | -               | -                | -                | -              | Heater fan setup                                                                                                                                                                                                                                            |
| Waste  | Telescopic Handlers | Tier 4 | EH Valve tuning                |        | -        | -               | -                | -                | -              | EH Valve tuning                                                                                                                                                                                                                                             |
| Waste  | Telescopic Handlers | Tier 4 | Loadall Fault Code Reader - T4 |        | -        | ✓               | ✓                | -                | -              | -                                                                                                                                                                                                                                                           |
| Waste  | Telescopic Handlers | Tier 4 | JCB Engine Diagnostics         |        | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests<br>Fuel System Diagnostics Test - Cranking<br>Fuel System Diagnostic Test - Engine Running<br>Fuel System Diagnostics<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Waste  | Telescopic Handlers | Tier 4 | Loadall Diagnostics - T4       |        | -        | -               | -                | ✓                | -              | -                                                                                                                                                                                                                                                           |
| Waste  | Telescopic Handlers | Tier 4 | Powershift Diagnostics - T4    |        | -        | -               | -                | ✓                | -              | -                                                                                                                                                                                                                                                           |
| Waste  | Telescopic Handlers | Tier 4 | Loadall LLMI Diagnostics - T4  |        | -        | ✓               | ✓                | ✓                | -              | -                                                                                                                                                                                                                                                           |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3.compared with the last version, the new added function is marked in red color.

| Series | Mode                    | Type                 | System                                | System             | Function |                 |                  |                  |                |                                                                                                                                             |
|--------|-------------------------|----------------------|---------------------------------------|--------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|        |                         |                      |                                       |                    | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Waste  | Telescopic Handlers     | Tier 4               | Loadall Pump Control Diagnostics - T4 |                    | -        | -               | -                | ✓                | -              | -                                                                                                                                           |
| Waste  | Telescopic Handlers     | Tier 4               | Immobiliser Diagnostics               |                    | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                           |
| Waste  | Telescopic Handlers     | Tier 4               | Transmaster Transmission Diagnostics  |                    | -        | -               | -                | ✓                | -              | -                                                                                                                                           |
| Waste  | Wheeled Loading Shovels | 427/437/435S T4F     | LiveLink2 Diagnostics                 |                    | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                           |
| Waste  | Wheeled Loading Shovels | 427/437/435S T4F     | T4F Diagnostics                       |                    | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                           |
| Waste  | Wheeled Loading Shovels | 457 T4F              | LiveLink2 Diagnostics                 |                    | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                           |
| Waste  | Wheeled Loading Shovels | 457 T4F              | T4F Diagnostics                       |                    | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                           |
| Engine | Engine                  | JCB Dieselmax Engine |                                       |                    | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                           |
| Engine | Engine                  | JCB Dieselmax Engine |                                       | Tier II/ Tier III  | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests                                                                                                                      |
| Engine | Engine                  | JCB Dieselmax Engine |                                       | Tier 3 Equiv 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine                  | JCB Dieselmax Engine |                                       | Tier 3 Equiv 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine                  | JCB Dieselmax Engine |                                       | Tier II 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                 | System | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------|--------|----------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                      |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Engine | Engine | JCB Dieselmax Engine |        | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override                                                                                                                |
| Engine | Engine | JCB Dieselmax Engine |        | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |
| Engine | Engine | JCB Dieselmax Engine |        | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override                                                                                                                |
| Engine | Engine | JCB Dieselmax Engine |        | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3.compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                       | System | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------|--------|----------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                            |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Engine | Engine | JCB Dieselmax Engine       |        | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Dieselmax Engine       |        | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                                                                                                                                              |
| Engine | Engine | JCB Dieselmax Engine (IPU) |        | Tier II/ Tier III   | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests                                                                                                                                                                                                                                     |
| Engine | Engine | JCB Dieselmax Engine (IPU) |        | Tier 3 Equiv 55kW   | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |
| Engine | Engine | JCB Dieselmax Engine (IPU) |        | Tier 3 Equiv 56+kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |
| Engine | Engine | JCB Dieselmax Engine (IPU) |        | Tier II 6 cylinder  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override                                                                                                                |
| Engine | Engine | JCB Dieselmax Engine (IPU) |        | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override                                                                                                                |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                       | System | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------|--------|----------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                            |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Engine | Engine | JCB Dieselmax Engine (IPU) |        | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |
| Engine | Engine | JCB Dieselmax Engine (IPU) |        | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override                                                                                                                |
| Engine | Engine | JCB Dieselmax Engine (IPU) |        | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Dieselmax Engine (IPU) |        | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                            | System | System              | Function |                 |                  |                  |                |                                                                                                                                             |
|--------|--------|---------------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                                 |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Engine | Engine | JCB Dieselmax Engine (TPU)      |        | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                               |
| Engine | Engine | JCB Dieselmax Engine (OEM Base) |        | Tier II/ Tier III   | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests                                                                                                                      |
| Engine | Engine | JCB Dieselmax Engine (OEM Base) |        | Tier 3 Equiv 55kW   | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine | JCB Dieselmax Engine (OEM Base) |        | Tier 3 Equiv 56+kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine | JCB Dieselmax Engine (OEM Base) |        | Tier II 6 cylinder  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Dieselmax Engine (OEM Base) |        | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Dieselmax Engine (OEM Base) |        | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine | JCB Dieselmax Engine (OEM Base) |        | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3.compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                            | System | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------|--------|---------------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                                 |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Engine | Engine | JCB Dieselmax Engine (OEM Base) |        | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Dieselmax Engine (OEM Base) |        | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Dieselmax Engine (OEM Base) |        | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                                                                                                                                              |
| Engine | Engine | JCB Dieselmax Engine (G-Drive)  |        | Tier II/ Tier III   | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests                                                                                                                                                                                                                                     |
| Engine | Engine | JCB Dieselmax Engine (G-Drive)  |        | Tier 3 Equiv 55kW   | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |
| Engine | Engine | JCB Dieselmax Engine (G-Drive)  |        | Tier 3 Equiv 56+kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                           | System | System              | Function |                 |                  |                  |                |                                                                                                                                             |
|--------|--------|--------------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                                |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Engine | Engine | JCB Dieselmax Engine (G-Drive) |        | Tier II 6 cylinder  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Dieselmax Engine (G-Drive) |        | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Dieselmax Engine (G-Drive) |        | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine | JCB Dieselmax Engine (G-Drive) |        | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |



## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                           | System | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------|--------|--------------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                                |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Engine | Engine | JCB Dieselmax Engine (G-Drive) |        | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Dieselmax Engine (G-Drive) |        | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Dieselmax Engine (G-Drive) |        | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                                                                                                                                              |
| Engine | Engine | JCB Ecomax Engine              |        | Tier II/ Tier III   | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests                                                                                                                                                                                                                                     |
| Engine | Engine | JCB Ecomax Engine              |        | Tier 3 Equiv 55kW   | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |
| Engine | Engine | JCB Ecomax Engine              |        | Tier 3 Equiv 56+kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type              | System | System              | Function |                 |                  |                  |                |                                                                                                                                             |
|--------|--------|-------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                   |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Engine | Engine | JCB Ecomax Engine |        | Tier II 6 cylinder  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Ecomax Engine |        | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Ecomax Engine |        | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine | JCB Ecomax Engine |        | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                    | System | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------|--------|-------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                         |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Engine | Engine | JCB Ecomax Engine       |        | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Ecomax Engine       |        | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Ecomax Engine (IPU) |        | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                                                                                                                                              |
| Engine | Engine | JCB Ecomax Engine (IPU) |        | Tier II/ Tier III   | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmox Engine Tests                                                                                                                                                                                                                                     |
| Engine | Engine | JCB Ecomax Engine (IPU) |        | Tier 3 Equiv 55kW   | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |
| Engine | Engine | JCB Ecomax Engine (IPU) |        | Tier 3 Equiv 56+kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                    | System | System              | Function |                 |                  |                  |                |                                                                                                                                             |
|--------|--------|-------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                         |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Engine | Engine | JCB Ecomax Engine (IPU) |        | Tier II 6 cylinder  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Ecomax Engine (IPU) |        | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Ecomax Engine (IPU) |        | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine | JCB Ecomax Engine (IPU) |        | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3.compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                         | System | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------|--------|------------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                              |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Engine | Engine | JCB Ecomax Engine (IPU)      |        | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Compoment Test |
| Engine | Engine | JCB Ecomax Engine (IPU)      |        | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Compoment Test |
| Engine | Engine | JCB Ecomax Engine (IPU)      |        | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                                                                                                                                              |
| Engine | Engine | JCB Ecomax Engine (OEM Base) |        | Tier II/ Tier III   | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmox Engine Tests                                                                                                                                                                                                                                     |
| Engine | Engine | JCB Ecomax Engine (OEM Base) |        | Tier 3 Equiv 55kW   | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |
| Engine | Engine | JCB Ecomax Engine (OEM Base) |        | Tier 3 Equiv 56+kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                         | System | System              | Function |                 |                  |                  |                |                                                                                                                                             |
|--------|--------|------------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                              |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Engine | Engine | JCB Ecomax Engine (OEM Base) |        | Tier II 6 cylinder  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Ecomax Engine (OEM Base) |        | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Ecomax Engine (OEM Base) |        | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine | JCB Ecomax Engine (OEM Base) |        | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                         | System | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------|--------|------------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                              |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Engine | Engine | JCB Ecomax Engine (OEM Base) |        | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Ecomax Engine (OEM Base) |        | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Ecomax Engine (OEM Base) |        | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                                                                                                                                              |
| Engine | Engine | JCB Ecomax Engine (G Drive)  |        | Tier II/ Tier III   | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests                                                                                                                                                                                                                                     |
| Engine | Engine | JCB Ecomax Engine (G Drive)  |        | Tier 3 Equiv 55kW   | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |
| Engine | Engine | JCB Ecomax Engine (G Drive)  |        | Tier 3 Equiv 56+kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                        | System | System              | Function |                 |                  |                  |                |                                                                                                                                             |
|--------|--------|-----------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                             |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Engine | Engine | JCB Ecomax Engine (G Drive) |        | Tier II 6 cylinder  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Ecomax Engine (G Drive) |        | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Ecomax Engine (G Drive) |        | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine | JCB Ecomax Engine (G Drive) |        | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |



## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3.compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                        | System | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------|--------|-----------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                             |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Engine | Engine | JCB Ecomax Engine (G Drive) |        | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Compoment Test |
| Engine | Engine | JCB Ecomax Engine (G Drive) |        | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Compoment Test |
| Engine | Engine | JCB Ecomax Engine (G Drive) |        | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                                                                                                                                              |
| Engine | Engine | JCB Dieselmax 672 Engine    |        | Tier II/ Tier III   | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests                                                                                                                                                                                                                                     |
| Engine | Engine | JCB Dieselmax 672 Engine    |        | Tier 3 Equiv 55kW   | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |
| Engine | Engine | JCB Dieselmax 672 Engine    |        | Tier 3 Equiv 56+kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                     | System | System              | Function |                 |                  |                  |                |                                                                                                                                             |
|--------|--------|--------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                          |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Engine | Engine | JCB Dieselmax 672 Engine |        | Tier II 6 cylinder  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Dieselmax 672 Engine |        | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Dieselmax 672 Engine |        | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine | JCB Dieselmax 672 Engine |        | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                           | System | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------|--------|--------------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                                |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Engine | Engine | JCB Dieselmax 672 Engine       |        | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Dieselmax 672 Engine       |        | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Dieselmax 672 Engine       |        | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                                                                                                                                              |
| Engine | Engine | JCB Dieselmax 672 Engine (IPU) |        | Tier II/ Tier III   | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests                                                                                                                                                                                                                                     |
| Engine | Engine | JCB Dieselmax 672 Engine (IPU) |        | Tier 3 Equiv 55kW   | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |
| Engine | Engine | JCB Dieselmax 672 Engine (IPU) |        | Tier 3 Equiv 56+kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                           | System | System              | Function |                 |                  |                  |                |                                                                                                                                             |
|--------|--------|--------------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                                |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Engine | Engine | JCB Dieselmax 672 Engine (IPU) |        | Tier II 6 cylinder  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Dieselmax 672 Engine (IPU) |        | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Dieselmax 672 Engine (IPU) |        | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine | JCB Dieselmax 672 Engine (IPU) |        | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                                | System | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------|--------|-------------------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                                     |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Engine | Engine | JCB Dieselmax 672 Engine (IPU)      |        | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Dieselmax 672 Engine (IPU)      |        | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Dieselmax 672 Engine (IPU)      |        | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                                                                                                                                              |
| Engine | Engine | JCB Dieselmax 672 Engine (OEM Base) |        | Tier II/ Tier III   | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests                                                                                                                                                                                                                                     |
| Engine | Engine | JCB Dieselmax 672 Engine (OEM Base) |        | Tier 3 Equiv 55kW   | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |
| Engine | Engine | JCB Dieselmax 672 Engine (OEM Base) |        | Tier 3 Equiv 56+kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                                | System | System              | Function |                 |                  |                  |                |                                                                                                                                             |
|--------|--------|-------------------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                                     |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Engine | Engine | JCB Dieselmax 672 Engine (OEM Base) |        | Tier II 6 cylinder  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Dieselmax 672 Engine (OEM Base) |        | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Dieselmax 672 Engine (OEM Base) |        | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine | JCB Dieselmax 672 Engine (OEM Base) |        | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                                | System | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------|--------|-------------------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                                     |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Engine | Engine | JCB Dieselmax 672 Engine (OEM Base) |        | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Dieselmax 672 Engine (OEM Base) |        | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | JCB Dieselmax 672 Engine (OEM Base) |        | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                                                                                                                                              |
| Engine | Engine | JCB Dieselmax 672 Engine (G Drive)  |        | Tier II/ Tier III   | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests                                                                                                                                                                                                                                     |
| Engine | Engine | JCB Dieselmax 672 Engine (G Drive)  |        | Tier 3 Equiv 55kW   | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |
| Engine | Engine | JCB Dieselmax 672 Engine (G Drive)  |        | Tier 3 Equiv 56+kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                               | System | System              | Function |                 |                  |                  |                |                                                                                                                                             |
|--------|--------|------------------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                                    |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Engine | Engine | JCB Dieselmax 672 Engine (G Drive) |        | Tier II 6 cylinder  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Dieselmax 672 Engine (G Drive) |        | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | JCB Dieselmax 672 Engine (G Drive) |        | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine | JCB Dieselmax 672 Engine (G Drive) |        | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |



## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                               | System | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------|--------|------------------------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                                    |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Engine | Engine | JCB Dieselmax 672 Engine (G Drive) |        | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Compoment Test |
| Engine | Engine | JCB Dieselmax 672 Engine (G Drive) |        | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Compoment Test |
| Engine | Engine | JCB Dieselmax 672 Engine (G Drive) |        | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                                                                                                                                              |
| Engine | Engine | Kohler TCR Engine                  |        |                     | ✓        | ✓               | ✓                | ✓                | -              | -                                                                                                                                                                                                                                                          |
| Engine | Engine | 430 Dieselmax Engine               |        | Tier II/ Tier III   | ✓        | ✓               | ✓                | ✓                | ✓              | Dieselmax Engine Tests                                                                                                                                                                                                                                     |
| Engine | Engine | 430 Dieselmax Engine               |        | Tier 3 Equiv 55kW   | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |
| Engine | Engine | 430 Dieselmax Engine               |        | Tier 3 Equiv 56+kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                                                                                                                                  |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                 | System | System              | Function |                 |                  |                  |                |                                                                                                                                             |
|--------|--------|----------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                      |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                            |
| Engine | Engine | 430 Dieselmax Engine |        | Tier II 6 cylinder  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | 430 Dieselmax Engine |        | Tier III 6 cylinder | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |
| Engine | Engine | 430 Dieselmax Engine |        | Tier IVi 55kW       | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics                                                                                                                   |
| Engine | Engine | 430 Dieselmax Engine |        | Tier IVi 56+kW      | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override |

## Xtruck OHW808 Support List -JCB

Remark:

1. ✓ : means that the system has this function

2. - : means that the system does not have this function

3. compared with the last version, the new added function is marked in red color.

| Series | Mode   | Type                 | System | System              | Function |                 |                  |                  |                |                                                                                                                                                                                                                                                            |
|--------|--------|----------------------|--------|---------------------|----------|-----------------|------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        |        |                      |        |                     | Read ECU | Read Fault Code | Erase Fault Code | Read Data Stream | Actuation Test | Special Function                                                                                                                                                                                                                                           |
| Engine | Engine | 430 Dieselmax Engine |        | Tier IV Final 55kW  | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | 430 Dieselmax Engine |        | Tier IV Final 56+kW | ✓        | ✓               | ✓                | ✓                | ✓              | Hydraulic FIE Diagnostics<br>High Pressure FIE Diagnostics - IMV<br>High Pressure FIE Diagnostics - HPV<br>IMV Dynamic Test<br>IMV Override<br>Aftertreatment Service Routines<br>Aftertreatment component initialisation<br>Aftertreatment Component Test |
| Engine | Engine | 430 Dieselmax Engine |        | 430 55kW            | ✓        | ✓               | ✓                | ✓                | ✓              | Cranking Bottle Leak Off Test                                                                                                                                                                                                                              |