




POLOLU A4990 DUAL MOTOR DRIVER

CARRIER

USER'S GUIDE

USING THE MOTOR DRIVER



Minimal wiring diagram for connecting a microcontroller to an A4990 dual motor driver carrier.

In a typical application, power connections are made on one side of the board and control connections are made on the other. The INH (inhibit) pin is pulled low internally, disabling the A4990 by default, and must be driven high (2.0–5.5 V) in order to enable the driver.






The OUT1 and OUT2 pins form one motor channel while the OUT3 and OUT4 pins form the other. The state of each output is controlled by a corresponding input (IN1 through IN4); note that IN2 and IN4 are inverted inputs. All four INx pins are pulled to their inactive states by default. See the truth tables in the A4990 datasheet for more information on how the inputs affect the driver outputs.

The EF1 and EF2 pins are open-drain outputs that are driven low by the chip to indicate active faults (the datasheet describes what each combination of EF1 and EF2 means). Otherwise, these pins remain in a floating state, so you will need to connect external pull-up resistors (or use microcontroller inputs with their built-in pull-ups enabled) if you want to monitor fault conditions on the driver.

PINOUT







PIN	Default State	Description
VIN		Reverse-protected 6 V to 32 V motor power supply connection.
VBB		This pin gives access to the motor power supply after the reverse-voltage protection MOSFET (see the board schematic below). It can be used to supply reverse-protected power to other components in the system. It is generally intended as an output, but it can also be used to supply board power.
GND		Ground connection points for the motor and logic power supplies. <u>The control source and the motor driver must share a common ground.</u>
OUT1		Motor A output +.
OUT2		Motor A output
OUT3		Motor B output +.
OUT4		Motor B output
IN1	LOW	Control input for OUT1. PWM can be applied to this pin.
IN2	HIGH	Inverted control input for OUT2. PWM can be applied to this pin.
IN3	LOW	Control input for OUT3. PWM can be applied to this pin.
IN4	HIGH	Inverted control input for OUT4. PWM can be applied to this pin.
INH	LOW	Logic input that puts the A4990 into a low-power sleep mode when low.
EF1	floating	Error flag output 1: driven low to indicate active fault status; floating otherwise.
EF2	floating	Error flag output 2: driven low to indicate active fault status; floating otherwise.

REAL-WORLD POWER DISSIPATION CONSIDERATIONS


Even though the driver limits the motor current to about 0.9 A per channel, the chip by itself will overheat at lower currents. For example, in our tests at room temperature with no forced air flow, the chip was able to deliver 0.9 A per channel for approximately 20 s before the chip's thermal protection kicked in. A continuous current of 0.7 A per channel was sustainable for many minutes without triggering a thermal shutdown. The actual current you can deliver will depend on how well you can keep the motor driver cool. The carrier's printed circuit board is designed to draw heat out of the motor driver chip, but performance can be improved by adding a heat sink. Our tests were conducted at 100% duty cycle; PWMing the inputs will introduce additional heating proportional to the frequency (unless the A4990 is already PWMing the outputs to limit the current).






This product can get **hot** enough to burn you long before the chip overheats. Take care when handling this product and other components connected to it.

INCLUDED HARDWARE






Two 1×8-pin breakaway 0.1" male headers are included with the A4990 motor driver carrier, which can be soldered in to use the driver with perfboards, breadboards, or 0.1" female connectors. (The headers might ship as a single 1×16 piece that can be broken in half.) When used with these header pins, the board can be oriented with the parts visible, as shown in the right picture above, or with the silkscreen visible, by soldering the headers in from the opposite side. You can also solder your motor leads and other connections directly to the board.





SCHEMATIC



A4990 Dual Motor Driver Carrier schematic diagram.

This schematic is also available as a downloadable pdf (118k pdf).