Qotom Q305P/Q310P

Qotom Q305P/Q310P Mini PC User Manual

Models: Q305P, Q310P

Advertisements

Advertisements

Brand: Qotom

1. Introduction

This manual provides detailed instructions for setting up, operating, and maintaining your Qotom Q305P or Q310P Mini PC. These fanless mini PCs are designed for various applications including office, home, banking, and hotel environments, offering low power consumption and 24/7 operation capability.

Advertisements

Advertisements

Manuals+ Q & A | Deep Search | Upload

The Q305P model features an Intel Celeron Processor 3205U (1.50 GHz), while the Q310P model is equipped with an Intel Celeron Processor 3215U (1.70 GHz), both with Intel HD Graphics.

2. Specifications

Feature	Description
Dimensions	155mm x 127mm x 48mm (L*W*H)
Processor (Q305P)	Intel Celeron Processor 3205U, 2M Cache, 1.50 GHz
Processor (Q310P)	Intel Celeron Processor 3215U, 2M Cache, 1.70 GHz
Graphics	Intel HD Graphics (Integrated Card)
Memory	1 x DDR3L SODIMM Memory Slot, supports DDR3L 1333/1600 GHz, Max. 8GB
Storage	1 x mSATA SSD slot, 1 x 2.5-inch HDD/SSD bay
Wi-Fi	1 x Half Mini PCIe slot for WIFI (optional)
Power Consumption	15W
Operating Systems	Windows 7, Windows 10, Linux, pfSense, CentOS, Sophos, OPNsense, VyOS, Linux iptables, Untangle, etc.
Certification	CE
Warranty	1 Year

Feature	Description
Package Weight	2.0kg

Advertisements

Port Layout

Detailed Front and Back Panel Connectors

Advertisements

Advertisements

3. Package Contents

Your Qotom Mini PC package should contain the following items:

- 1 x Qotom Mini PC (Q305P or Q310P model)
- 1 x Power supply (adapter and regional plug: US/UK/EU/AU/IT standard)
- 1 x VESA bracket & screws for monitor mounting
- Optional: Wi-Fi antennas (if Wi-Fi option was selected)

Advertisements

Advertisements

Included Accessories: Power Adapter, VESA Bracket, Antennas, and Screws

4. Initial Setup

4.1 Connecting Peripherals

1. **Power Connection:** Connect the provided power adapter to the 12V DC input port on the back panel of the Mini PC, then plug it into a power outlet.

2. **Display Connection:** Connect your monitor to one of the HD video ports (HDMI) on the back panel. If you require VGA, ensure you have requested the COM3 VGA port option and use an appropriate adapter if necessary.
3. **USB Devices:** Connect your keyboard, mouse, and other USB devices to the available USB 3.0 or USB 2.0 ports on the front or back panels.
4. **Network Connection:** For wired network access, connect an Ethernet cable to one of the Intel I211-AT 10/100/1000 Controller ports.
5. **Audio Devices:** Connect speakers or headphones to the Line-out port, and a microphone to the Mic-in port on the back panel.
6. **Antennas (if applicable):** If your model includes Wi-Fi, screw the provided antennas onto the connectors on the back panel.

4.2 VESA Mount Installation

The Mini PC can be mounted to the back of a VESA-compatible monitor using the included bracket and screws.

Advertisements

Advertisements

1. Attach the VESA bracket to the back of your monitor using the appropriate screws.
2. Secure the Mini PC to the VESA bracket using the remaining screws.

VESA Bracket Installation Diagram

5. Operating System

Your Mini PC supports a wide range of operating systems including Windows 7, Windows 10, various Linux distributions (e.g., pfSense, CentOS, Sophos, OPNsense, VyOS, Linux iptables, Untangle).

Advertisements

Advertisements

The device may come with an unactivated version of Windows 10 preloaded for testing purposes. Users can reinstall their preferred operating system as needed.

5.1 Boot Options and BIOS Access

- To access the boot menu and select a boot device (e.g., USB drive for OS installation), press the **F11** key during startup.
- To enter the BIOS/UEFI setup utility, press the **Delete** key during startup.

6. Connectivity

6.1 Front Panel Connectors

- **Power Button:** To turn the device on/off.
- **HDD LED, Power LEDs:** Indicators for hard drive activity and power status.
- **2 x USB 3.0 Ports:** For high-speed data transfer with compatible devices.
- **2 x USB 2.0 Ports:** For connecting standard USB peripherals.
- **2 x RS232 Ports (COM5, COM6):** Serial communication ports.

Advertisements

Advertisements

6.2 Back Panel Connectors

- **1 x DV 12V DC Input:** Power input port.
- **2 x HD Video Ports (HDMI):** For connecting displays.
- **4 x COM Ports (COM1, COM2, COM3, COM4):** Serial communication ports. Note that COM2 can be configured as RS485 and COM3 can be configured as a VGA port if specified at the time of purchase.
- **2 x Intel I211-AT 10/100/1000 Controller Ports:** Gigabit Ethernet ports for network connectivity.
- **2 x USB 3.0 Ports:** Additional high-speed USB ports.
- **1 x Mic-in, Line-out:** 3.5mm audio jacks for microphone input and audio output.

7. Internal Components and Expansion

7.1 Storage

The Mini PC supports two types of storage:

- **1 x Full Mini PCIe slot:** For mSATA SSDs.
- **1 x 2.5-inch bay:** For standard 2.5-inch HDD or SSD drives.

Advertisements

Advertisements

7.2 Wireless Connectivity

The device includes:

- **1 x Half Mini PCIe slot:** This slot is typically used for a Wi-Fi module. It can also be used for a 3G/4G module if specified during purchase.
- **1 x SIM card slot:** Available for use with 3G/4G modules.

7.3 Other Internal Connectors

- **1 x Automatically Boot Jumper:** Allows configuration for automatic power-on.
- **1 x GPIO:** General Purpose Input/Output pins for custom applications.

Advertisements

Advertisements

Internal View of Qotom Mini PC

8. Maintenance

The Qotom Mini PC is designed to be fanless, reducing dust accumulation and noise. Regular maintenance is minimal but important for longevity:

- **Cleaning:** Periodically wipe the exterior of the device with a soft, dry cloth to remove dust. Avoid using liquid cleaners directly on the device.
- **Ventilation:** Ensure the heat sink fins are not obstructed to allow for proper passive cooling.
- **Firmware Updates:** Check the manufacturer's website for any available BIOS or driver updates to ensure optimal performance and compatibility.

Advertisements

Advertisements

9. Troubleshooting

9.1 Common Issues and Solutions

- **No Power:**
  - Ensure the power adapter is securely connected to both the Mini PC and a working power outlet.
  - Verify the power outlet is functional by testing with another device.
- **No Display:**
  - Check that the monitor is powered on and correctly connected to the Mini PC's HD video port.
  - Try a different display cable or monitor if available.
- **Operating System Not Booting:**
  - Ensure the storage drive (mSATA SSD or 2.5-inch HDD/SSD) with the OS is properly installed.
  - Access the BIOS (press Delete during startup) to verify boot order and detect the storage drive.
  - If installing a new OS, ensure your bootable USB drive is correctly prepared and select it from the boot menu (press F11 during startup).

Advertisements

Advertisements

- **Network Connectivity Issues:**
  - For wired connections, check the Ethernet cable and router/switch status.
  - For Wi-Fi, ensure antennas are securely attached and the Wi-Fi module is correctly installed and drivers are loaded in the OS.

10. User Tips

- **Custom COM Port Configuration:** If you require COM2 to function as RS485 or COM3 as a VGA port, ensure you communicate this requirement at the time of purchase. These configurations are typically set during manufacturing.
- **4G Module Installation:** If you plan to use a 4G module instead of Wi-Fi in the Half Mini PCIe slot, please specify this when ordering, as it may require specific module compatibility or configuration.
- **OS Reinstallation:** The Mini PC is compatible with various operating systems. If you wish to reinstall or change the OS, you can do so by booting from a USB drive (F11 key) and accessing the BIOS (Delete key) for advanced settings.

Advertisements

Advertisements

11. Warranty and Support

Your Qotom Mini PC comes with a **1-year warranty** from the date of purchase, covering manufacturing defects.

For technical support, driver downloads, or to request the motherboard user manual, please contact Qotom Official Store directly. You may need to provide your purchase details for assistance.

Documents - Qotom – Q305P/Q310P

no relevant documents

Advertisements

Advertisements