
SOLAIRE INTELLIGENCE

SI WATER · TANK & BOREHOLE CONTROLLER

Your tank runs itself.

SI Water watches your tank, runs your borehole pump, protects it, and opens the municipal supply as backup. All on its own, with or without the internet.

- No moving parts. One sealed probe in the tank.
- Decides everything on the unit. The app is the window.
- Drops into the wiring the float switch used.





Not one empty tank.

Feedback from three of our own sites since install: no empty tanks, no borehole running through the night, no evenings that start on a low tank. The controller fills before it becomes a problem.

Fills on its own

Set the level it should start at and the level to stop at. Add a time window for the borehole and a daily top-up if you want one.

Emergency fill

Below the emergency level it fills sooner. At a critical level it fills straight away, day or night, whatever the schedule.

Pump protection

When the borehole stops delivering, the pump is switched off, rested and retried. After repeated failures it locks out until someone checks it.

Municipal backup

If the borehole can't keep up, the town supply valve opens and closes at the levels you set. In automatic mode the borehole and the valve never run together.

Knows your water

Litres in the tank, inflow and outflow, today's and this month's usage, and the size of each draw your home makes.


Overflow guard

At a full tank both outputs switch off, in every mode, including manual. A lost level reading stops automatic filling too.

IN THE APP


Everything about your water, on your phone.

The Solaire Intelligence app for iPhone and Android shows the tank live, from the lounge or the other side of the country. Change a fill level or switch the pump by hand from anywhere.




Status

Level, litres, flow in and out, and running totals for the day, the month and all time.



Automation

Each fill mode has its own switch and its own start and stop levels, in plain words.



Your tank

Enter the tank's height and volume once. Pump protection and municipal backup are set here too.

For installers

- Replaces the float switch. The signal cable to the pump controller now comes from SI Water, so there is no extra cabling.
- One probe does the work of high, mid and low level switches.
- Ships as a complete IP65 enclosure with breaker, 12 V supply and the probe already wired. Bring in 230 V, connect the pump signal, set up in the app.
- Firmware updates arrive through the app. No site visit.
- Works with Home Assistant out of the box, for owners who run one.

Specifications

MEASURES	Tank level, litres, inflow, outflow, usage events
PROBE	Sealed stainless pressure probe, 5 m cable. Up to 20 m on request
TANKS	Straight-sided tanks of any size. Other shapes calculated per project
OUTPUTS	Two volt-free relay contacts: borehole pump control, municipal valve
ENCLOSURE	IP65, with breaker and 12 V DIN-rail supply. Fed from 230 V AC
NETWORK	2.4 GHz WiFi. Automation runs with no connection
APP	Solaire Intelligence, iOS and Android, plus web portal
WARRANTY	12 months. No subscription
MADE IN	South Africa

Solaire Intelligence. Local, smart, reliable.

Ask about SI Water for your property or your next installation.

sales@solairesa.co.za
073 894 8248
solaire-intelligence.co.za