




J_CELL
cell tap sense wires from the 4S b..



F2
SCF9550-30-05 self-control fuse



SECOND-LEVEL PROTECTOR BQ77207, FUSE DRIVE, UNDER-VOLTAGE HOLD



SMBUS OUT, TEST POINTS, FLAGS

