**5** Use the Bather's panel to set the temperature, select the filtration, and turn on the jets and lights.

**11** This valve controls the water flow of the neck jets.




| # | Component Identification | Qty. |
|---|---|---|
| 1 | HK™12 Jets | 14 |
| 2 | HK™16 Jets | 2 |
| 4 | HK™8 Neck Jets | 2 |
| 5 | Bathers Control Panel | 1 |
| 6 | IR Sensor | 1 |
| 7 | Filter Canisters | 2 |
| 8 | Suction Fitting | 1 |
| 9 | Floor Drain | 1 |
| 10 | Light | 1 |
| 11 | Neck Jet Valve | 1 |
| 12 | Ozone Injector Fitting | 1 |
| 13 | Spa Frog® | 1 |
| 14 | Spa Frog® Return Fitting | 1 |

| Physical Specifications | Size |
|---|---|
| Dimensions | 77" x 84" |
| Height | 34" |
| Interior Depth | 32.5" |
| Seating Positions | 4-7 |
| Weight Dry/Lbs. | 600 |
| Weight Full/Lbs. | 3436 |
| Water Capacity/Gallons | 340 |
| Total Therapy Jets | 18 |

**5** Use the Bather's panel to set the temperature, select the filtration, and turn on the jets and lights.

**11** This valve controls the water flow of the neck jets.




| # | Component Identification | Qty. |
|---|---|---|
| 1 | HK™ 12 Jets | 10 |
| 2 | HK™ 16 Jets | 2 |
| 3 | HK™ 40 Jets | 4 |
| 4 | HK™ 8 Neck Jets | 2 |
| 5 | Bathers Control Panel | 1 |
| 6 | IR Sensor | 1 |
| 7 | Filter Canisters | 2 |
| 8 | Suction Fitting | 1 |
| 9 | Floor Drain | 1 |
| 10 | Light | 1 |
| 11 | Neck Jet Valve | 1 |
| 12 | Ozone Injector Fitting | 1 |
| 13 | Spa Frog® | 1 |
| 14 | Spa Frog® Return Fitting | 1 |
| 15 | Waterfall Valve | 1 |
| 16 | PowerShift™ Control | 1 |
| 17 | Waterfall Feature | 1 |

| Physical Specifications | Size |
|---|---|
| Dimensions | 77" x 84" |
| Height | 34" |
| Interior Depth | 32.5" |
| Seating Positions | 4-7 |
| Weight Dry/Lbs. | 600 |
| Weight Full/Lbs. | 3436 |
| Water Capacity/Gallons | 340 |
| Total Therapy Jets | 18 |



**ZONE 2**
Upper-, mid- and lower-back jets.*



**ZONE 1**
Lower-body jets.*

*Neck jets operate in zone 2.

Waterfall operates in zone 1.