


Cullet Preheater Manual-Villotta

Contents

- Cullet Preheater Manual-Villotta.....3**
 - Cullet Preheater Manual-Villotta.....3
 - References..... 11
 - Approval..... 12
 - Revision History..... 12
- Index.....13**

Cullet Preheater Manual-Villotta

Cullet Preheater Manual-Villotta



Section	Title
Introduction	
	CPH - Table of Contents
Safety	
	FUR-02-001 Furnace Safety
	Cullet Preheater System - CE User Manual (available in Windchill)
Installation	
	Installation Tasks Villotta
	CPH Preassembly and Lift Procedure
	35932-00-01-rev24 PFD
	35932-00-100_3D_R4
	As Built Drawings
	35932-00-301.pdf
	35932-00-302.pdf
	35932-00-301.dxf

Section	Title
	35932-00-302.dxf
Controls	
	CPH Control Loop Flowchart - Villotta 1
	CPH DFC Plus HMI and Touch Panel Operator's Manual - v2.0.0 (available in Windchill)
	BAT-07-031 Cullet Preheater Controls Cross Reference
Commissioning/Startup	
	BAT-02-030-F 001 Cullet Preheater Cold Commissioning Checklist
	BAT-03-005 Cullet Preheater Hot Restart - v6
	BAT-03-006 Cullet Preheater Cold Startup - v6
	BAT-03-007 Cullet Preheater Fast Shutdown - v6
	BAT-03-008 Cullet Preheater Slow Shutdown - v6
Operations	
	BAT-02-030 Cullet Preheater Operation
	BAT-04-030 Cullet Preheater Operation and Maintenance Manual - v6
	BAT-07-030 Cullet Preheater Operation Conditions
Maintenance and Troubleshooting	
	BAT-02-040 Cullet Preheater Maintenance
	BAT-03-009 Cullet Preheater Cleaning
	BAT-07-040 Cullet Preheater Maintenance Conditions
	CPH Lower Cone Drawings
	35932-01-04.pdf
	35932-01-04-01.pdf
	35932-01-04-02.pdf
	35932-01-04-03.pdf

Section	Title
	35932-01-04-04.pdf
	35932-01-04_1.dxf
	35932-01-04-01__1.dxf
	35932-01-04-02__1.dxf
	35932-01-04-03__1.dxf
	35932-01-04-04__1.dxf
	Wear Plate Drawings
	35932-08-06.pdf
	35932-08-06__1.dxf
Manufacturer's Materials	
	Actuator
	Beck Instruction Manual (available in Windchill)
	Beck Drive Wiring Diagram (available in Windchill)
	Beck EC Declaration of Conformity (available in Windchill)
	Airlock
	Fansider DVCM and DVCP (available in Windchill)
	Fansider Double-Clip Valves Use, Maintenance and Spare Parts (available in Windchill)
	Conveyors
	ZIPPE SC-46 EC Declaration of Conformity (available in Windchill)
	ZIPPE SC-46 Operating Instructions (available in Windchill)
	ZIPPE SC-46 Spare Part List (available in Windchill)
	ZIPPE SC-46 Technical Data Sheet (available in Windchill)
	ZIPPE SC-46 Sleeves for Screw Conveyor Spare Part List (available in Windchill)

Section	Title
	Carl Stahl Chain Block User Information (available in Windchill)
	Carl Stahl EC Declaration of Conformity (available in Windchill)
	RUD SF-07 Load Ring VLBS User Instructions (available in Windchill)
	ZIPPE SF-07 Chasis Spare Part List (available in Windchill)
	ZIPPE SF-07 EC Declaration of Conformity (available in Windchill)
	ZIPPE SF-07 Load Ring VLBS Technical Data Sheet (available in Windchill)
	ZIPPE SF-07 Operating Instructions (available in Windchill)
	ZIPPE SF-07 Spare Part List (available in Windchill)
	ZIPPE SF-07 Technical Data Sheet (available in Windchill)
	ZIPPE SF-07 Spur Wheel Chain Block Technical Data Sheet (available in Windchill)
	ZIPPE Maintenance Protocol (available in Windchill)
	SEW Eurodrive Motor Operating Instructions (available in Windchill)
	SEW Eurodrive Gear Unit Operating Instructions (available in Windchill)
	Electrical
	Cullet Pre-Heater Schematic Diagram (available in Windchill)
	Acrotecna Field Termination Board (available in Windchill)
	Acrotecna Composite Drawing (available in Windchill)
	Acrotecna PCB 3D Print (available in Windchill)
	Acrotecna Analog Input Terminal (available in Windchill)

Section	Title
	Acrotecna DFC plus HMI Overall Network (available in Windchill)
	Acrotecna LOOP Wiring –CPH (available in Windchill)
	CPH Cable Pull Sheet rev 2 (available in Windchill)
	Acrotecna CE Declaration of Conformity - Panel SN2216 (available in Windchill)
	Acrotecna Internal test certificate - Panel SN2216 (available in Windchill)
	Fans
	Ferrari Centrifugal Fan User's Manual (available in Windchill)
	FA-02 Technical Document (available in Windchill)
	FA-02 EC Declaration of Conformity (available in Windchill)
	FA-02 Main Fan Drawing (available in Windchill)
	FA-06 Technical Document (available in Windchill)
	FA-06 EC Declaration of Conformity (available in Windchill)
	FA-06 Fan Drawing (available in Windchill)
	FA-11 Technical Document (available in Windchill)
	FA-11 EC Declaration of Conformity (available in Windchill)
	FA-11 Fan Drawing (available in Windchill)
	FA-12 Technical Document (available in Windchill)
	FA-12 EC Declaration of Conformity (available in Windchill)
	FA-12 Fan Drawing (available in Windchill)
	Falk Steelflex Grid Coupling Installation Manual (available in Windchill)
	Siemens Simotics GP, SD, DP Operating Instructions (available in Windchill)

Section	Title
	Telemecanique XSAV Proximity Sensor (available in Windchill)
	Filters
	Wamair Filter User's Manual (available in Windchill)
	ZIPPE Batch Filter Technical Data Sheet(available in Windchill)
	ZIPPE Batch Filter Spare Part List (available in Windchill)
	Batch Filter EC Declaration of Conformity (available in Windchill)
	Cullet Filter Technical Data Sheet (available in Windchill)
	ZIPPE Cullet Filter Spare Part List (available in Windchill)
	ZIPPE Cullet Filter EC Declaration of Conformity (available in Windchill)
	ZIPPE Maintenance Protocol (available in Windchill)
	Inverters
	ABB ACS355 Drive User's Manual (available in Windchill)
	ABB ACS850 Quick Start-Up Guide (available in Windchill)
	ABB ACS850 and ACQ810 Application Programming Guide (available in Windchill)
	ABB ACS850 Firmware Manual (available in Windchill)
	ABB ACS850 Hardware Manual (available in Windchill)
	CPH Batch Screw Feeder SF07 - ACS850 1 247 rev1 (available in Windchill)
	CPH Charger Vent Fan FA12 - ACS355 rev1 (available in Windchill)
	CPH Emergency Air Fan 1 FA11 - ACS355 rev1 (available in Windchill)

Section	Title
	CPH Emergency Air Fan 2 FA06 - ACS355 rev1 (available in Windchill)
	CPH Main Fan FA02 - ACS850 1 247 rev1 (available in Windchill)
	Isolator
	Dekomte Drawing-Fabric Expansion Joint (available in Windchill)
	Level Indicators
	VEGAPULS 68 Radar Sensor Operating Instructions (available in Windchill)
	VEGAPULS 68 Declaration of Conformity (available in Windchill)
	Bindicator Roto-Bin-Dicator Installation-Operation Manual (available in Windchill)
	Automation Products Low Temp Information (available in Windchill)
	Automation Products Hi Temp Information (available in Windchill)
	Batch LI-201 – 030915 (available in Windchill)
	Cullet LI-204 030715 After Calibration (available in Windchill)
	Bindicator Declaration of Conformity (available in Windchill)
	Load Cell
	Sartorius PR 6201 Load Cell Technical Data Sheet (available in Windchill)
	Sartorius Load Cell Calibration on 7th March 2015 (available in Windchill)
	Sartorius Mounting Kit for PR 6201 Installation Manual (available in Windchill)
	Sartorius PR 6001 Mounting Kit Data Sheet (available in Windchill)

Section	Title
	Sartorius X3 Process Indicator Pr 5410 Operating Manual (available in Windchill)
	Sartorius X3 Process Indicator Data Sheet (available in Windchill)
	Sartorius Cable Junction Box Installation Manual (available in Windchill)
	Sartorius Cables and Cable Box Data Sheet (available in Windchill)
	Sartorius Cable Junction Box EU Declaration of Conformity (available in Windchill)
	Sartorius Load Cell Declaration of Conformity (available in Windchill)
	Sartorius PR6001-GL-Certificate (available in Windchill)
	Pressure Transmitter
	Rosemount 3051S Pressure Transmitter Reference Manual (available in Windchill)
	Rosemount 3051S EC Declaration of Conformity (available in Windchill)
	Rotameters
	asa Flowmeters Instructions and Maintenance (available in Windchill)
	asa Flowmeters Technical Sheet (available in Windchill)
	asa Flowmeter Part Information (available in Windchill)
	Thermocouple
	Rosemount DIN-Style Temperature Sensors Data Sheet (available in Windchill)
	Rosemount 1075 and 1099 Thermocouples Data Sheet (available in Windchill)
	Rosemount 0065-0185 Sensor Assembly Quick Start Guide (available in Windchill)
	Rosemount 1067 Compact Sensor Data Sheet (available in Windchill)

Section	Title
	Rosemount 1067 Drawing (available in Windchill)
	WIKA TC50 Surface TC Sensor (available in Windchill)
	WIKA TC50 Configuration Sheet (available in Windchill)
	WIKA TC50 Operating Instructions (available in Windchill)
	WIKA TC50 Declaration of Conformity (available in Windchill)
	WIKA Standard Bending Dimensions (available in Windchill)
	Rosemount Temperature Sensor EC Declaration of Conformity (available in Windchill)
	Trolley
	Tractel Corso Overhead Traveling Trolleys Operation Manual (available in Windchill)
	Tractel Corso Beam Trolley Technical Sheet (available in Windchill)
	Tractel Corso Declaration of Conformity (available in Windchill)
	Vibrator
	FMC Syntron Electromagnetic Vibrators Service Manual (available in Windchill)
	FMC Syntron PowerPulse Service Manual (available in Windchill)

References

Document Classification

- Asset Protection and Stability

Fundamentals

- N/A

Approval

Sanctioning Representatives of the Global Team

Title	Representative
Global Operations	Benjamin Brown

Revision History

2016-05-24	Approved by John Jenkinson, Mechanical Systems Discipline Leader Original Issue
2019-10-21	Approved by Benjamin Brown, Mechanical Systems Discipline Leader Updated with the following changes: The reference codes regarding -06 documents were deleted and changed to “(available in Windchill)” because these documents were retired from Book Space.

Index

C

change log [12](#)
cullet preheating sequence [3](#)

D

document approval [12](#)

H

heat recovery optimization [3](#)

R

reference list [11](#)
revision history [12](#)

S

sign-off workflow [12](#)
standards and norms [11](#)

T

temperature sensor calibration [3](#)