[

mmexport1552147425962.png

930×877 121 KB

](https://global.discourse-cdn.com/standard17/uploads/enigma1/original/1X/63326f42de049fa2340fce2437029feb1ea9868c.png)

This is the error message above. Then the core just exit and surface is waiting for the core. Is there any solutions to work it out?