My computer uses i5 which I thought was compatible with Intel SGX, however when accessing the BIOS I couldn't find SGX anywhere to enable. If it IS compatible, where would it be in the BIOS?

Also will we have to download or purchase SGX software as well?