


Беспроводной сенсор температуры DOMOBOЙ WTSensor v.3.0



Принципиальная схема





Печатная плата лицевая сторона

Печатная плата оборотная сторона

Part	Value	Device	Package
BT1	1.5V	BATTERY-AAA_KIT	BATTERY-AAA-KIT
BT2	1.5V	BATTERY-AAA_KIT	BATTERY-AAA-KIT
C 1	0.1uF	C-EUC1206	C1206
C2	0.1uF	C-EUC1206	C1206
C3	0.1uF	C-EUC1206	C1206
C4	0.1uF	C-EUC1206	C1206
C 7	0.1uF	C-EUC1206	C1206
IC1	LM75_ICN	SO8_LM75	lm75
JP1	COM	PINHD-1X5	1X05
Q2	BC848ALT1SMD	BC848ALT1SMD	SOT23
Q3	BC848ALT1SMD	BC848ALT1SMD	SOT23
R1	10K	R-EU_R1206	R1206
R2	10K	R-EU_R1206	R1206
R3	10K	R-EU_R1206	R1206
R4	10K	R-EU_R1206	R1206
R5	10K	R-EU_R1206	R1206
U\$9	NRF24L01+	NRF24L01+	NRF24L01+
U1	ATMEGA168PA-AU	ATMEGA168PA-AU	QFP80P900X900X120-32N

Таблица компонентов