# Development Kit

SteamVR™ Tracking

Introduction

Welcome to the world of Steam®VR tracking! This kit contains everything you will need to get your head mounted display, controller, or other object tracking in the Steam®VR 3D environment.

## Contents

Core Module
100835-R03B

Application Board
100862-R03

Breakout Board A
100861-R02

Breakout Board B
100869-R02

USB Wireless Dongle

**Battery Pack**

Sensor Board (x40)
100857-R03

Antenna

4" Sensor Cables (x10)

3" Sensor Cables (x10)

**Trackpad Module**

Trackpad Board
100871-R02

Trackpad Ribbon

Sensor Breakout Pinout

Assembly Guide

Breakout A

BOTTOM

26 24 22 20 18 16 14 12 10 8 6 4
30 28   2 0

TOP

5 7 9 11 13 15 17 19 21 23 25 27
1 3   29 31

Breakout B

5 7 9 11 13 15 17 19 21 23 25 27
1
3
0
2
4
6
8
10
12
14

31
29
30
28
26
24
22
20
18
16

Software Setup

All of the necessary software and documentation can be obtained through Steam® using your developer account. You can download Steam® at http://www.steampowered.com.

Important Notes

- Sensor cables should be connected to the Breakout Boards and Sensor Boards with the metal cable contacts facing away from the PCB.

Support

For software and hardware support, visit the forums at: http://steamcommunity.com/app/507090/discussions/