


To Begin, orient the Heat Exhanger (PN: 3394011)

upright. Collect this part from those pulled.




Next, place the Housing on top of the

Heat Exchanger.

NOTE: Edge Grip and Foam Tape must be applied prior to installation (shown later)

WARNING: Ensure housing holes face the operator (shown later)



Next, Drill Bolts with a Torque

Drill into place.(PN: 601376 and 2580868)

NOTE: Lock Washers must be

applied, and Torque Value (22) must be met

WARNING: Thread screws prior to

drill to prevent stripping.



Next, place the fan (PN: 2957926) on

top of the housing,


aligning the bolt holes.

NOTE: The yellow

sticker (highlighted)

should be oriented

towards the top.



NOTE: Use the blue torque drill to fasten lock washers


and bolts to 5 ft/lbs each. The PNs for these were

PN: 636196, 2580868.

Drill until a Green prompt light

and a *beep* is audible. Check lock

asher deployment.




Apply the HYDAC Sticker in the shown orientation.

NOTE: Bubbles, Horizontal Alignment,

Orientation, and Centering are all


important for meeting Quality Standard.

Ensure this is done neatly or the Cooler may come back!



WARNING: Tie the cable on the fan as shown.

Do not pinch, double knot, or perform any action that may compromise the quality of the wires inside.




Lastly, mark all bolts (8) with

the yellow paint marker. This is

to ensure the customer cannot

mess with the bolt afte

shipment.



You have now completed the assembly!

Refer to the drawing to ensure all steps
were followed correctly. Ensure all labels
were attached neatly.

When all steps are completed, locate a Quality employee for inspection (if

necessary). Repeat this process until the order is fulfilled