




## **Thule Omnistor 8000**

## > Instructions

**User manual** 










5AP913-01 3








5AP913-01







5AP913-01 5

























## OPTIONAL INSTALLATION







8 5AP913-01