Data Communication and Computer Networks DCCN - EEE314

Lab 5RIP Configuration




COMSATS Institute of Information Technology (CIIT)

Islamabad Campus

Cisco Networking Academy Mind Wide Open

Lab 05 RIP Configuration

Topology Diagram



Learning Objectives

Upon completion of this lab, you will be able to:


- Cable a network according to the Topology Diagram.
- Erase the startup configuration and reload a router to the default state.
- Perform basic configuration tasks on a router.
- Configure and activate interfaces.
- Configure RIP routing on all routers.
- Verify RIP routing using **show** and **debug** commands.
- Reconfigure the network to make it contiguous.
- Observe automatic summarization at boundary router.
- Gather information about RIP processing using the debug ip rip command.
- Configure a static default route.
- Propagate default routes to RIP neighbors.
- Document the RIP configuration.

Scenarios

- Scenario A: Running RIPv1 on Classful Networks
- Scenario B: Running RIPv1 with Subnets and Between Classful Networks
- Scenario C: Running RIPv1 on a Stub Network.

Scenario A: Running RIPv1 on Classful Networks

Topology Diagram



Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
R1	Fa0/0	192.168.1.1	255.255.255.0	N/A
	S0/0/0	192.168.2.1	255.255.255.0	N/A
R2	Fa0/0	192.168.3.1	255.255.255.0	N/A
	S0/0/0	192.168.2.2	255.255.255.0	N/A
	S0/0/1	192.168.4.2	255.255.255.0	N/A
R3	Fa0/0	192.168.5.1	255.255.255.0	N/A
	S0/0/1	192.168.4.1	255.255.255.0	N/A
PC1	NIC	192.168.1.10	255.255.255.0	192.168.1.1
PC2	NIC	192.168.3.10	255.255.255.0	192.168.3.1
PC3	NIC	192.168.5.10	255.255.255.0	192.168.5.1

Task 1: Prepare the Network.

Step 1: Cable a network that is similar to the one in the Topology Diagram.

You can use any current router in your lab as long as it has the required interfaces shown in the topology.

Note: If you use 1700, 2500, or 2600 routers, the router outputs and interface descriptions will appear different.

Step 2: Clear any existing configurations on the routers.

Task 2: Perform Basic Router Configurations.

Perform basic configuration of the R1, R2, and R3 routers according to the following guidelines:

- 1. Configure the router hostname.
- 2. Disable DNS lookup.
- 3. Configure an EXEC mode password.
- 4. Configure a message-of-the-day banner.
- 5. Configure a password for console connections.
- 6. Configure a password for VTY connections.

Task 3: Configure and Activate Serial and Ethernet Addresses.

Step 1: Configure interfaces on R1, R2, and R3.

Configure the interfaces on the R1, R2, and R3 routers with the IP addresses from the table under the Topology Diagram.

Step 2: Verify IP addressing and interfaces.

Use the **show ip interface brief** command to verify that the IP addressing is correct and that the interfaces are active.

When you have finished, be sure to save the running configuration to the NVRAM of the router.

Step 3: Configure Ethernet interfaces of PC1, PC2, and PC3.

Configure the Ethernet interfaces of PC1, PC2, and PC3 with the IP addresses and default gateways from the table under the Topology Diagram.

Step 4: Test the PC configuration by pinging the default gateway from the PC.

Task 4: Configure RIP.

Step 1: Enable dynamic routing.

To enable a dynamic routing protocol, enter global configuration mode and use the router command.

Enter router ? at the global configuration prompt to a see a list of available routing protocols on your router.

To enable RIP, enter the command router rip in global configuration mode.

```
R1(config) #router rip
R1(config-router) #
```

Step 2: Enter classful network addresses.

Once you are in routing configuration mode, enter the classful network address for each directly connected network, using the **network** command.

```
R1(config-router) #network 192.168.1.0
R1(config-router) #network 192.168.2.0
R1(config-router) #
```

The network command:

- Enables RIP on all interfaces that belong to this network. These interfaces will now both send and receive RIP updates.
- Advertises this network in RIP routing updates sent to other routers every 30 seconds.

When you are finished with the RIP configuration, return to privileged EXEC mode and save the current configuration to NVRAM.

```
R1(config-router)#end
%SYS-5-CONFIG_I: Configured from console by console
R1#copy run start
```

Step 3: Configure RIP on the R2 router using the router rip and network commands.

```
R2(config) #router rip
R2(config-router) #network 192.168.2.0
R2(config-router) #network 192.168.3.0
R2(config-router) #network 192.168.4.0
R2(config-router) #end
%SYS-5-CONFIG_I: Configured from console by console
R2#copy run start
```

When you are finished with the RIP configuration, return to privileged EXEC mode and save the current configuration to NVRAM.

Step 4: Configure RIP on the R3 router using the router rip and network commands.

```
R3(config) #router rip
R3(config-router) #network 192.168.4.0
R3(config-router) #network 192.168.5.0
R3(config-router) #end
%SYS-5-CONFIG_I: Configured from console by console
R3# copy run start
```

When you are finished with the RIP configuration, return to privileged EXEC mode and save the current configuration to NVRAM.

Task 5: Verify RIP Routing.

Step 1: Use the show ip route command to verify that each router has all of the networks in the topology entered in the routing table.

Routes learned through RIP are coded with an **R** in the routing table. If the tables are not converged as shown here, troubleshoot your configuration. Did you verify that the configured interfaces are active? Did you configure RIP correctly? Return to Task 3 and Task 4 to review the steps necessary to achieve convergence.

R3#

```
R1#show ip route
Codes: C - connected, S - static, I - IGRP, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       {
m N1} - OSPF NSSA external type 1, {
m N2} - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
       i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
       * - candidate default, U - per-user static route, o - ODR
       P - periodic downloaded static route
Gateway of last resort is not set
    192.168.1.0/24 is directly connected, FastEthernet0/0
С
С
    192.168.2.0/24 is directly connected, Serial0/0/0
    192.168.3.0/24 [120/1] via 192.168.2.2, 00:00:04, Serial0/0/0
    192.168.4.0/24 [120/1] via 192.168.2.2, 00:00:04, Serial0/0/0
R
    192.168.5.0/24 [120/2] via 192.168.2.2, 00:00:04, Serial0/0/0
R1#
R2#show ip route
<Output omitted>
     192.168.1.0/24 [120/1] via 192.168.2.1, 00:00:22, Serial0/0/0
С
    192.168.2.0/24 is directly connected, Serial0/0/0
    192.168.3.0/24 is directly connected, FastEthernet0/0
С
    192.168.4.0/24 is directly connected, Serial0/0/1
R
    192.168.5.0/24 [120/1] via 192.168.4.1, 00:00:23, Serial0/0/1
R2#
R3#show ip route
<Output omitted>
    192.168.1.0/24 [120/2] via 192.168.4.2, 00:00:18, Serial0/0/1
    192.168.2.0/24 [120/1] via 192.168.4.2, 00:00:18, Serial0/0/1
    192.168.3.0/24 [120/1] via 192.168.4.2, 00:00:18, Serial0/0/1
    192.168.4.0/24 is directly connected, Serial0/0/1
С
С
    192.168.5.0/24 is directly connected, FastEthernet0/0
```

Step 2: Use the show ip protocols command to view information about the routing processes.

The **show ip protocols** command can be used to view information about the routing processes that are occurring on the router. This output can be used to verify most RIP parameters to confirm that:

- RIP routing is configured
- The correct interfaces send and receive RIP updates
- The router advertises the correct networks
- RIP neighbors are sending updates

R1#debug ip rip

RIP: build update entries

```
R1#show ip protocols
Routing Protocol is "rip"
Sending updates every 30 seconds, next due in 16 seconds
Invalid after 180 seconds, hold down 180, flushed after 240
Outgoing update filter list for all interfaces is not set
Incoming update filter list for all interfaces is not set
Redistributing: rip
Default version control: send version 1, receive any version
               Send Recv Triggered RIP Key-chain
 Interface
  FastEthernet0/0 1 2 1 Serial0/0/0 1 2 1
Automatic network summarization is in effect
Maximum path: 4
Routing for Networks:
     192.168.1.0
     192.168.2.0
Passive Interface(s):
Routing Information Sources:
     Gateway Distance Last Update 192.168.2.2
Distance: (default is 120)
R1#
```

R1 is indeed configured with RIP. R1 is sending and receiving RIP updates on FastEthernet0/0 and Serial0/0/0. R1 is advertising networks 192.168.1.0 and 192.168.2.0. R1 has one routing information source. R2 is sending R1 updates.

Step 3: Use the debug ip rip command to view the RIP messages being sent and received.

Rip updates are sent every 30 seconds so you may have to wait for debug information to be displayed.


The debug output shows that R1 receives an update from R2. Notice how this update includes all the networks that R1 does not already have in its routing table. Because the FastEthernet0/0 interface belongs to the 192.168.1.0 network configured under RIP, R1 builds an update to send out that interface. The update includes all networks known to R1 except the network of the interface. Finally, R1 builds an update to send to R2. Because of split horizon, R1 only includes the 192.168.1.0 network in the update.

Step 4: Discontinue the debug output with the undebug all command.

R1#undebug all All possible debugging has been turned off

network 192.168.1.0 metric 1

Scenario B: Running RIPv1 with Subnets and Between Classful Networks Topology Diagram



Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
R1	Fa0/0	172.30.1.1	255.255.255.0	N/A
	S0/0/0	172.30.2.1	255.255.255.0	N/A
R2	Fa0/0	172.30.3.1	255.255.255.0	N/A
	S0/0/0	172.30.2.2	255.255.255.0	N/A
	S0/0/1	192.168.4.9	255.255.255.252	N/A
R3	Fa0/0	192.168.5.1	255.255.255.0	N/A
	S0/0/1	192.168.4.10	255.255.255.252	N/A
PC1	NIC	172.30.1.10	255.255.255.0	172.30.1.1
PC2	NIC	172.30.3.10	255.255.255.0	172.30.3.1
PC3	NIC	192.168.5.10	255.255.255.0	192.168.5.1

Task 1: Make Changes between Scenario A and Scenario B

Step 1: Change the IP addressing on the interfaces as shown in the Topology Diagram and the Addressing Table.

Sometimes when changing the IP address on a serial interface, you may need to reset that interface by using the **shutdown** command, waiting for the LINK-5-CHANGED message, and then using the **no shutdown** command. This process will force the IOS to starting using the new IP address.

```
R1(config)#int s0/0/0
R1(config-if)#ip add 172.30.2.1 255.255.255.0
R1(config-if)#shutdown

%LINK-5-CHANGED: Interface Serial0/0/0, changed state to administratively down
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/0, changed state to down
R1(config-if)#no shutdown

%LINK-5-CHANGED: Interface Serial0/0/0, changed state to up
R1(config-if)#
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/0, changed state to up
```

Step 2: Verify that routers are active.

After reconfiguring all the interfaces on all three routers, verify that all necessary interfaces are active with the **show ip interface brief** command.

Step 3: Remove the RIP configurations from each router.

Although you can remove the old **network** commands with the **no** version of the command, it is more efficient to simply remove RIP and start over. Remove the RIP configurations from each router with the **no router rip** global configuration command. This will remove all the RIP configuration commands including the **network** commands.

```
R1(config) #no router rip
R2(config) #no router rip
R3(config) #no router rip
```

Task 2: Configure RIP

Step 1: Configure RIP routing on R1 as shown below.

```
R1(config) #router rip
R1(config-router) #network 172.30.0.0
```

Notice that only a single network statement is needed for R1. This statement includes both interfaces on different subnets of the 172.30.0.0 major network.

Step 2: Configure R1 to stop sending updates out the FastEthernet0/0 interface.

Sending updates out this interface wastes the bandwidth and processing resources of all devices on the LAN. In addition, advertising updates on a broadcast network is a security risk. RIP updates can be intercepted with packet sniffing software. Routing updates can be modified and sent back to the router, corrupting the router table with false metrics that misdirects traffic.

The passive-interface fastethernet 0/0 command is used to disable sending RIPv1 updates out that interface. When you are finished with the RIP configuration, return to privileged EXEC mode and save the current configuration to NVRAM.

```
R1(config-router) #passive-interface fastethernet 0/0 R1(config-router) #end %SYS-5-CONFIG_I: Configured from console by console R1#copy run start
```

Step 3: Configure RIP routing on R2 as shown below.

```
R2(config) #router rip
R2(config-router) #network 172.30.0.0
R2(config-router) #network 192.168.4.0
R2(config-router) #passive-interface fastethernet 0/0
R2(config-router) #end
%SYS-5-CONFIG_I: Configured from console by console
R2#copy run start
```

Again notice that only a single network statement is needed for the two subnets of 172.30.0.0. This statement includes both interfaces, on different subnets, of the 172.30.0.0 major network. The network for the WAN link between R2 and R3 is also configured.

When you are finished with the RIP configuration, return to privileged EXEC mode and save the current configuration to NVRAM.

Step 4: Configure RIP routing on R3 as shown below.

```
R3(config) #router rip
R3(config-router) #network 192.168.4.0
R3(config-router) #network 192.168.5.0
R3(config-router) #passive-interface fastethernet 0/0
R3(config-router) #end
%SYS-5-CONFIG_I: Configured from console by console
R3#copy run start
```

When you are finished with the RIP configuration, return to privileged EXEC mode and save the current configuration to NVRAM.

Task 3: Verify RIP Routing

Step 1: Use the show ip route command to verify that each router has all of the networks in the topology in the routing table.

```
Rl#show ip route

<Output omitted>

172.30.0.0/24 is subnetted, 3 subnets

C 172.30.1.0 is directly connected, FastEthernet0/0

C 172.30.2.0 is directly connected, Serial0/0/0

R 172.30.3.0 [120/1] via 172.30.2.2, 00:00:22, Serial0/0/0

R 192.168.4.0/24 [120/1] via 172.30.2.2, 00:00:22, Serial0/0/0

R 192.168.5.0/24 [120/2] via 172.30.2.2, 00:00:22, Serial0/0/0

R1#
```

Note: RIPv1 is a classful routing protocol. Classful routing protocols do not send the subnet mask with network in routing updates. For example, 172.30.1.0 is sent by R2 to R1 without any subnet mask information.

R2#show ip route

```
<Output omitted>
    172.30.0.0/24 is subnetted, 3 subnets
        172.30.1.0 [120/1] via 172.30.2.1, 00:00:04, Serial0/0/0
R
С
        172.30.2.0 is directly connected, Serial0/0/0
С
       172.30.3.0 is directly connected, FastEthernet0/0
    192.168.4.0/30 is subnetted, 1 subnets
        192.168.4.8 is directly connected, Serial0/0/1
С
     192.168.5.0/24 [120/1] via 192.168.4.10, 00:00:19, Serial0/0/1
R
R2#
R3#show ip route
<Output omitted>
    172.30.0.0/16 [120/1] via 192.168.4.9, 00:00:22, Serial0/0/1
     192.168.4.0/30 is subnetted, 1 subnets
C
        192.168.4.8 is directly connected, Serial0/0/1
С
    192.168.5.0/24 is directly connected, FastEthernet0/0
```

Step 2: Verify that all necessary interfaces are active.

If one or more routing tables does not have a converged routing table, first make sure that all necessary interfaces are active with **show ip interface brief**.

Then use **show ip protocols** to verify the RIP configuration. Notice in the output from this command that the FastEthernet0/0 interface is no longer listed under **Interface** but is now listed under a new section of the output: **Passive Interface(s)**.

```
R1#show ip protocols
```

```
Routing Protocol is "rip"
  Sending updates every 30 seconds, next due in 20 seconds
  Invalid after 180 seconds, hold down 180, flushed after 240
  Outgoing update filter list for all interfaces is not set
  Incoming update filter list for all interfaces is not set
  Redistributing: rip
  Default version control: send version 2, receive version 2
    Interface
                          Send Recv Triggered RIP Key-chain
    Serial0/1/0
                          2
  Automatic network summarization is in effect
 Maximum path: 4
  Routing for Networks:
    172.30.0.0
    209.165.200.0
Passive Interface(s):
    FastEthernet0/0
  Routing Information Sources:
              Distance Last Update 00.229 120 00:00:15
   Gateway
    209.165.200.229
  Distance: (default is 120)
```

Step 3: View the RIP messages being sent and received.

To view the RIP messages being sent and received use the **debug ip rip** command. Notice that RIP updates are not sent out of the fa0/0 interface because of the **passive-interface fastethernet** 0/0 command.

R1#debug ip rip R1#RIP: sending v1 update to 255.255.255.255 via Serial0/0/0 (172.30.2.1) RIP: build update entries network 172.30.1.0 metric 1 RIP: received v1 update from 172.30.2.2 on Serial0/0/0 172.30.3.0 in 1 hops


Step 4: Discontinue the debug output with the undebug all command.

R1#undebug all

All possible debugging has been turned off

Scenario C: Running RIPv1 on a Stub Network

Topology Diagram



Background

In this scenario we will modify Scenario B to only run RIP between R1 and R2. Scenario C is a typical configuration for most companies connecting a stub network to a central headquarters router or an ISP. Typically, a company runs a dynamic routing protocol (RIPv1 in our case) within the local network but finds it unnecessary to run a dynamic routing protocol between the company's gateway router and the ISP. For example, colleges with multiple campuses often run a dynamic routing protocol between campuses but use default routing to the ISP for access to the Internet. In some cases, remote campuses may even use default routing to the main campus, choosing to use dynamic routing only locally.

To keep our example simple, for Scenario C, we left the addressing intact from Scenario B. Let's assume that R3 is the ISP for our Company XYZ, which consists of the R1 and R2 routers using the 172.30.0.0/16 major network, subnetted with a /24 mask. Company XYZ is a stub network, meaning that there is only one way in and one way out of the 172.30.0.0/16 network—in via R2 (the gateway router) and out via R3 (the ISP). It doesn't make sense for R2 to send R3 RIP updates for the 172.30.0.0 network every 30 seconds, because R3 has no other way to get to 172.30.0.0 except through R2. It makes more sense for R3 to have a static route configured for the 172.30.0.0/16 network pointing to R2.

How about traffic from Company XYZ toward the Internet? It makes no sense for R3 to send over 120,000 summarized Internet routes to R2. All R2 needs to know is that if a packet is not destined for a host on the 172.30.0.0 network, then it should send the packet to the ISP, R3. This is the same for all other Company XYZ routers (only R1 in our case). They should send all traffic not destined for the 172.30.0.0 network to R2. R2 would then forward the traffic to R3.

Task 1: Make Changes between Scenario B and Scenario C.

Step 1: Remove network 192.168.4.0 from the RIP configuration for R2.

Remove network 192.168.4.0 from the RIP configuration for R2, because no updates will be sent between R2 and R3 and we don't want to advertise the 192.168.4.0 network to R1.

```
R2(config) #router rip
R2(config-router) #no network 192.168.4.0
```

Step 2: Completely remove RIP routing from R3.

```
R3(config) #no router rip
```

Task 2: Configure the Static Route on R3 for the 172.30.0.0/16 network.

Because R3 and R2 are not exchanging RIP updates, we need to configure a static route on R3 for the 172.30.0.0/16 network. This will send all 172.30.0.0/16 traffic to R2.

```
R3(config) #ip route 172.30.0.0 255.255.252.0 serial0/0/1
```

Task 3: Configure a Default Static Route on R2.

Step 1: Configure R2 to send default traffic to R3.

Configure a default static route on R2 that will send all default traffic—packets with destination IP addresses that do not match a specific route in the routing table—to R3.

```
R2(config) # ip route 0.0.0.0 0.0.0.0 serial 0/0/1
```

Step 2: Configure R2 to send default static route information to R1.

The default-information originate command is used to configure R2 to include the default static route with its RIP updates. Configure this command on R2 so that the default static route information is sent to R1.

```
R2(config) #router rip
R2(config-router) #default-information originate
R2(config-router) #
```

Note: Sometimes it is necessary to clear the RIP routing process before the **default-information originate** command will work. First, try the command **clear ip route** * on both R1 and R2. This command will cause the routers to immediately flush routes in the routing table and request updates from each other. Sometimes this does not work with RIP. If the default route information is still not sent to R1, save the configuration on R1 and R2 and then reload both routers. Doing this will reset the hardware and both routers will restart the RIP routing process.

Task 4: Verify RIP Routing.

Step 1: Use the show ip route command to view the routing table on R2 and R1.

```
R2#show ip route
Codes: C - connected, S - static, I - IGRP, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
      N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
       i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
       * - candidate default, U - per-user static route, o - ODR
       P - periodic downloaded static route
Gateway of last resort is 0.0.0.0 to network 0.0.0.0
     172.30.0.0/24 is subnetted, 3 subnets
С
       172.30.2.0 is directly connected, Serial0/0/0
        172.30.3.0 is directly connected, FastEthernet0/0
С
R
        172.30.1.0 [120/1] via 172.30.2.1, 00:00:16, Serial0/0/0
```

```
192.168.4.0/30 is subnetted, 1 subnets
C 192.168.4.8 is directly connected, Serial0/0/1
S* 0.0.0.0/0 is directly connected, Serial0/0/1
```

Notice that R2 now has a static route tagged as a candidate default.

```
R1#show ip route
```

```
Codes: C - connected, S - static, I - IGRP, R - RIP, M - mobile, B - BGP
    D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
    N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
    E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
    i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
    * - candidate default, U - per-user static route, o - ODR
    P - periodic downloaded static route
```

Gateway of last resort is 172.30.2.2 to network 0.0.0.0

```
172.30.0.0/24 is subnetted, 3 subnets
C 172.30.2.0 is directly connected, Serial0/0/0
R 172.30.3.0 [120/1] via 172.30.2.2, 00:00:05, Serial0/0/0
C 172.30.1.0 is directly connected, FastEthernet0/0
R* 0.0.0.0/0 [120/1] via 172.30.2.2, 00:00:19, Serial0/0/0
```

Notice that R1 now has a RIP route tagged as a **candidate default** route. The route is the "quad-zero" default route sent by R2. R1 will now send default traffic to the **Gateway of last resort** at 172.30.2.2, which is the IP address of R2.

Step 2: View the RIP updates that are sent and received on R1 with the debug ip rip command.

R1#debug ip rip

```
RIP protocol debugging is on
R1#RIP: sending v1 update to 255.255.255.255 via Serial0/0/0 (172.30.2.1)
RIP: build update entries
    network 172.30.1.0 metric 1
RIP: received v1 update from 172.30.2.2 on Serial0/0/0
    0.0.0.0 in 1 hops
    172.30.3.0 in 1 hops
```

Notice that R1 is receiving the default route from R2.

Step 3: Discontinue the debug output with the undebug all command.

R1#undebug all

All possible debugging has been turned off

Step 4: Use the show ip route command to view the routing table on R3.

R3#show ip route

<Output omitted>

```
S 172.30.0.0/16 is directly connected, Serial0/0/1 192.168.4.0/30 is subnetted, 1 subnets
C 192.168.4.8 is directly connected, Serial0/0/1 192.168.5.0/24 is directly connected, FastEthernet0/0
```

Notice that RIP is not being used on R3. The only route that is not directly connected is the static route.

Task 5: Document the Router Configurations

On each router, capture the following command output to a text file and save for future reference:


- Running configuration
- Routing table
- Interface summarization
- Output from show ip protocols

Task 6: Clean Up

Erase the configurations and reload the routers. Disconnect and store the cabling. For PC hosts that are normally connected to other networks (such as the school LAN or to the Internet), reconnect the appropriate cabling and restore the TCP/IP settings.

RIPv2 Configuration Lab

Topology Diagram



Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
	Fa0/0	172.30.1.1	255.255.255.0	N/A
R1	Fa0/1	172.30.2.1	255.255.255.0	N/A
	S0/0/0	209.165.200.230	255.255.255.252	N/A
	Fa0/0	10.1.0.1	255.255.0.0	N/A
R2	S0/0/0	209.165.200.229	255.255.255.252	N/A
	S0/0/1	209.165.200.233	255.255.255.252	N/A
	Fa0/0	172.30.100.1	255.255.255.0	N/A
	S0/0/1	209.165.200.234	255.255.255.252	N/A
R3	Lo0	172.30.110.1	255.255.255.0	N/A
	Lo1	172.30.200.17	255.255.255.240	N/A
	Lo2	172.30.200.33	255.255.255.240	N/A
PC1	NIC	172.30.1.10	255.255.255.0	172.30.1.1
PC2	NIC	172.30.2.10	255.255.255.0	172.30.2.1
PC3	NIC	10.1.0.10	255.255.0.0	10.1.0.1
PC4	NIC	172.30.100.10	255.255.255.0	172.30.100.1

Learning Objectives

Upon completion of this lab, you will be able to:

- Cable a network according to the Topology Diagram.
- Load provided scripts onto the routers.
- Examine the current status of the network.
- Configure RIPv2 on all routers.
- Examine the automatic summarization of routes.
- Examine routing updates with debug ip rip.
- Disable automatic summarization.
- Examine the routing tables.
- Verify network connectivity.
- Document the RIPv2 configuration.

Scenario

The network shown in the Topology Diagram contains a discontiguous network, 172.30.0.0. This network has been subnetted using VLSM. The 172.30.0.0 subnets are physically and logically divided by at least one other classful or major network, in this case the two serial networks 209.165.200.228/30 and 209.165.200.232/30. This can be an issue when the routing protocol used does not include enough information to distinguish the individual subnets. RIPv2 is a classless routing protocol that can be used to provide subnet mask information in the routing updates. This will allow VLSM subnet information to be propagated throughout the network.

Task 1: Cable, Erase, and Reload the Routers.

Step 1: Cable a network.

Cable a network that is similar to the one in the Topology Diagram.

Step 2: Clear the configuration on each router.

Clear the configuration on each of routers using the erase startup-config command and then reload the routers. Answer **no** if asked to save changes.

Task 2: Load Routers with the Supplied Scripts.

Step 1: Load the following script onto R1.

```
!
hostname R1
!
!
!
!
interface FastEthernet0/0
  ip address 172.30.1.1 255.255.255.0
  duplex auto
  speed auto
  no shutdown
!
interface FastEthernet0/1
  ip address 172.30.2.1 255.255.255.0
  duplex auto
```

```
speed auto
no shutdown
!
interface Serial0/0/0
ip address 209.165.200.230 255.255.255.252
clock rate 64000
no shutdown
!
router rip
passive-interface FastEthernet0/0
passive-interface FastEthernet0/1
network 172.30.0.0
network 209.165.200.0
!
line con 0
line vty 0 4
login
!
end
```

Step 2: Load the following script onto R2.

```
hostname R2
!
interface FastEthernet0/0
ip address 10.1.0.1 255.255.0.0
 duplex auto
 speed auto
 no shutdown
interface Serial0/0/0
 ip address 209.165.200.229 255.255.255.252
no shutdown
interface Serial0/0/1
 ip address 209.165.200.233 255.255.255.252
 clock rate 64000
no shutdown
router rip
passive-interface FastEthernet0/0
network 10.0.0.0
network 209.165.200.0
line con 0
line vty 0 4
 login
!
end
```

Step 3: Load the following script onto R3.

```
hostname R3
interface FastEthernet0/0
 ip address 172.30.100.1 255.255.255.0
 duplex auto
 speed auto
no shutdown
interface Serial0/0/1
 ip address 209.165.200.234 255.255.255.252
no shutdown
interface Loopback0
 ip address 172.30.110.1 255.255.255.0
interface Loopback1
 ip address 172.30.200.17 255.255.255.240
interface Loopback2
 ip address 172.30.200.33 255.255.255.240
!
router rip
passive-interface FastEthernet0/0
network 172.30.0.0
network 209.165.200.0
line con 0
line vty 0 4
login
!
end
```

Task 3: Examine the Current Status of the Network.

Step 1: Verify that both serial links are up.

The two serial links can quickly be verified using the **show** ip **interface brief** command on R2.

R2#show ip interface brief Interface IP-Address OK? Method Status Protocol FastEthernet0/0 10.1.0.1 YES manual up up FastEthernet0/1 unassigned YES manual administratively down down Serial0/0/0 209.165.200.229 YES manual up up Serial0/0/1 209.165.200.233 YES manual up up Vlan1 unassigned YES manual administratively down down

Step 2: Check the connectivity from R2 to the hosts on the R1 and R3 LANs.

Note: For the 1841 router, you will need to disable IP CEF to obtain the correct output from the ping command. Although a discussion of IP CEF is beyond the scope of this course, you may disable IP CEF by using the following command in global configuration mode:

```
R2(config) #no ip cef
```

From the R2 router, how many ICMP messages are successful when pinging PC1?

From the R2 router, how many ICMP messages are successful when pinging PC4?

Step 3: Check the connectivity between the PCs.

From the PC1, is it possible to ping PC2?
What is the success rate?
From the PC1, is it possible to ping PC3?
What is the success rate?
From the PC1, is it possible to ping PC4?
What is the success rate?
From the PC4, is it possible to ping PC2?
What is the success rate?
From the PC4, is it possible to ping PC3?
What is the success rate?

Step 4: View the routing table on R2.

Both the R1 and R3 are advertising routes to the 172.30.0.0/16 network; therefore, there are two entries for this network in the R2 routing table. The R2 routing table only shows the major classful network address of 172.30.0.0—it does not show any of the subnets for this network that are used on the LANs attached to R1 and R3. Because the routing metric is the same for both entries, the router alternates the routes that are used when forwarding packets that are destined for the 172.30.0.0/16 network.

R2#show ip route

```
Output omitted

10.0.0.0/16 is subnetted, 1 subnets
C 10.1.0.0 is directly connected, FastEthernet0/0
R 172.30.0.0/16 [120/1] via 209.165.200.230, 00:00:24, Serial0/0/0 [120/1] via 209.165.200.234, 00:00:15, Serial0/0/1 209.165.200.0/30 is subnetted, 2 subnets
C 209.165.200.228 is directly connected, Serial0/0/0 209.165.200.232 is directly connected, Serial0/0/1
```

Step 5: Examine the routing table on the R1 router.

Both R1 and R3 are configured with interfaces on a discontiguous network, 172.30.0.0. The 172.30.0.0 subnets are physically and logically divided by at least one other classful or major network—in this case, the two serial networks 209.165.200.228/30 and 209.165.200.232/30. Classful routing protocols like RIPv1 summarize networks at major network boundaries. Both R1 and R3 will be summarizing 172.30.0.0/24 subnets to 172.30.0.0/16. Because the route to 172.30.0.0/16 is directly connected, and because R1 does not have any specific routes for the 172.30.0.0 subnets on R3, packets destined for the R3 LANs will not be forwarded properly.

R1#show ip route

Output omitted

```
R 10.0.0.0/8 [120/1] via 209.165.200.229, 00:00:02, Serial0/0/0
172.30.0.0/24 is subnetted, 2 subnets
C 172.30.1.0 is directly connected, FastEthernet0/0
172.30.2.0 is directly connected, FastEthernet0/1
209.165.200.0/30 is subnetted, 2 subnets
C 209.165.200.228 is directly connected, Serial0/0/0
R 209.165.200.232 [120/1] via 209.165.200.229, 00:00:02, Serial0/0/0
```

Step 6: Examine the routing table on the R3 router.

R3 only shows its own subnets for 172.30.0.0 network: 172.30.100/24, 172.30.110/24, 172.30.200.16/28, and 172.30.200.32/28. R3 does not have any routes for the 172.30.0.0 subnets on R1.

```
R3#show ip route
```

Step 7: Examine the RIPv1 packets that are being received by R2.

Use the **debug** ip rip command to display RIP routing updates.

R2 is receiving the route 172.30.0.0, with 1 hop, from both R1 and R3. Because these are equal cost metrics, both routes are added to the R2 routing table. Because RIPv1 is a classful routing protocol, no subnet mask information is sent in the update.

R2 is sending only the routes for the 10.0.0.0 LAN and the two serial connections to R1 and R3. R1 and R3 are not receiving any information about the 172.30.0.0 subnet routes.

```
RIP: sending v1 update to 255.255.255.255 via Serial0/0/1 (209.165.200.233)

RIP: build update entries network 10.0.0.0 metric 1 network 209.165.200.228 metric 1

RIP: sending v1 update to 255.255.255.255 via Serial0/0/0 (209.165.200.229)
```

```
RIP: build update entries

network 10.0.0.0 metric 1

network 209.165.200.232 metric 1
```

When you are finished, turn off the debugging.

R2#undebug all

Task 4: Configure RIP Version 2.

Step 1: Use the version 2 command to enable RIP version 2 on each of the routers.

```
R2(config) #router rip
R2(config-router) #version 2
R1(config) #router rip
R1(config-router) #version 2
R3(config) #router rip
R3(config-router) #version 2
```

RIPv2 messages include the subnet mask in a field in the routing updates. This allows subnets and their masks to be included in the routing updates. However, by default RIPv2 summarizes networks at major network boundaries, just like RIPv1, except that the subnet mask is included in the update.

Step 2: Verify that RIPv2 is running on the routers.

The debug ip rip, show ip protocols, and show run commands can all be used to confirm that RIPv2 is running. The output of the show ip protocols command for R1 is shown below.

```
R1# show ip protocols
Routing Protocol is "rip"
Sending updates every 30 seconds, next due in 7 seconds
Invalid after 180 seconds, hold down 180, flushed after 240
Outgoing update filter list for all interfaces is not set
Incoming update filter list for all interfaces is not set
Redistributing: rip
Default version control: send version 2, receive 2
 Interface Send Recv Triggered RIP Key-chain
 FastEthernet0/0 2 2 FastEthernet0/1 2 2
 Serial0/0/0
                      2
Automatic network summarization is in effect
Maximum path: 4
Routing for Networks:
  172.30.0.0
   209.165.200.0
Passive Interface(s):
  FastEthernet0/0
  FastEthernet0/1
Routing Information Sources:
  Gateway Distance Last Update
   209.165.200.229 120
Distance: (default is 120)
```

Task 5: Examine the Automatic Summarization of Routes.

The LANs connected to R1 and R3 are still composed of discontiguous networks. R2 still shows two equal cost paths to the 172.30.0.0/16 network in the routing table. R2 still shows only the major classful network address of 172.30.0.0 and does not show any of the subnets for this network.

R2#show ip route

```
Output omitted

10.0.0.0/16 is subnetted, 1 subnets
C 10.1.0.0 is directly connected, FastEthernet0/0
R 172.30.0.0/16 [120/1] via 209.165.200.230, 00:00:07, Serial0/0/0 [120/1] via 209.165.200.234, 00:00:08, Serial0/0/1 209.165.200.0/30 is subnetted, 2 subnets
C 209.165.200.228 is directly connected, Serial0/0/0 209.165.200.232 is directly connected, Serial0/0/1
```

R1 still shows only its own subnets for the 172.30.0.0 network. R1 still does not have any routes for the 172.30.0.0 subnets on R3.

```
R1#show ip route
```

R3 still only shows its own subnets for the 172.30.0.0 network. R3 still does not have any routes for the 172.30.0.0 subnets on R1.

R3#show ip route

Use the output of the debug ip rip command to answer the following questions:
What entries are included in the RIP updates sent out from R3?

On R2, what routes are in the RIP updates that are received from R3?

R3 is not sending any of the 172.30.0.0 subnets—only the summarized route of 172.30.0.0/16, including the subnet mask. This is why R2 and R1 are not seeing the 172.30.0.0 subnets on R3.

Task 6: Disable Automatic Summarization.

The no auto-summary command is used to turn off automatic summarization in RIPv2. Disable auto summarization on all routers. The routers will no longer summarize routes at major network boundaries.

```
R2(config) #router rip
R2(config-router) #no auto-summary
R1(config) #router rip
R1(config-router) #no auto-summary
R3(config) #router rip
R3(config-router) #no auto-summary
```

The **show** ip **route** and **ping** commands can be used to verify that automatic summarization is off.

Task 7: Examine the Routing Tables.

The LANs connected to R1 and R3 should now be included in all three routing tables.

```
R2#show ip route

Output omitted

10.0.0.0/16 is subnetted, 1 subnets
C 10.1.0.0 is directly connected, FastEthernet0/0
172.30.0.0/16 is variably subnetted, 7 subnets, 3 masks
R 172.30.0.0/16 [120/1] via 209.165.200.230, 00:01:28, Serial0/0/0
[120/1] via 209.165.200.234, 00:01:56, Serial0/0/1
R 172.30.1.0/24 [120/1] via 209.165.200.230, 00:00:08, Serial0/0/0
```

```
172.30.2.0/24 [120/1] via 209.165.200.230, 00:00:08, Serial0/0/0
           172.30.100.0/24 [120/1] via 209.165.200.234, 00:00:08, Serial0/0/1
           172.30.110.0/24 [120/1] via 209.165.200.234, 00:00:08, Serial0/0/1
           172.30.200.16/28 [120/1] via 209.165.200.234, 00:00:08, Serial0/0/1
           172.30.200.32/28 [120/1] via 209.165.200.234, 00:00:08, Serial0/0/1
        209.165.200.0/30 is subnetted, 2 subnets
   С
           209.165.200.228 is directly connected, Serial0/0/0
           209.165.200.232 is directly connected, Serial0/0/1
   С
  R1#show ip route
   Output omitted
        10.0.0.0/8 is variably subnetted, 2 subnets, 2 masks
   R
           10.0.0.0/8 [120/1] via 209.165.200.229, 00:02:13, Serial0/0/0
           10.1.0.0/16 [120/1] via 209.165.200.229, 00:00:21, Serial0/0/0
   R
        172.30.0.0/16 is variably subnetted, 6 subnets, 2 masks
   C
           172.30.1.0/24 is directly connected, FastEthernet0/0
           172.30.2.0/24 is directly connected, FastEthernet0/1
           172.30.100.0/24 [120/2] via 209.165.200.229, 00:00:21, Serial0/0/0
           172.30.110.0/24 [120/2] via 209.165.200.229, 00:00:21, Serial0/0/0
           172.30.200.16/28 [120/2] via 209.165.200.229, 00:00:21, Serial0/0/0
           172.30.200.32/28 [120/2] via 209.165.200.229, 00:00:21, Serial0/0/0
        209.165.200.0/30 is subnetted, 2 subnets
   С
           209.165.200.228 is directly connected, Serial0/0/0
           209.165.200.232 [120/1] via 209.165.200.229, 00:00:21, Serial0/0/0
   R
  R3#show ip route
   Output omitted
        10.0.0.0/8 is variably subnetted, 2 subnets, 2 masks
   R
           10.0.0.0/8 [120/1] via 209.165.200.233, 00:02:28, Serial0/0/1
   R
           10.1.0.0/16 [120/1] via 209.165.200.233, 00:00:08, Serial0/0/1
        172.30.0.0/16 is variably subnetted, 6 subnets, 2 masks
           172.30.1.0/24 [120/2] via 209.165.200.233, 00:00:08, Serial0/0/1
           172.30.2.0/24 [120/2] via 209.165.200.233, 00:00:08, Serial0/0/1
   R
           172.30.100.0/24 is directly connected, FastEthernet0/0
           172.30.110.0/24 is directly connected, Loopback0
           172.30.200.16/28 is directly connected, Loopback1
           172.30.200.32/28 is directly connected, Loopback2
        209.165.200.0/30 is subnetted, 2 subnets
           209.165.200.228 [120/1] via 209.165.200.233, 00:00:08, Serial0/0/1
   R
   С
           209.165.200.232 is directly connected, Serial0/0/1
Use the output of the debug ip rip command to answer the following questions:
What entries are included in the RIP updates sent out from R1?
```

On R2, what routes are in the RIP updates that are received from R1?
Are the subnet masks now included in the routing updates?
Task 8: Verify Network Connectivity.
Step 1: Check connectivity between R2 router and PCs.
From R2, how many ICMP messages are successful when pinging PC1?
From R2, how many ICMP messages are successful when pinging PC4?
Step 2: Check the connectivity between the PCs.
From PC1, is it possible to ping PC2?
What is the success rate?
From PC1, is it possible to ping PC3?
What is the success rate?
From PC1, is it possible to ping PC4?
What is the success rate?
From PC4, is it possible to ping PC2?
What is the success rate?
From PC4, is it possible to ping PC3?
What is the success rate?

Task 9: Documentation

On each router, capture the following command output to a text (.txt) file and save for future reference.

- show running-config
- show ip route
- show ip interface brief
- show ip protocols

If you need to review the procedures for capturing command output, refer to Lab 1.5.1.

Task 10: Clean Up

Erase the configurations and reload the routers. Disconnect and store the cabling. For PC hosts that are normally connected to other networks (such as the school LAN or to the Internet), reconnect the appropriate cabling and restore the TCP/IP settings.