### ☐ fbarresi / Sharp7

Code Issues 3 Pull requests Discussions Actions Projects **Wiki** Security

# System information functions

### Jump to bottom

Federico Barresi edited this page on Jan 12, 2019 · 1 revision

these functions access to SZL (or SSL - System Status List) to give you all the same information that you can get from S7 Manager.

### **System Status List**

The system status list (SSL) describes the current status of a programmable logic controller.

The contents of the SSL can only be read using information functions but cannot be modified. The partial lists are virtual lists, in other words, they are only created by the operating system of the CPUs when specifically requested.

You can access to system status list using SFC 51 too "RDSYSST."

To read a partial list you must specify its ID and Index.

For a detailed description of SZL see: §33 of "System Software for S7-300/400 System and Standard Functions".

Function	Purpose
ReadSZL	Reads a partial list of given ID and Index
GetOrderCode	Returns the CPU order code
GetCpuInfo	Returns some information about the AG
GetCpInfo	Returns some information about the CP (communication processor)

### ReadSZL

### Description

Reads a partial list of given ID and INDEX.

### Declaration

```
public int ReadSZL(int ID, int Index, ref S7SZL SZL, ref int Size)
```

### **Parameters**

Name	Туре	Note
ID	int	List ID
Index	int	List Index
SZL	S7Szl	S7Szl structure
Size	int	Size Read in bytes

### S7SZL

```
[StructLayout(LayoutKind.Sequential, Pack = 1)]
public struct SZL_HEADER
{
    public UInt16 LENTHDR;
    public UInt16 N_DR;
};

[StructLayout(LayoutKind.Sequential, Pack = 1)]
public struct S7SZL
{
    public SZL_HEADER Header;
    [MarshalAs(UnmanagedType.ByValArray)]
    public byte[] Data;
};
```

Name	Туре	Meaning
LENTHDR	int	Length of a data record of the partial list in bytes
N_DR	int	Number of data records contained in the partial list

### Return value

- 0: The function was accomplished with no errors.
- Other values : see the Errors Code List.

### Remarks

Remember to allocate the Data[] buffer

## GetOrderCode

### Description

Gets CPU order code and version info.

### **Declaration**

```
public int GetOrderCode(S7OrderCode Info)
```

### **Parameters**

Name	Туре	Note
Info	S7OrderCode	see below

```
public struct S70rderCode
{
    public string Code;
    public byte V1; // Version 1st digit
    public byte V2; // Version 2nd digit
    public byte V3; // Version 3th digit
};
```

The Order code is a string like: "6ES7 151-8AB01-0AB0"

## GetCpuInfo

### Description

Gets CPU module name, serial number and other info.

### **Declaration**

```
public int GetCpuInfo(S7CpuInfo Info)
```

### **Parameters**

Name	Туре	Note
Info	S7CpuInfo	see below

```
public struct S7CpuInfo
{
    public string ModuleTypeName;
    public string SerialNumber;
    public string ASName;
```

```
public string Copyright;
public string ModuleName;
}
```

### Return value

- 0: The function was accomplished with no errors.
- Other values : see the Errors Code List.

## GetCpInfo

### Description

Gets CP (communication processor) info.

### **Declaration**

```
public int GetCpInfo(S7CpInfo Info)
```

### **Parameters**

Name	Туре	Note
Info	S7CpInfo	see below

```
public struct S7CpInfo
{
    public int MaxPduLength;
    public int MaxConnections;
    public int MaxMpiRate;
    public int MaxBusRate;
}
```

### Return value

- 0: The function was accomplished with no errors.
- Other values : see the Errors Code List.

```
▶ Pages 11
```

### Home

### **S7Client**

7/2021	Cystem intermation fariotions	iban con charp? With
Get connected		
I/O functions		
System Info functions		
PLC control functions		
Security functions		
Properties and info		
ErrorCodes		
S7Helper		
S7MultiVar		

## Clone this wiki locally

https://github.com/fbarresi/Sharp7.wiki.git