


Populife


Smart Keybox Max

———— User Guide ————




populife.co


Components Overview



Populife Smart
Keybox Max x 1



Protective
Cover x 1



Rubber mat x 1



Rubber ring x 4



Rubber stopper x 4



Screwdriver x 1




Battery cover
screw x 2



Self-tapping
screw x 4



Expansion
screw x 4




key x 2




Card x 2

Identification


Mode	K2 Max
Dimensions	196(H) x 75(W) x 52(T) mm
Material	Aluminum Alloy, Steel, Plastic, Silicon Rubber
Weight	1.38 pounds
Batteries	4 x AAA (Not included)
Unlock Methods	Bluetooth, PIN code, Fingerprint, IC Card, Key
Water & Dust Proof	IP 65
Working Temp	-13°F ~ 131°F



Identification




Battery Installation



Installation


Mount it on a surface



Rubber Ring


Reduces gaps around the screw holes when mounting the keybox on a wall, enhancing waterproof protection.

Side View



Installation

Hang it on the doorknob



Quick Start Guide

Factory mode

- ① Open the battery cover with the provided screwdriver and insert 4 AAA batteries as described on page 4. Alkaline batteries can provide better battery life.
- ② Touch the keypad to wake up the Keybox, enter the default passcode "123456" and end with " Ⓜ ". You will hear a voice prompt indicating the Keybox has been unlocked.

Read these notes before using

- ① Once paired with the Populife App, the default passcode becomes invalid. You can set your own Admin code during pairing. If you delete the lock from the App, the default passcode "123456" will be re-enabled.
- ② Whenever the Keybox is closed, it will automatically lock.
- ③ Install the "Populife" App via the App Store or Google Play. For direct download, simply scan the provided QR code. Start managing access easily with the Populife App.



How to Use

Pair the Keybox in App

On the Populife App homepage, tap the "+" button > Select "Keybox Max" > Follow the instructions to complete the pairing.

- ① Before pairing, ensure the default passcode "123456" unlocks the Keybox. If it does not, press and hold the Reset button (see page 4) until you hear a beep and a voice prompt. Then, enter "0000" and press "Ⓚ" to reset.
- ② Keep the Keybox open during pairing and ensure you have the provided key on hand. This will prevent any issues with unlocking the device later if the initialization fails due to a weak network connection.
- ③ If pairing fails, try restarting Bluetooth and internet connections on your phone, restart the Populife App, and attempt the pairing again.
- ④ If the Keybox was previously paired, ask the previous owner to delete it from their App. For new products, contact our customer service through the App with proof of purchase and the serial number.

Unlock by Populife App

Turn on Bluetooth, ensure the phone is close to the Keybox, and unlock the Keybox by tapping the "Unlock" button in the Populife App.

View Unlocking Records

You can view the Keybox access records and synchronize them to the App via Bluetooth when you are near the device. To view and synchronize the records, follow these steps: Lock page on Populife App > Select "History".

Sharing Bluetooth key

The lock owner can authorize other registered Populife users to unlock via Bluetooth keys: Lock page on Populife App > Select "Digital Key" > Tap "+" button > set a key and share it with Populife account or generate a link.

How to Use

Sharing Passcode

Administrators and authorized users can create 6-9 digit passcodes in the Populife App, which can then be shared with others by following these steps:

Lock page on Populife App > Select "PIN code" > Tap "+" button > Select code type > Configure and generate a code > Tap "Share" .

Note:

- ① You can generate time-sensitive random passcodes remotely on the App without requiring an internet connection for the Keybox.
- ② The Keybox can store up to 300 valid passcodes, including 150 random permanent and custom passcodes and 150 other types of random passcodes.

Register Fingerprint

The fingerprint registration process must be completed near the Keybox using the Populife App. To register a fingerprint, follow these steps: Lock page on the Populife App > Select "Fingerprint" > Tap "+" button. Follow the Populife App instructions to configure your fingerprint settings. Once you touch the keypad to wake up the Keybox Max, follow the guide to place your finger on the fingerprint scanner 4 times for successful registration.

Note:

- ① You can register up to 100 valid fingerprints
- ② Ensure you set up a passcode in case fingerprint registration fails.
- ③ If the same fingerprint is registered twice and both are still valid, the lockbox will keep the one with the longest validity period.
- ④ If a fingerprint has expired, it remains blocked and won't work with the lockbox. Delete it from the invalid list before re-adding it.

How to Use

IC Card Registration

The IC card registration process must be completed near the Keybox using the Populife App. To register an IC card, follow these steps:

Lock page on the Populife App > Select "Access Card" > Tap "+" button. Follow the App instructions to configure IC card settings.

Once you touch the keypad to wake up the Keybox, follow the guide to complete the registration by placing the IC card on the keybox.

Note:

- ① You can register up to 1000 valid IC cards.
- ② If your Android phone supports NFC card emulation, please refer to your phone's instructions to enable NFC for use as a virtual access card.

Decoy Code

You can enter up to 10 random digits before or after your passcode to protect it from being observed. For example, you can unlock it by entering 1231598765443345, where 876544 is the correct passcode.

The maximum length for one attempt is 16 digits.

Sound Settings

By default, voice guide reminders are enabled. On the unlock page, you can tap "Settings" to turn the sound on or off. If you disable the sound, both the keypad sounds and voice prompts will be muted.

Security Alarm

After 5 consecutive incorrect attempts with a passcode, fingerprint, or IC card, the keypad will emit 5 beeps and lock for 5 minutes. To unlock immediately, use Bluetooth in the Populife App or wait for 5 minutes before retrying.

How to Use

Remote Control via Gateway

If you've purchased Populife Smart Keybox, you can pair it with our Smart Gateway to remotely create custom passcodes, modify and delete existing passcodes, and view real-time unlocking records via the Populife App. Without the gateway, these functions will require Bluetooth proximity to the device.

Calibration Time

This feature allows you to sync the device's time to match your phone's time. To ensure that all time-sensitive passcodes function correctly, please calibrate the lock time after replacing the battery or periodically. To calibrate the lock time, follow these steps: Lock page on Populife App > "Settings" > Tap "Calibration time".

Battery Level

You can check the battery level on Populife App. The battery level updates only when you unlock the Keybox using the App or manually sync it in the "Settings" page.

Emergency Jump Start

For emergency power, there is a type-C power port at the bottom of the Keybox. Connect the type-C charging cable to the power port until you unlock with the Populife App or passcode. This port is for emergency use only and is not intended for regular charging.

