# *youBot Joypad Control*

Base motors on/off

Arm motors on/off

Gripper

Arm joint 1 and 2

Arm joint 5

Arm joint 2 and 3

Reconnect/recalibrate

Base translation

Base rotation

Deadman

Run

Arm cartesian mode

Print arm joint states

Must be in Position "D"