

 \vdash - - -

1-1/2" webbing at 36"

Insert webbing

into 1.5" male clip &

adjustment slider,

Then sew stitch as

close to adjustment

slider as possible

Opposite end is sewn between

front and back apron