Quick Links

↑ Forum Main Category Project Guidance Xbox Adaptive Controller with Teensy HID Joystick

Forum Actions

Forum Rule: Always post complete source code & details to reproduce any issue!

If this is your first visit, be sure to check out the **FAQ** by clicking the link above. You may have to **register** before you can post: click the register link above to proceed. To start viewing messages, select the forum that you want to visit from the selection below.

Results 1 to 5 of 5

Advanced Search

Thread: Xbox Adaptive Controller with Teensy HID Joystick

result.

New Posts FAQ Calendar Community

Thread Tools Search Thread Display #1 09-17-2018, 03:37 PM steve.mcgie o **Xbox Adaptive Controller with Teensy HID Joystick** Junior Member I've been playing around recently with Microsoft's new Join Date: Jan 2015 Xbox Adaptive Controller, which is meant to be like a Posts: 7 'modular' gaming controller for people with disabilities. One of the features on it is that you can plug one or two HID joysticks into it, and it interprets the X & Y axes of the joysticks as if they were the controller's thumbsticks. Plugging in a flight-sim joystick, a Logitech gamepad, or even a regular Xbox controller works fine with this. But

My theory on this is that the Adaptive Controller is looking for devices that appear -only- as a Joystick, and that the triple-purpose HID mode of the Teensy throws it off. Like it sees the Keyboard or Mouse components first, and decides that this can't possibly be a Joystick. Or something.

when I plugged in a Teensy 2.0 that was programmed in "Keyboard + Mouse + Joystick" mode, and didn't get any

Any thoughts or suggestions on how I might get this working? Thanks!

Reply With Quote

11-04-2018, 01:20 AM

#2

gdsports o

Member

Join Date: Jul 2018 Posts: 45 I have been looking at various Teensy USB projects as well but I do not have an adaptive controller. I do not know which approach is easiest.

- 1) Modify the files in hardware/teensy/avr/cores/usb_hid to create a joystick only driver.
- 2) For Teensy LC/3 there is a library that makes the Teensy looks like an Xbox 360 controller. No keyboard, no mouse, no raw HID, etc. just an XINPUT (xbox 360)

controller.

The original repo is https://github.com/zlittell/MSF-XINPUT but it is a bit stale. The fork https://github.com/dmadison/MSF-XINPUT works with Arduino IDE 1.8.7 and Teensyduino 1.44.

I used this on Teensy LC and Teensy 3.6 plugged into an Ubuntu 18.04 computer. Note this will not work with an Xbox console because real controllers have security chips. But I doubt this will be an issue since the adaptive controller is a authentic Xbox accessory.

Good luck!

Reply With Quote

Chris Veigl hello Steve, Junior Member Join Date: Oct 2018 Posts: 6 could you solve the issue? i ran into the same problem, see thread: https://forum.pjrc.com/threads/54227...implementation

steve.mcgie o

Junior Member
Join Date: Jan 2015
Posts: 7

Junior Member
Join Date: Jan 2015
Reply With Quote

gdsports • As far as I can tell, the XAC ignores the joystick buttons.

Member

Join Date: Jul 2018
Posts: 45

I found XAC has a Shift function so a single joystick can be swapped to the other joystick when the Shift key is held down.

https://support.xbox.com/en-US/xbox-...ive-controller

Reply With Quote

Quick Navigation Pr

Project Guidance

Тор

« Previous Thread | Next Thread »





All times are GMT. The time now is 07:58 PM.

Powered by vBulletin® Version 4.2.2 Copyright © 2021 vBulletin Solutions, Inc. All rights reserved. Web Hosting