| z/Bulletin <sup>®</sup> |           | User Name     | Password    | Log in | Help | Register       |  |
|-------------------------|-----------|---------------|-------------|--------|------|----------------|--|
|                         |           | Remembe       | er Me?      |        |      |                |  |
| What's New? Forum       | n         |               |             |        |      |                |  |
| New Posts FAO Calendar  | Community | Forum Actions | Ouick Links |        | Δ    | dvanced Search |  |

## ♠ Forum Main Category Technical Support & Questions

Horizontal scroll with Arduino Mouse library, Teensy LC, and Linux?

**Forum Rule**: Always post complete source code & details to reproduce any issue!

If this is your first visit, be sure to check out the **FAQ** by clicking the link above. You may have to **register** before you can post: click the register link above to proceed. To start viewing messages, select the forum that you want to visit from the selection below.

Results 1 to 3 of 3

# Thread: Horizontal scroll with Arduino Mouse library, Teensy LC, and Linux?

|  | Thread Tools Search Thread Display  |   |  |  |  |  |
|--|---|---|--|--|--|--|
| 08-28-2018, 12:47 PM                         | #   |   |  |  |  |  |
| Senior Member Join Date: Jul 2013 Posts: 123 | Horizontal scroll with Arduino Mouse library, Teensy LC, and Linux?  I built a keyboard with Teensy LC as the controller. The firmware is written with the Arduino 1.8.5 library and Teensyduino 1.42. I would like to issue horizontal scroll commands from the keyboard I use horizontal scroll on LibreOffice Calc spreadsheet on Linux. |   |  |  |  |  |
|  |   |   |  |  |  | What do I need to do, to add horizontal scroll to Arduino Mouse library for Teensy LC? Some of the following links are relevant. |
|  | https://www.arduino.cc/en/Reference/MouseMove The Arduino Mouse.move(x,y,wheel) function has a "wheel" parameter for vertical-scroll, but no parameter for horizontal-scroll.   |   |  |  |  |  |
|  | https://github.com/keyboardio/KeyboardioHID<br>Mouse (5 buttons, move, vertical wheel, horizontal whee  |   |  |  |  |  |
|  | https://github.com/Trass3r/TeensyCore<br>Mouse extra buttons & horizontal scroll on Teensy 2.0  |   |  |  |  |  |
|  | https://arduino.stackexchange.com/qul-horizontally Oc<br>30 '17<br>instructions to rewrite the ATmega32U4 core to provide<br>horizontal-scroll buttons 6 and 7  |   |  |  |  |  |
|  | https://forum.pjrc.com/threads/33017izontal-scroll 02-<br>10-2016   |   |  |  |  |  |
|  |   | https://forum.pjrc.com/threads/34472izontal+scroll 05-<br>10-2016<br>#1 Changes since Teensyduino 1.28: USB Mouse adds<br>horizontal scroll |  |  |  |  |

https://forum.pjrc.com/threads/45740...izontal+scroll 11-08-2017

page 2, #48 This should be able to recognize the scroll wheel on any mouse, and properly find horizontal scroll, if the mouse has it.

page 8, #176 > horizontal\_link

Last edited by wolfv; 08-28-2018 at 01:18 PM.

**Reply With Quote** 

08-28-2018, 02:07 PM

#2

# PaulStoffregen o

Senior Member



Join Date: Nov 2012 Posts: 23,188 Use Mouse.scroll(vertical, horizontal);

The 2nd parameter is optional and defaults to zero.

**Reply With Quote** 

08-28-2018, 03:49 PM

#3

#### wolfv o

Senior Member

Join Date: Jul 2013 Posts: 123 **Q** Originally Posted by **PaulStoffregen** 

Use Mouse.scroll(vertical, horizontal);

The 2nd parameter is optional and defaults to zero.

That's too easy Works great. Thank you!

Where is the Mouse.scroll() function documented? It's not listed in

https://www.arduino.cc/reference/en/...ons/usb/mouse/

This works:

## Code:

```
//for this to scroll, mouse pointer must be po:
#include <Mouse.h>
int count = 0;

void setup()
{
    delay(1000);
    Keyboard.print("start");

    while(count < 2)
    {
        delay(100);
        Mouse.scroll(1,1); //with mouse pointer in count++;
        Keyboard.print(count);
    }
    Keyboard.print("end ");
}</pre>
```

« Previous Thread | Next Thread »

Quick Navigation

**Technical Support & Questions** 

Тор



16/12/2020



All times are GMT. The time now is 06:57 PM.

Powered by vBulletin® Version 4.2.2 Copyright © 2020 vBulletin Solutions, Inc. All rights reserved.