CHE260

Thermodynamics and Heat Transfer

Michael Boyadjian

December 27, 2019

Contents

Ι	The	ermodynamics	4
1	Intr	coduction: Brief History of Thermodynamics	4
	1.1	First Law of Thermodynamics	4
	1.2	Second Law of Thermodynamics	4
2	Con	ncepts and Definitions	5
	2.1	Thermodynamic Systems	5
		2.1.1 Closed System	5
		2.1.2 Open System	5
		2.1.3 Isolated System	5
	2.2	Properties	5
	2.3	Equilibrium	5
		2.3.1 Mechanical Equilibrium	6
		2.3.2 Thermal Equilibrium	6
		2.3.3 Phase Equilibrium	6
	2.4	State and Processes	6
		2.4.1 Isothermal Process	6
		2.4.2 Isobaric Process	6
		2.4.3 Isochoric Process	6
		2.4.4 Adibiatic Process	6
3	The	ermodynamics System Properties	7
	3.1	Mass and Volume	7
	3.2	Pressure	7
	3.3	Ideal Gas Equation	7
	3.4	Modelling Ideal Gases	7
	3.5	Internal Energy	8
4	Ene	ergy and the First Law of Thermodynamics	9
	4.1	Energy	9
	4.2	Energy Transfer	9
	4.3	Heat	9
	4.4	Work	9
			10
		·	10
	4.5		10
	4.6		10
	4.7	10	11
	4.8		11

5	Ent	ropy	12
	5.1	A New Extensive Property: Entropy	12
	5.2	Second Law of Thermodynamics	12
	5.3	Reversible and Irreversible Processes	12
	5.4	Third Law of Thermodynamics	12
	5.5	Production of Entropy	13
6	The	Second Law of Thermodynamics	14
	6.1	Change in Entropy	14
	6.2	Isentropic Processes	14
	6.3	Control Mass Analysis	14
	6.4	Isentropic Efficiency	15
7	Phase Equilibrium		16
8	Ref	rigerators	17

Part I

Thermodynamics

1 Introduction: Brief History of Thermodynamics

1.1 First Law of Thermodynamics

States that energy cannot be created or destroyed. For the case of an engine:

$$Q_H = W + Q_C$$

It's efficiency is calculated using:

$$\eta_t h = \frac{W}{Q_H} = \frac{Q_H - Q_C}{Q_H} = 1 - \frac{Q_C}{Q_H}$$

1.2 Second Law of Thermodynamics

Clausius postulated that heat transfer makes another, previously undefined property of the engines increase by an amount $\frac{Q_H}{T_H}$. This property is called **entropy**. Adding or removing energy to any system in the form of heat changes its entropy.

The second law states that over a cycle, the net change in entropy of an engine must also be zero.

$$\Delta S = \frac{Q_H}{T_H} - \frac{Q_C}{T_C} = 0$$

2 Concepts and Definitions

2.1 Thermodynamic Systems

A **system** can be any piece of matter or space that we identify for purposes of analysis. The **surroundings** are everything outside the system and the **boundary** is what separates the system from its surroundings.

2.1.1 Closed System

- The amount of mass is fixed and no mass crosses the system boundary
- Energy in the form of heat or work can enter or leave the system
- Volume is not fixed and may be compressed or expanded

2.1.2 Open System

- Both energy and mass can cross the boundaries
- Boundaries may change in shape or move in space

2.1.3 Isolated System

- No mass or energy crosses the boundary
- The properties, once at equilibrium, will never change

2.2 Properties

A **property** of a system is any attribute that can be measured without knowing the history of the system.

- **Intensive** properties are those that can be specified at a point within the system and are independent of system mass. Examples would be *temperature* or *pressure*.
- Extensive properties depend on the size of the system. These include *mass*, *volume*, and *energy*.

Taking any extensive property and dividing it by the mass yields a new intensive property.

$$v = \frac{V}{m}$$
 $\rho = \frac{m}{V} = \frac{1}{v}$ $e = \frac{E}{m}$

2.3 Equilibrium

All physical systems that are left isolated will eventually reach a state of equilibrium where their properties do not change with time.

2.3.1 Mechanical Equilibrium

• Pressure in a system is the same everywhere

2.3.2 Thermal Equilibrium

• Temperature in a system is the same everywhere

2.3.3 Phase Equilibrium

• No more phase change within a system

2.4 State and Processes

A complete list of properties defines the state of the system. The change of a system from one state to another is called a process.

2.4.1 Isothermal Process

• Temperature of the system remains constant

2.4.2 Isobaric Process

• Pressure of the system remains constant

2.4.3 Isochoric Process

• Volume of the system remains constant

2.4.4 Adibiatic Process

- No heat is added or removed from the system
- A system whose boundaries are perfectly isolated will undergo this process

3 Thermodynamics System Properties

3.1 Mass and Volume

Mass and volume are the two most obvious ways to describe the quantity of a substance and the amount of space that it occupies. The mass of a molecule is known as its molar mass.

$$m = N \times mm$$

3.2 Pressure

A gas confined to a closed vessel exerts a force (F) on it due to gas molecules hitting the walls of the vessel and rebounding . This force, divided by the area (A) on which it is acting, is known as the gas pressure:

$$P = \frac{F}{A}$$

We can define the gas pressure or absolute pressure as:

$$P_{gas} = \rho gh + P_{atm} \qquad P_{abs} - P_{atm} = \rho gh$$

We can also define the gauge pressure as:

$$P_{gauge} = P_{abs} - P_{atm}$$

3.3 Ideal Gas Equation

By combining the Avogadro, Boyle, and Charles equations, we have been able to come up with the ideal gas equation:

$$PV = NR_{u}T$$

where R_u is known as the *universal gas constant*. It has been experimentally found to have the same value for all gases:

$$R_u = 8.314 \text{ kJ/mol}$$

We can use kilograms instead of mols in this equation, by using the relation m = NM, and we can also define a particular gas constant $R = \frac{R_u}{M}$.

$$PV = \frac{m}{M}R_uT$$
 $PV = mRT$

3.4 Modelling Ideal Gases

The kinetic theory of gases is based on several simplifying assumptions:

- 1. A gas is made of a very large number of elementary particles called molecules that are in constant, random motion. All molecules have the same mass
- 2. The total number of molecules is very large.

- 3. Molecules collide perfectly elastically with each other and with the walls of the container. They obey Newton's laws during collisions.
- 4. There is no force acting on molecules except during collisions.
- 5. The volume of molecules is negligible they are considered to be point masses.

3.5 Internal Energy

The internal energy (U) is the total energy of all the molecules in a substance. The internal energy is an extensive property with units of joules, given for a monoatomic, ideal gas by

$$U = \frac{3}{2}NR_uT$$

The internal energy of an ideal gases depends only on temperature. The change in specific internal energy of an ideal gas is

$$u_2 - u_1 = c(T_2 - T_1)$$

where c is the specific heat. For gases that do not behave ideally, or for liquids and solids, internal energy can, in general, depend on both pressure and temperature.

4 Energy and the First Law of Thermodynamics

4.1 Energy

Energy is an extensive property of all thermodynamic systems. A system possesses energy if it is capable of lifting a weight. Potential energy and kinetic energy are **macroscopic** forms of energy, and altering them requires a change in the position or velocity of the system. Internal energy includes all **microscopic** forms of energy storage. The total energy (E) of a system is the sum of its potential (PE), kinetic (KE) and internal (U) energies:

$$E = PE + KE + U$$

The specific energy is an intensive property and is the sum of its specific kinetic, potential and internal energies:

$$e = \frac{E}{m} = gz + \frac{1}{2}V^2 + u$$

4.2 Energy Transfer

Energy can be transferred to or from a system in two ways: as **work** or **heat**. Heat transfer is "an exchange of energy that occurs due to a temperature difference between a system and its surroundings". All other energy transfer is classified as work.

- Net heat is given by $Q_{net} = \sum_{i=1}^{n} Q_{i}$
- Net work is given by $W_{net} = \sum_{i=1}^{n} W_{i}$
- The rate of doing work, **power**, is given by $\dot{W} = \frac{\delta W}{dt}$
- Mechanical work done by a force F through an infinitesimal distance dx is $\delta W = F dx$
- The power expended in applying a force is $\dot{W} = \frac{\delta W}{dt} = F \frac{dx}{dt} = F \mathbf{V}$
- The rate of heat transfer, in watts, is given by $\dot{Q} = \frac{\delta Q}{dt}$

We can also talk about work or heat transfer per unit mass of a system:

$$w = \frac{W}{m} \qquad q = \frac{Q}{m}$$

4.3 Heat

Heat transfer is a mode of energy transport that occurs when a temperature difference exists. This occurs at the microscopic level with no macroscopic displacement. Heat conduction also occurs in all materials.

4.4 Work

Work is energy transfer across the boundary of a closed system in the absence of any temperature difference.

4.4.1 Boundary Work

Occurs when a force acts on the boundaries of a system and deforms them, either expanding or compressing the system.

For example, when a piston compresses a container, the work done would be

$$\delta W = Fdx = PAdx = -PdV$$

The work in compressing a gas from state 1 to state 2 in which the volume changes from V_1 to V_2 is given by

$$W_{12} = -\int_{V_1}^{V_2} P dV$$

- For constant volume: $W_{12} = -\int_{V_1}^{V_2} P dV = 0$
- For constant pressure: $W_{12} = -\int_{V_1}^{V_2} P dV = P(V_1 V_2)$
- For constant temperature: $W_{12} = -\int_{V_1}^{V_2} P dV = -\int_{V_1}^{V_2} \frac{mRT}{V} dV = -mRT \int_{V_1}^{V_2} \frac{dV}{V} = mRT \ln \frac{V_1}{V_2}$
- For a polytropic process: $W_{12} = -\int_{V_1}^{V_2} P dV = -C \int_{V_1}^{V_2} \frac{dV}{V^n}$

- If
$$n = 1$$
: $W_{12} = C \ln \frac{V_1}{V_2} = P_2 V_2 \ln \frac{V_1}{V_2}$

- If
$$n \neq 1$$
: $W_{12} = \frac{P_2 V_2 - P_1 V_1}{n-1}$

4.4.2 Flow Work

To drive a fluid into a control volume, a force must act a through a distance, which is known as flow work

$$W_{flow} = FL = PAL = PV$$

4.5 First Law of a Control Mass

We've discovered energy as an extensive property in all thermodynamics. We can combine the definition of heat transfer and work to give the first law of thermodynamics:

$$Q + W = \Delta E$$
 $\Delta E = \Delta U + \Delta P E + \Delta K E$ $\Delta E = E_{final} - E_{initial}$

4.6 Enthalpy

Enthalpy is the capacity of a fluid to do work. It is mathematically defined as

$$H = U + PV$$

4.7 Specific Heats of Ideal Gases

In order to relate internal energy (U) and enthalpy (H) to pressure (P), volume (V), and temperature (T), we define specific heat, which is "the amount of energy required to raise the temperature of a unit mass of a substance by one degree".

$$c_{avg} = \frac{Q}{m\Delta T} = \frac{q}{\Delta T}$$

Specific heat at a constant volume is defined as

$$C_v(T) = \left(\frac{\partial u}{\partial T}\right)_v$$

Specific heat at a constant pressure is defined as

$$C_p(T) = \left(\frac{\partial h}{\partial T}\right)_p$$

For an ideal gas,

$$c_p = c_v + R$$

4.8 Steady Mass Flow Through a Control Volume

The mass flow through a control volume is

$$\dot{m} = \frac{AV}{v}$$

At steady state,

$$\sum_i \dot{m}_i = \sum_e \dot{m}_i$$

The energy balance for a control volume at steady state is

$$\dot{Q} + \dot{W} = \dot{m} \left[(h_2 - h_1) + \frac{V_2^2 - V_1^2}{2} + g(z_2 - z_1) \right]$$

5 Entropy

5.1 A New Extensive Property: Entropy

Entropy is a property that measures the quality of heat and tells us how efficiently it can be transformed to work. This changes whenever heat is added or removed from a system.

$$Entropy\ Change = \frac{Heat\ Transferred}{Temperature\ Change}$$

Entropy and energy are related properties, but there is an important difference to note: energy is conserved, but entropy can be generated.

The change in entropy of a thermal reservoir being heated or cooled is

$$\Delta S = \frac{Q}{T}$$

5.2 Second Law of Thermodynamics

The second law of thermodynamics states that "The entropy of an isolated system will increase until the system reaches a state of equilibrium. The entropy of an isolated system in equilibrium remains constant". Stated mathematically:

 $dS_{isolated} > 0$ for an isolated system not in equilibrium

 $dS_{isolated} = 0$ for an isolated system in equilibrium

 $dS_{isolated} < 0$ not possible for an isolated system

5.3 Reversible and Irreversible Processes

A **reversible** process is one that can be reversed by an infinitesimal change in the surroundings so that both the system and surroundings are restored to their initial conditions

Processes that are both reversible and adiabatic produce no change in entropy and are called **isentropic** processes.

A reversible process generates no entropy while an irreversible process generates entropy.

 $S_{gen} = 0$ for a reversible process

 $S_{qen} > 0$ for an irreversible process

5.4 Third Law of Thermodynamics

The entropy of a pure substance in thermodynamic equilibrium is zero at a temperature of absolute zero.

5.5 Production of Entropy

Each individual distribution of molecules among available energy states, which satisfies the constraints imposed, is a microstate of the system. The macrostate of the system is defined by macroscopic properties such as energy and volume. The equilibrium macrostate of any system is the one that has the largest number of corresponding microstates. The molecular definition of entropy is

$$S = k \ln \Omega$$

If a system goes from an initial state with Ω_1 microstates to a final state with Ω_2 microstates, the change in entropy is

$$S = k \ln \frac{\Omega_1}{\Omega_2}$$

The entropy change for a monoatomic ideal gas is

$$\Delta S = NR_u \left[\ln \frac{V_2}{V_1} + \frac{3}{2} \ln \frac{T_2}{T_1} \right] = mR \left[\ln \frac{V_2}{V_1} + \frac{3}{2} \ln \frac{T_2}{T_1} \right]$$

6 The Second Law of Thermodynamics

6.1 Change in Entropy

For incompressible liquids and solids, the change in entropy is:

$$\Delta s = s_2 - s_1 = c_{avg} \ln \frac{T_2}{T_1}$$

For ideal gases with constant specific heats, the change in entropy is:

$$\Delta s = s_2 - s_1 = c_v \ln \frac{T_2}{T_1} + R \ln \frac{v_2}{v_1}$$

$$\Delta s = s_2 - s_1 = c_v \ln \frac{P_2}{P_1} + c_p \ln \frac{v_2}{v_1}$$

$$\Delta s = s_2 - s_1 = c_v \ln \frac{T_2}{T_1} + R \ln \frac{P_2}{P_1}$$

6.2 Isentropic Processes

Remember that an isentropic process is one that is both adiabatic and reversible. For an ideal gas undergoing an isentropic process:

$$\frac{T_2}{T_1} = \left(\frac{v_1}{v_2}\right)^{\gamma - 1} \qquad \frac{T_2}{T_1} = \left(\frac{P_2}{P_1}\right)^{\frac{\gamma - 1}{\gamma}} \qquad \frac{P_2}{P_1} = \left(\frac{v_1}{v_2}\right)^{\gamma}$$

$$Pv^{\gamma} = constant$$

6.3 Control Mass Analysis

For a control mass at a constant temperature (T):

$$\Delta S = \frac{Q_{12}}{T}$$

The entropy balance for a control mass is

$$\Delta S = S_{in} - S_{out} + S_{gen}$$

For an isentropic system at steady state:

$$s_2 = s_1$$

6.4 Isentropic Efficiency

For a turbine:

$$\eta_t = \frac{w_t}{w_{t,s}} = \frac{h_2 - h_1}{h_{2s} - h_1}$$

For a nozzle:

$$\eta_{nozzle} = \frac{V_2^2}{V_{2s}^2}$$

For a compressor or pump:

$$\eta_c = \frac{w_{c,s}}{w_s} = \frac{h_{2s} - h_1}{h_s - h_1}$$

7 Phase Equilibrium

The quality of a liquid-vapour mixture is defined as

$$x = \frac{\text{mass of vapour}}{\text{mass of mixture}} = \frac{m_g}{m}$$

By knowing this, we can find the properties of specific volume, specific internal energy, specific enthalpy, and specific entropy

$$v = xv_g + (1 - x)v_f$$

$$u = xu_g + (1 - x)u_f$$

$$h = xh_g + (1 - x)h_f$$

$$s = xs_g + (1 - x)s_f$$

8 Refrigerators

The thermal efficiency of a heat engine is given as

$$\eta_{th} = \frac{\text{net work output}}{\text{heat input}} = \frac{W_{net}}{Q_{in}}$$

The thermal efficiency of a **Carnot** engine is:

$$\eta_{th,carnot} = 1 - \frac{Q_C}{Q_H} = 1 - \frac{T_C}{T_H}$$

The Carnot principles state the following:

- 1. The efficiency of a reversible heat engine is always greater than that of an irreversible engine operating between the same two temperatures.
- 2. The efficiencies of all reversible heat engines operating between the same two temperatures are the same.