IQRF USB Drivers

Installation guide







Content

IQRF USB devices and drivers	3
WinUSB driver	3
MPUSB driver	3
Installation package	3
IQRF WinUSB driver installation	4
Windows 7, Windows 8, Windows 8.1 and Windows 10	4
Windows Vista	12
IQRF MPUSB driver installation	19
Windows Vista, Windows 7, Windows 8 (32 b), Windows 8.1 (32 b) and Windows 10 (32 b)	19
Windows 8 (64 b), Windows 8.1 (64 b) and Windows 10 (64 b)	25
Troubleshhoting	32
Windows XP	44
Assigning the CDC class driver	48
Assigning the Custom class driver	51
Migration between MPUSB and WinUSB	54
Migration from MPUSB to WinUSB	54
Migration from WinUSB to MPUSB	58
Document revision	59



IQRF USB devices and drivers

IQRF devices with USB connectivity utilizes **Custom class** with **VID / PID by MICRORISC**. Additionally, several of them supports also **CDC class**.

WinUSB driver

USB driver by verified publisher based on the WinUSB by Microsoft is available for the following IQRF devices:

IQRF USB device	Minimal FW version
CK-USB-02	2.0
CK-USB-04	1.04
CK-USB-04A	1.11
GW-USB-04	1.20
GW-USB-05	1.04
GW-GSM-02A	3.03
GW-WIFI-01	0.49
GW-ETH-02A	2.66

MPUSB driver

USB driver **by not verified publisher** based on the **MPUSB** by Microchip is available for all IQRF USB devices (with any FW versions).

Installation package

This package is not necessary when using IQRF IDE development environment. USB drivers are installed within the IQRF IDE installation procedure in this case.

The installation package is intended for:

- Custom and CDC classes, selectable during the installation
- All IQRF USB devices
- All IQRF IDE versions
- Operating systems Windows Vista, Windows 7, Windows 8, Windows 8.1 and Windows 10. The MPUSB driver is also applicable on Windows XP.

The contents of the installation package:

For Windows Vista, Windows 7, Windows 8, Windows 8.1

and Windows 10.

For Windows XP, Vista, Windows 7, Windows 8, Windows

8.1 and Windows 10.

For using the WinUSB driver, the <code>IQRF_WinUSB_drivers_setup.exe</code> or <code>IQRF IDE 4.30</code> or higher must be installed.

For using the MPUSB driver, the <code>IQRF_MPUSB_drivers_setup.exe</code> or <code>IQRF IDE 4.23</code> or lower must be installed.



IQRF WinUSB driver installation


Windows 7, Windows 8, Windows 8.1 and Windows 10

Before installation, do not get any IQRF USB device connected.

- 1. Invoke the installer (IQRF_WinUSB_drivers_setup_yymmdd.exe)
- 2. Follow the instructions





3. Allow to install drivers from verified publisher






4. Continue installing











5. Select which drivers to install (Custom and/or CDC)






6. Installing of selected drivers




7. CDC driver (if requested) installing





8. Custom driver (if requested) installing




9. Finish the installation








10. After successful installation connect IQRF USB device. The drivers should be indicated in Windows device manager, e.g. as follows:






All the following steps are valid for Windows 8, 8.1 and 10 only.

11. If the following setup appears, continue to points 12. and 13.





12. Uninstall the driver using *Uninstall* in pop-up menu invoked in Windows Device manager:



Then confirm the uninstallation.



13. Disconnect and then reconnect the USB device. Successful installation result should correspond to point 10. above.




Windows Vista

Before installation, do not get any IQRF USB device connected.

Before installation, you should have updated your Windows operating system for all available updates.

To check the updates, open *Control Panel\Programs\Programs and Features -> Installed Updates*. It is not necessary for Windows Vista SP2 or higher.



If the updates are missing, install them from www.microsoft.com.





- 1. Invoke the installer (IQRF_WinUSB_drivers_setup_yymmdd.exe)
- 2. Follow the instructions





3. Allow to install drivers from verified publisher






4. Continue installing











5. Select which drivers to install (Custom and/or CDC)






6. Installing of selected drivers





7. CDC driver (if requested) installing





8. Custom driver (if requested) installing Finish the installation










After successful installation connect IQRF USB device. The drivers should be indicated in Windows device manager, e.g. as follows:






IQRF MPUSB driver installation


Windows Vista, Windows 7, Windows 8 (32 b), Windows 8.1 (32 b) and Windows 10 (32 b)

Before installation, do not get any IQRF USB device connected.

- 1. Invoke the installer (IQRF_MPUSB_drivers_setup_yymmdd.exe)
- 2. Follow the instructions




3. Allow to install drivers from verified publisher






4. Continue installing












5. Select which drivers to install (Custom and/or CDC)






6. CDC class driver installing (if requested, otherwise go to point 8)








7. Confirm installing the driver from unknown publisher



8. Custom class driver installation (if requested, otherwise go to point 10)





9. Confirm installing the driver from unknown publisher



10. Finish the installation



After connecting an IQRF USB device the driver is assigned automatically.




Windows 8 (64 b), Windows 8.1 (64 b) and Windows 10 (64 b)

Before installation, do not get any IQRF USB device connected.

- 1. Invoke the installer (IQRF_MPUSB_drivers_setup_yymmdd.exe)
- 2. Follow the instructions



3. Allow to install drivers from verified publisher





4. Windows 8, 8.1 or 10 (64b) detected. Thus, Windows must be restarted now.




Save data in your other programs possibly running and then confirm OK.


If UEFI Boot mode is detected (see the screenshot below), the drivers can not be installed automatically. In this case, after installation is completed, go to chapter *Troubleshooting* below.

OK

Cancel




5. After restarting, wait until Windows is switched from the metro to the desktop mode and installation continues (Setup).






6. Continue installing








7. Select which drivers to install (Custom and/or CDC)









8. CDC class driver installing (if requested, otherwise go to point 10)








9. Confirm installing the driver from unknown publisher



10. Custom class driver installation (if requested, otherwise go to point 12)






11. Confirm installing the driver from unknown publisher



12. Finish the installation and restart the computer.



After connecting an IQRF USB device the driver is assigned automatically.



Troubleshhoting

When automatical installation of drivers on 64 b Windows 8, 8.1 or 10 failed (e.g. in UEFI Boot mode), the following procedure should be done to install the drivers manually.

I. How to enable installation of not signed driver

Windows 8:

- 1. Change PC Settings (hotkeys Win+I) Fig. 1, Fig.2
- 2. General → Advanced startup → Restart now Fig. Win8_5
- 3. Troubleshoot Fig. 6
- 4. Advanced Options Fig. 7
- 5. Startup settings Fig. 8
- 6. Restart Fig. 9
- 7. Disable driver signature enforcement (hotkey F7) Fig. 10

Windows 8.1:

- 1. Change PC Settings (hotkeys Win+I) Fig. 1, Fig. 2
- 2. Update and recovery Fig. Win8.1_3
- 3. Recovery Fig. Win8.1 4
- 4. Advanced startup → Restart now Fig. Win8.1_5
- 5. Troubleshoot Fig. 6
- 6. Advanced Options Fig. 7
- 7. Startup settings Fig. 8
- 8. Restart Fig. 9
- 9. Disable driver signature enforcement (hotkey F7) Fig. 10

Windows 10:

- 1. Change PC Settings (hotkeys Win+I) Fig. Win10_1,
- 2. Update and recovery Fig. Win10 1
- 3. Recovery Fig. Win10 2
- 4. Advanced startup → Restart now Fig. Win10._2
- 5. Troubleshoot Fig. 6
- 6. Advanced Options Fig. 7
- 7. Startup settings Fig. 8
- 8. Restart Fig. 9
- 9. Disable driver signature enforcement (hotkey F7) Fig. 10










Fig. 2




Fig. Win10_1








Fig 8.1_4

Fig. Win 8.1_3




Fig. Win 10_2



IQRF USB drivers




Fig. Win 8_5





Fig. Win 8.1_5








Fig. 6 Fig. 7




Fig. 8



Startup Settings

Restart to change Windows options such as:

- · Enable low-resolution video mode
- · Enable debugging mode
- · Enable boot logging
- Enable Safe Mode
- · Disable driver signature enforcement
- · Disable early-launch anti-malware protection
- · Disable automatic restart on system failure

Restart

Fig. 9

Startup Settings

Press a number to choose from the options below:

Use number keys or functions keys F1-F9

- 1) Enable debugging
- 2) Enable boot logging
- 3) Enable low-resolution video
- 4) Enable Safe Mode
- 5) Enable Safe Mode with Networking
- 6) Enable Safe Mode with Command Prompt
- 7) Disable driver signature enforcement
- 8) Disable early launch anti-malware protection
- 9) Disable automatic restart after failure

Press F10 for more options

Press Enter to return to your operating system

Fig. 10





II. Custom driver installation (Windows 8, Windows 8.1 and Windows 10)

- 1. Connect IQRF USB device
- 2. Windows Device manager (hotkeys Win+X) Fig. 11
- 3. Other device → Unknown device → Update Driver Software Fig. 12
- 4. Browse my computer for driver software Fig. 13
- 5. Setup the path to subdirectory USB Drivers
 - under the directory where IQRF IDE is installed Fig. 14 when installing within the IQRF IDE installation (from IQRF iqrf ide 4xx setup yymmdd.exe file)
 - under directory c:\Program Files\IQRF driver\ (or to another location specified by the user during the installation) when installing from IQRF MPUSB drivers setup yymmdd.exe file.
- 6. Install this driver software anyway Fig. 15
- 7. All is O.K. notice Fig. 16

III. CDC driver installation (Windows 8, Windows 8.1 and Windows 10)

- 1. Launch IQRF IDE, menu Tools → USB Classes → Switch to CDC mode → Yes Fig. 17, Fig.18
- 2. Windows Device manager (hotkeys Win+X) Fig. 11
- 3. Other device → Unknown device → Update Driver Software Fig. 12
- 4. Browse my computer for driver software Fig. 13
- 5. Setup the path to subdirectory USB Drivers
 - under the directory where IQRF IDE is installed Fig. 14 when installing within the IQRF IDE installation (from IQRF iqrf_ide_4xx_setup_yymmdd.exe file)
 - under directory c:\Program Files\IQRF driver\ (or to another location specified by the user during the installation) when installing from IQRF MPUSB drivers setup yymmdd.exe file.
- 6. Install this driver software anyway Fig. 15
- 7. All is O.K. notice Fig. 19








Fig. 11 Fig. 12






Fig. 13




Fig. 14








Fig. 15




Fig. 16



IQRF USB drivers




Fig. 17




Fig. 18







Fig. 19



Windows XP


Before installation, do not get any IQRF USB device connected.


- 1. Invoke the installer (IQRF_MPUSB_drivers_setup_yymmdd.exe)
- 2. Follow the instructions














3. Select which drivers to install (Custom and/or CDC)




4. Confirm installing





5. Finish the installation



After connecting an IQRF USB device, the driver must be assigned manually:





Assigning the CDC class driver



















Assigning the Custom class driver


















Migration between MPUSB and WinUSB

The Windows operating system stores the driver setup for every USB device and for every USB port plug at given computer. Therefore:

- If both WinUSB and MPUSB dirvers are requested to operate at the same time, the procedure described below has to be repeated by connecting the USB device successively in every USB port plug.
- If just one of USB drivers is requested, the uninstallation should be simply completed by removing the old driver (*Uninstall* using the pop-up menu). Then Windows will perform setup of other USB plugs automatically.

Migration from MPUSB to WinUSB

The following procedure is applicable to Custom device as well as CDC device (COMx).

- 1. Invoke Windows Device manager, e.g. from IQRF IDE menu Tools
- 2. Select IQRF USB Device and (using the pop-up menu) Update Driver Software




Fig. 21



3. Browse the driver manually




Fig. 22

4. Select the driver from the list




Fig. 23



IQRF USB drivers

5. If WinUSB driver is already installed, select the signed IQRF USB Device (with icon 📮) and go to point 9.




Fig. 24

If WinUSB driver is not installed, continue with points 6 to 8.

6. Select the Have Disk button




Fig. 25



7. Use the Browse button and navigate to the driver




Fig. 26

- 8. Setup the path to subdirectory USB Drivers
 - under the directory where IQRF IDE is installed when installing within the IQRF IDE installation (from iqrf ide 4xx setup yymmdd.exe file)
 - under directory c:\Program Files\IQRF driver\ (or to another location specified by the user during the installation) when installing from IQRF WinUSB drivers setup yymmdd.exe file.
- 9. Successfull update is indicated as follows:




Fig. 27

It is recommended to disconnect and then reconnect the IQRF USB device and (when requested) to perform Windows reset.




Migration from WinUSB to MPUSB

Because of an unsigned driver is to be installed, it is necessary to follow the procedure in chapter *Troubleshooting* first.

Then the following procedure is applicable to Custom device as well as CDC device (COMx).

- 1. Invoke Windows Device manager, e.g. from IQRF IDE menu Tools.
- 2. Select IQRF USB device and (using the pop-up menu) Update Driver Software Fig. 21.
- 3. Browse the driver manually Fig. 22.
- 4. Select the driver from the list Fig.23.
- 5. If MPUSB driver is already installed, select the unsigned *IQRF USB Device* and go to point 9 Fig.24. If MPUSB driver is not installed, continue with points 6 to 8.
- 6. Select the Have Disk button.



- 7. Use the *Browse* button and navigate to the driver Fig. 26.
- 8. Setup the path to subdirectory USB Drivers
 - under the directory where IQRF IDE is installed when installing within the IQRF IDE installation (from iqrf ide 4xx setup yymmdd.exe file).
 - under directory c:\Program Files\IQRF driver\ (or to another location specified by the user during the installation) when installing from IQRF_MPUSB_drivers_setup_yymmdd.exe file.
- 9. Successfull update is indicated as on Fig. 27.

It is recommended to disconnect and then reconnect the IQRF USB device and (when requested) to perform Windows reset.





Document revision

•	170810	Page Sales and Service updated.
---	--------	---------------------------------

- 150812 Updated for WinUSB driver 1.07. Chapter *Migration between MPUSB and WinUSB* added. Windows 10 non-beta.
- 150319 Updated for WinUSB driver (by verified publisher) and for Windows 8.1 and Windows 10 beta.
- 121210 First release, for MPUSB driver, by not verified publisher



Sales and Service

Corporate office

IQRF Tech s.r.o., Prumyslova 1275, 506 01 Jicin, Czech Republic, EU

Tel: +420 493 538 125, Fax: +420 493 538 126, www.iqrf.tech

E-mail (commercial matters): sales@iqrf.org

Technology and development

www.iqrf.org

E-mail (technical matters): support@iqrf.org

Partners and distribution

www.iqrf.org/partners

Quality management

ISO 9001: 2009 certified

Trademarks

The IQRF name and logo are registered trademarks of IQRF Tech s.r.o.

PIC, SPI, Microchip and all other trademarks mentioned herein are property of their respective owners.

Legal

All information contained in this publication is intended through suggestion only and may be superseded by updates without prior notice. No representation or warranty is given and no liability is assumed by IQRF Tech s.r.o. with respect to the accuracy or use of such information.

Without written permission it is not allowed to copy or reproduce this information, even partially.

No licenses are conveyed, implicitly or otherwise, under any intellectual property rights.

The IQRF ® products utilize several patents (CZ, EU, US)

On-line support: support@iqrf.org

