## Betjeningspanel - ledOnOff: int - ledMan: int - ledWifi: int - butOnOff: int - \_butMan: int - gpioExport(int): void - gpioUnexport(int): void + setLedValue(): void + getButValue(): int + getWifi(): int

**I2Csocket** 

+ recvMsg(int): void + sendMsg(int): void

Emailserver	
-memberName	_
-memberName	

Website	
-memberName	
-memberName	