
Speed estimator of the 3-ph induction motor

Description

This software module implements a speed estimator of the 3-ph induction motor based upon its mathematics model. The estimator's accuracy relies heavily on knowledge of critical motor parameters.



Availability

This IQ module is available in one interface:

1) The C interface version

Module Properties

Type: Target Independent, Application Dependent

Target Devices: 28x Fixed Point or Piccolo

C Version File Names: aci_se.h

IQmath library files for C: IQmathLib.h, IQmath.lib

C Interface

Object Definition

The structure of ACISE object is defined by following structure definition

```
typedef struct { _iq IQsS;
                                        // Input: Stationary q-axis stator current
               _iq PsiDrS;
                                        // Input: Stationary d-axis rotor flux
                                        // Input: Stationary d-axis stator current
               _iq IDsS;
                                        // Input: Stationary q-axis rotor flux
               _iq PsiQrS;
                                        // Parameter: Constant using in speed computation
               ig K1;
              _iq SquaredPsi;
                                        // Variable: Squared rotor flux
                                        // Input: Rotor flux angle
              _iq ThetaFlux;
              _iq21 K2;
                                        // Parameter: Constant using in differentiator (Q21)
                                        // Variable: Previous rotor flux angle
              _iq OldThetaFlux;
                                        // Parameter: Constant using in low-pass filter
              _iq K3;
                                        // Variable: Synchronous rotor flux speed in pu (Q21)
              _iq21 WPsi;
              _iq K4;
                                        // Parameter: Constant using in low-pass filter
              _iq WrHat;
                                        // Output: Estimated speed in per unit
              Uint32 BaseRpm;
                                        // Parameter: Base rpm speed (Q0)
                                        // Output: Estimated speed in rpm (Q0)
              int32 WrHatRpm;
           } ACISE;
```

typedef ACISE *ACISE_handle;

Module Terminal Variables

| Item | Name | Description | Format [*] | Range(Hex) |
|-----------|--------------|-----------------------------------|---------------------|------------------|
| Inputs | PsiDrS | stationary d-axis rotor flux | GLOBAL_Q | 80000000-7FFFFFF |
| | PsiDrS | stationary q-axis rotor flux | GLOBAL_Q | 80000000-7FFFFFF |
| | ThetaFlux | rotor flux linkage angle | GLOBAL_Q | 00000000-7FFFFFF |
| | | | | (0 – 360 degree) |
| | IDsS | stationary d-axis stator current | GLOBAL_Q | 80000000-7FFFFFF |
| | IQsS | stationary q-axis stator current | GLOBAL_Q | 80000000-7FFFFFF |
| Outputs | WrHat | estimated rotor speed | GLOBAL_Q | 80000000-7FFFFFF |
| | WrHatRpm | estimated rotor speed in rpm | Q0 | 80000000-7FFFFFF |
| ACISE | K1 | K1 = 1/(Wb*Tr) | GLOBAL_Q | 80000000-7FFFFFF |
| parameter | K2 | K2 = 1/(fb*T) | Q21 | 80000000-7FFFFFF |
| | K3 | K3 = Tau/(Tau+T) | GLOBAL_Q | 80000000-7FFFFFF |
| | K4 | K4 = T/(Tau+T) | GLOBAL_Q | 80000000-7FFFFFF |
| | BaseRpm | base speed in rpm | Q0 | 80000000-7FFFFFF |
| Internal | OldThetaFlux | previous rotor flux linkage angle | GLOBAL_Q | 00000000-7FFFFFF |
| | | | | (0 - 360 degree) |
| | WPsi | synchronous speed | GLOBAL_Q | 80000000-7FFFFFF |
| | SquaredPsi | squared magnitude of rotor flux | GLOBAL_Q | 80000000-7FFFFFF |

GLOBAL_Q valued between 1 and 30 is defined in the IQmathLib.h header file.

Special Constants and Data types

ACISE

The module definition is created as a data type. This makes it convenient to instance an interface to the speed estimator of Induction Motor module. To create multiple instances of the module simply declare variables of type ACISE.

ACISE handle

User defined Data type of pointer to ACISE module

ACISE DEFAULTS

Structure symbolic constant to initialize ACISE module. This provides the initial values to the terminal variables as well as method pointers.

Methods

ACISE_MACRO(ACISE_handle);

This definition implements one method viz., the speed estimator of Induction Motor computation macro. The input argument to this macro is the module handle.

Module Usage

Instantiation

The following example instances two ACISE objects ACISE se1, se2:

Initialization

```
To Instance pre-initialized objects
ACISE se1 = ACISE_DEFAULTS;
ACISE se2 = ACISE_DEFAULTS;
```

Invoking the computation macro

```
ACISE_MACRO(se1);
ACISE_MACRO(se2);
```

Example

The following pseudo code provides the information about the module usage.

```
main()
       se1.K1 = parem1_1;
                                             // Pass parameters to se1
       se1.K2 = parem1 2;
                                             // Pass parameters to se1
       se1.K3 = parem1 3;
                                             // Pass parameters to se1
       se1.K4 = parem1 4;
                                             // Pass parameters to se1
       se1.BaseRpm = base speed 1;
                                             // Pass parameters to se1
                                             // Pass parameters to se2
       se2.K1 = parem2 1;
       se2.K2 = parem2 2;
                                             // Pass parameters to se2
       se2.K3 = parem2 3;
                                             // Pass parameters to se2
       se2.K4 = parem2 4;
                                             // Pass parameters to se2
       se2.BaseRpm = base_speed_2;
                                             // Pass parameters to se2
}
```

```
void interrupt periodic_interrupt_isr()
       se1.PsiDrS= flux_dq1.d;
                                              // Pass inputs to se1
                                              // Pass inputs to se1
       se1.PsiQrS= flux_dq1.q;
       se1.IDsS=current_dq1.d;
                                              // Pass inputs to se1
       se1.IQsS=current_dq1.q;
                                              // Pass inputs to se1
                                              // Pass inputs to se1
       se1.ThetaFlux=angle1;
       se2.PsiDrS= flux_dq2.d;
                                              // Pass inputs to se2
                                              // Pass inputs to se2
       se2.PsiQrS= flux_dq2.q;
                                              // Pass inputs to se2
       se2.IDsS=current_dq2.d;
                                              // Pass inputs to se2
       se2.IQsS=current_dq2.q;
       se2.ThetaFlux=angle2;
                                              // Pass inputs to se2
       ACISE_MACRO(se1);
                                              // Call compute macro for se1
       ACISE_MACRO(se2);
                                              // Call compute macro for se2
       speed_pu1 = se1.WrHat;
                                              // Access the outputs of se1
                                              // Access the outputs of se1
       speed_rpm1 = se1.WrHatRpm;
       speed pu2 = se2.WrHat;
                                              // Access the outputs of se2
                                              // Access the outputs of se2
       speed_rpm2 = se2.WrHatRpm;
}
```

Constant Computation Macro

Since the speed estimator of Induction motor module requires four constants (K1,..., K4) to be input basing on the machine parameters, base quantities, mechanical parameters, and sampling period. These four constants can be internally computed by the macro (aci_se_const.h). The followings show how to use the constant computation macro.

Object Definition

The structure of ACISE_CONST object is defined by following structure definition

```
typedef struct { float32 Rr;
                                // Input: Rotor resistance (ohm)
                                 // Input: Rotor inductance (H)
                 float32 Lr;
                                // Input: Base electrical frequency (Hz)
                 float32 fb;
                 float32 fc;
                                // Input: Cut-off frequency of low-pass filter (Hz)
                 float32 Ts;
                                // Input: Sampling period in sec
                 float32 K1;
                                // Output: constant using in rotor flux calculation
                 float32 K2;
                                // Output: constant using in rotor flux calculation
                 float32 K3;
                                 // Output: constant using in rotor flux calculation
                 float32 K4;
                                // Output: constant using in stator current calculation
                } ACISE_CONST;
```

typedef ACISE_CONST *ACISE_CONST_handle;

Module Terminal Variables

| Item | Name | Description | Format | Range(Hex) |
|---------|------|---|----------|------------|
| Inputs | Rr | Rotor resistance (ohm) | Floating | N/A |
| _ | Lr | Rotor inductance (H) | Floating | N/A |
| | fb | Base electrical frequency (Hz) | Floating | N/A |
| | fc | Cut-off frequency of low-pass filter (Hz) | Floating | N/A |
| | Ts | Sampling period (sec) | Floating | N/A |
| Outputs | K1 | constant using in rotor flux calculation | Floating | N/A |
| - | K2 | constant using in rotor flux calculation | Floating | N/A |
| | K3 | constant using in rotor flux calculation | Floating | N/A |
| | K4 | constant using in stator current cal. | Floating | N/A |

Special Constants and Data types

ACISE CONST

The module definition is created as a data type. This makes it convenient to instance an interface to the speed estimation of Induction Motor constant computation module. To create multiple instances of the module simply declare variables of type ACISE_CONST.

ACISE CONST handle

User defined Data type of pointer to ACISE CONST module

ACISE CONST DEFAULTS

Structure symbolic constant to initialize ACISE_CONST module. This provides the initial values to the terminal variables as well as method pointers.

Methods

ACISE_CONST_MACRO(ACISE_CONST_handle);

This definition implements one method viz., the speed estimator of Induction Motor constant computation macro. The input argument to this macro is the module handle.

Module Usage

Instantiation

The following example instances two ACISE_CONST objects ACISE_CONST se1_const, se2_const;

Initialization

To Instance pre-initialized objects

ACISE_CONST se1_const = ACISE_CONST_DEFAULTS;

ACISE_CONST se2_const = ACISE_CONST_DEFAULTS;

Invoking the computation macro

ACISE_CONST_MACRO(se1_const); ACISE_CONST_MACRO (se2_const);

Example

The following pseudo code provides the information about the module usage.

```
main()
{
       se1_const.Rr = Rr1;
                                       // Pass floating-point inputs to se1_const
       se1 const.Lr = Lr1;
                                       // Pass floating-point inputs to se1 const
                                       // Pass floating-point inputs to se1 const
       se1 const.fb = Fb1;
       se1 const.fc = Fc1;
                                       // Pass floating-point inputs to se1_const
                                       // Pass floating-point inputs to se1 const
       se1 const.Ts = Ts1;
       se2\_const.Rr = Rr2;
                                       // Pass floating-point inputs to se2_const
       se2 const.Lr = Lr2;
                                       // Pass floating-point inputs to se2_const
       se2 const.fb = Fb2;
                                       // Pass floating-point inputs to se2 const
       se2\_const.fc = Fc2;
                                       // Pass floating-point inputs to se2_const
       se2\_const.Ts = Ts2;
                                       // Pass floating-point inputs to se2_const
       ACISE_CONST_MACRO (se1_const); // Call compute macro for se1_const
       ACISE CONST MACRO (se2 const); // Call compute macro for se2 const
       se1.K1 = _IQ(se1_const.K1); // Access the floating-point outputs of se1_const
       se1.K2 = IQ(se1 const.K2); // Access the floating-point outputs of se1 const
       se1.K3 = _IQ(se1_const.K3); // Access the floating-point outputs of se1_const
       se1.K4 = _IQ(se1_const.K4); // Access the floating-point outputs of se1_const
       se2.K1 = _IQ(se2_const.K1); // Access the floating-point outputs of se2_const
       se2.K2 = _IQ(se2_const.K2); // Access the floating-point outputs of se2_const
       se2.K3 = _IQ(se2_const.K3); // Access the floating-point outputs of se2_const
       se2.K4 = _IQ(se2_const.K4); // Access the floating-point outputs of se2_const
}
```

Technical Background

The open-loop speed estimator [1] is derived basing on the mathematics equations of induction motor in the stationary reference frame. The precise values of machine parameters are unavoidably required, otherwise the steady-state speed error may happen. However, the structure of the estimator is much simple comparing with other advanced techniques. All equations represented here are in the stationary reference frame (with superscript "s"). Firstly, the rotor flux linkage equations can be shown as below:

$$\lambda_{dr}^{s} = L_{r}i_{dr}^{s} + L_{m}i_{ds}^{s} \tag{1}$$

$$\lambda_{qr}^{s} = L_{r}i_{qr}^{s} + L_{m}i_{qs}^{s} \tag{2}$$

where L_r , and L_m are rotor, and magnetizing inductance (H), respectively. According to equations (1)-(2), the rotor currents can be expressed as

$$i_{dr}^{s} = \frac{1}{L_{r}} \left(\lambda_{dr}^{s} - L_{m} i_{ds}^{s} \right)$$
(3)

$$i_{qr}^{s} = \frac{1}{L_{r}} \left(\lambda_{qr}^{s} - L_{m} i_{qs}^{s} \right) \tag{4}$$

Secondly, the rotor voltage equations are used to find the rotor flux linkage dynamics.

$$0 = R_r i_{dr}^s + \omega_r \lambda_{qr}^s + \frac{d\lambda_{dr}^s}{dt}$$
 (5)

$$0 = R_r i_{qr}^s - \omega_r \lambda_{dr}^s + \frac{d\lambda_{qr}^s}{dt}$$
 (6)

where ω_r is electrically angular velocity of rotor (rad/sec), and R_r is rotor resistance (Ω). Substituting the rotor currents from (3)-(4) into (5)-(6), then the rotor flux linkage dynamics can be found as

$$\frac{d\lambda_{dr}^{s}}{dt} = -\frac{1}{\tau_{r}}\lambda_{dr}^{s} + \frac{L_{m}}{\tau_{r}}i_{ds}^{s} - \omega_{r}\lambda_{qr}^{s}$$
(7)

$$\frac{d\lambda_{qr}^{s}}{dt} = -\frac{1}{\tau_{r}}\lambda_{qr}^{s} + \frac{L_{m}}{\tau_{r}}i_{qs}^{s} + \omega_{r}\lambda_{dr}^{s}$$
(8)

where $\tau_{\rm r}=\frac{L_{\rm r}}{R_{\rm r}}$ is rotor time constant (sec).

Suppose that the rotor flux linkages in (7)-(8) are known, therefore, its magnitude and angle can be computed as

$$\lambda_{\rm r}^{\rm s} = \sqrt{\left(\lambda_{\rm dr}^{\rm s}\right)^2 + \left(\lambda_{\rm qr}^{\rm s}\right)^2} \tag{9}$$

$$\theta_{\lambda_{\rm r}} = \tan^{-1} \left(\frac{\lambda_{\rm qr}^{\rm s}}{\lambda_{\rm dr}^{\rm s}} \right) \tag{10}$$

Next, the rotor flux (i.e., synchronous) speed, ω_e , can be easily calculated by derivative of the rotor flux angle in (10).

$$\omega_{e} = \frac{d\theta_{\lambda_{r}}}{dt} = \frac{d\left(\tan^{-1}\left(\frac{\lambda_{qr}^{s}}{\lambda_{dr}^{s}}\right)\right)}{dt}$$
(11)

Referring to the derivative table, equation (11) can be solved as

$$\frac{d(\tan^{-1} u)}{dt} = \frac{1}{1+u^2} \frac{du}{dt}$$
 (12)

where $u = \frac{\lambda_{qr}^s}{\lambda_{dr}^s}$, yields

$$\omega_{e} = \frac{d\theta_{\lambda_{r}}}{dt} = \frac{\left(\lambda_{dr}^{s}\right)^{2}}{\left(\lambda_{r}^{s}\right)^{2}} \left(\frac{\lambda_{dr}^{s} \frac{d\lambda_{qr}^{s}}{dt} - \lambda_{qr}^{s} \frac{d\lambda_{dr}^{s}}{dt}}{\left(\lambda_{dr}^{s}\right)^{2}}\right)$$
(13)

Substituting (7)-(8) into (13), and rearranging, then finally it gives

$$\omega_{e} = \frac{d\theta_{\lambda_{r}}}{dt} = \omega_{r} + \frac{1}{\left(\lambda_{r}^{s}\right)^{2}} \frac{L_{m}}{\tau_{r}} \left(\lambda_{dr}^{s} \dot{i}_{qs}^{s} - \lambda_{qr}^{s} \dot{i}_{ds}^{s}\right)$$
(14)

The second term of the left hand in (14) is known as slip that is proportional to the electromagnetic torque when the rotor flux magnitude is maintaining constant. The electromagnetic torque can be shown here for convenience.

$$T_{e} = \frac{3}{2} \frac{p}{2} \frac{L_{m}}{L_{r}} \left(\lambda_{dr}^{s} i_{qs}^{s} - \lambda_{qr}^{s} i_{ds}^{s} \right)$$
 (15)

where p is the number of poles. Thus, the rotor speed can be found as

$$\omega_{\rm r} = \omega_{\rm e} - \frac{1}{\left(\lambda_{\rm r}^{\rm s}\right)^2} \frac{L_{\rm m}}{\tau_{\rm r}} \left(\lambda_{\rm dr}^{\rm s} i_{\rm qs}^{\rm s} - \lambda_{\rm qr}^{\rm s} i_{\rm ds}^{\rm s}\right) \tag{16}$$

Now, the per-unit concept is applied to (16), then, the equation (16) becomes

$$\omega_{r,pu} = \omega_{e,pu} - \frac{1}{\omega_b \tau_r} \left(\frac{\lambda_{dr,pu}^s \mathbf{i}_{qs,pu}^s - \lambda_{qr,pu}^s \mathbf{i}_{ds,pu}^s}{\left(\lambda_{r,pu}^s\right)^2} \right) \qquad \text{pu}$$
 (17)

where $\omega_b=2\pi f_b$ is the base electrically angular velocity (rad/sec), $\lambda_b=L_m I_b$ is the base flux linkage (volt.sec), and I_b is the base current (amp). Equivalently, another form is

$$\omega_{r,pu} = \omega_{e,pu} - \mathbf{K}_{1} \left(\frac{\lambda_{dr,pu}^{s} \mathbf{i}_{qs,pu}^{s} - \lambda_{qr,pu}^{s} \mathbf{i}_{ds,pu}^{s}}{\left(\lambda_{r,pu}^{s}\right)^{2}} \right) \qquad \text{pu}$$
 (18)

where $K_1 = \frac{1}{\omega_b \tau_r}$.

The per-unit synchronous speed can be calculated as

$$\omega_{\rm e,pu} = \frac{1}{2\pi f_{\rm h}} \frac{d\theta_{\lambda_{\rm r}}}{dt} = \frac{1}{f_{\rm h}} \frac{d\theta_{\lambda_{\rm r},pu}}{dt} \qquad \text{pu}$$
 (19)

where f_b is the base electrical (supplied) frequency (Hz) and 2π is the base angle (rad).

Discretizing equation (19) by using the backward approximation, yields

$$\omega_{e,pu}(k) = \frac{1}{f_h} \left(\frac{\theta_{\lambda_r,pu}(k) - \theta_{\lambda_r,pu}(k-1)}{T} \right) \quad pu$$
 (20)

where T is the sampling period (sec). Equivalently, another form is

$$\omega_{e,pu}(k) = K_2(\theta_{\lambda_r,pu}(k) - \theta_{\lambda_r,pu}(k-1)) \quad \text{pu}$$
 (21)

where $K_2 = \frac{1}{f_b T}$ is usually a large number.

In practice, the typical waveforms of the rotor flux angle, $\theta_{\lambda_r,pu}$, in both directions can be seen in Figure 1. To take care the discontinuity of angle from 360° to 0° (CCW) or from 0° to 360° (CW), the differentiator is simply operated only within the differentiable range as seen in this Figure. This differentiable range does not significantly lose the information to compute the estimated speed.




Figure 1: The waveforms of rotor flux angle in both directions

In addition, the synchronous speed in (21) is necessary to be filtered out by the low-pass filter in order to reduce the amplifying noise generated by the pure differentiator in (21). The simple 1st-order low-pass filter is used, then the actual synchronous speed to be used is the output of the low-pass filter, $\hat{\omega}_{e,pu}$, seen in following equation. The continuous-time equation of 1st-order low-pass filter is as

$$\frac{d\hat{\omega}_{e,pu}}{dt} = \frac{1}{\tau_c} \left(\omega_{e,pu} - \hat{\omega}_{e,pu} \right) \quad \text{pu}$$
 (22)

where $\tau_c = \frac{1}{2\pi f_c}$ is the low-pass filter time constant (sec), and f_c is the cut-off frequency

(Hz). Using backward approximation, then (22) finally becomes

$$\hat{\omega}_{e,pu}(k) = K_3 \hat{\omega}_{e,pu}(k-1) + K_4 \omega_{e,pu}(k)$$
 pu (23)

where
$$\,K_{_3}=\frac{\tau_{_c}}{\tau_{_c}+T}\,,$$
 and $\,K_{_4}=\frac{T}{\tau_{_c}+T}\,.$

In fact, only three equations (18), (21), and (23) are mainly employed to compute the estimated speed in per-unit. The required parameters for this module are summarized as follows:

The machine parameters:

- number of poles (p)
- rotor resistance (R_r)
- rotor leakage inductance (L_{rl})
- magnetizing inductance (L_m)

The based quantities:

- base current (I_b)
- base electrically angular velocity (ω_b)

The sampling period:

- sampling period (T)

Low-pass filter:

- cut-off frequency (f_c)

Notice that the rotor self inductance is $L_r = L_{rl} + L_m$ (H).

Next, Table 1 shows the correspondence of notations between variables used here and variables used in the program (i.e., aci_se.c, aci_se.h). The software module requires that both input and output variables are in per unit values.

| | Equation Variables | Program Variables | |
|--------|------------------------------------|-------------------|--|
| Inputs | $\lambda_{ m dr}^{ m s}$ | PsiDrS | |
| | $\lambda_{ m qr}^{ m s}$ | PsiQrS | |
| | $\theta_{\lambda_{\mathrm{r}}}$ | ThetaFlux | |
| | i_{ds}^s | IDsS | |
| | \mathbf{i}_{qs}^{s} | IQsS | |
| Output | $\omega_{\rm r}$ | WrHat | |
| Others | $\left(\lambda_{r}^{s}\right)^{2}$ | SquaredPsi | |
| | $\omega_{ m e}$ | WPsi | |

Table 1: Correspondence of notations

References:

[1] A.M. Trzynadlowski, The Field Orientation Principle in Control of Induction Motors, Kluwer Academic Publishers, 1994, pp. 176-180.