FPU DSP Software Library

USER'S GUIDE



Copyright

Copyright © 2014 Texas Instruments Incorporated. All rights reserved. ControlSUITE is a registered trademark of Texas Instruments. Other names and brands may be claimed as the property of others.

APlease be aware that an important notice concerning availability, standard warranty, and use in critical applications of Texas Instruments semiconductor products and disclaimers thereto appears at the end of this document.

Texas Instruments 12203 Southwest Freeway Houston, TX 77477 http://www.ti.com/c2000



Revision Information

This is version V1.40.00.00 of this document, last updated on Jan 30, 2014.

Table of Contents

Copy	right	2
Revi	sion Information	2
1	Introduction	5
2	Other Resources	6
3	Library Structure	7
3.1	Build Options used to build the library	8
3.2	Header Files	8
4	Using the FPU Library	9
4.1	Library Build Configurations	9
4.2	Integrating the Library into your Project	10
5	Application Programming Interface (FPU)	16
5.1		20
5.2		23
5.3		25
5.4		27
5.5	Complex Fast Fourier Transform Phase	29
5.6	Complex Fast Fourier Transform Twiddle Factors	31
5.7	Inverse Complex Fast Fourier Transform	33
5.8	Real Fast Fourier Transform	36
5.9	Real Fast Fourier Transform (Unaligned)	39
5.10		41
		44
		46
		48
		50
		52
		54
	the process of the control of the co	58
		59
		60
		61
		62
		63
		64
5.20		65
		67
		68
		69
		09 71
		71 72
		72 73
5.30		
		74 75
		75
		76
		77 70
		78 70
ე.კხ	Sort an Array of Floats	79

E 07	Payading (Unbigged) of a Floating Point Cooler	٠,
	Rounding (Unbiased) of a Floating Point Scalar	
5.38	Subtraction of a Complex Scalar from a Complex Vector	31
5.39	Subtraction of a Complex Vector and another Complex Vector	32
5.40	Fast Square Root	33
5.41	Optimized Memory Copy	34
5.42	Optimized Memory Set	35
6	Benchmarks	36
7	Revision History	39
IMPC	DRTANT NOTICE) (

1 Introduction

The Texas Instruments TMS320C28x Floating Point Unit (FPU) Library is collection of highly optimized application functions written for the C28x+FPU (and C28x+FPU+TMU0). These functions enable C/C++ programmers to take full advantage of the performance potential of the C28x+FPU. This document provides a description of each function included within the library.

This library requires v133 of the F2833x device support files, v100 of the F2837xD device support files and v100 of the FPU Fast Run Time support library.

Chapter 2 provides a host of resources on the FPU in general, as well as training material.

Chapter 3 describes the directory structure of the package.

Chapter 4 provides step-by-step instructions on how to integrate the library into a project and use any of the maths routines.

Chapter 5 describes the programming interface, structures and routines available for this library

Chapter 6 lists The performance of each of the library routines.

Chapter 7 provides a revision history of the library.

Examples have been provided for each library routine. They can be found in the <code>examples_ccsv5</code> directory. For the current revision, all examples have been written for the <code>F2833x</code> and <code>F2837xD</code> devices and tested on their respective <code>controlCard</code> platforms. Each example has a script "<code>SetupDebugEnv.js</code>" that can be launched from the <code>Scripting Console</code> in CCS. These scripts will set-up the watch variables for the example. In some examples graphs (.graphProp) are provided; these can be imported into CCS during debug.

2 Other Resources

The user can get answers to F2833x and F2837xD frequently asked questions(FAQ) from the processors wiki page. Links to other references such as training videos will be posted here as well. http://processors.wiki.ti.com/index.php/Main_Page.

Also check out the TI Delfino page: http://www.ti.com/delfino

And don't forget the TI community website: http://e2e.ti.com

Building the FPU library and examples requires Codegen Tools v6.2.4 or later

3 Library Structure

| Build Options | s used to | build t | the libra | ary |
 | . 8 |
|---------------|-----------|---------|-----------|-----|------|------|------|------|------|------|------|------|------|------|------|-----|
| Header Files | | | | |
 | . 8 |

As installed, the C28x FPU Library is partitioned into a well-defined directory structure. By default, the library and source code is installed into the default controlSUITE directory,

C:\TI\controlSUITE\libs\dsp\FPU\VERSION

VERSION indicates the current revision of the FPU library. Figure. 3.1 shows the directory structure while the subsequent table 3.1 provides a description for each folder.




Figure 3.1: Directory Structure of the FPU Library

Folder	Description
<base/>	Base install directory. By default this is
	C:/TI/controlSUITE/libs/dsp/FPU/v1_40_00_00 For the rest
	of this document <base/> will be omitted from the directory
	names.
<base/> /ccs	Project files for the library. Allows the user to reconfigure, modify
	and re-build the library to suit their particular needs.
<base/> /cmd	Linker command files used in the examples.
<base/> /doc	Documentation for the current revision of the library including re-
	vision history.
<base/> /examples_ccsv5	Examples that illustrate the library functions. At the time of writing
	these examples were built for the F2833x device using the CCS
	5.5.0.00077 IDE.
<base/> /include	Header files for the FPU library. These include function proto-
	types and structure definitions.
<base/> /lib	Pre-built FPU libraries.
<base/> /source	Source files for the library.
<pre><base/>/examples_ccsv5/<example>/matlab</example></pre>	MATLAB reference code for the example. These are useful as
	they provide a standard input/output reference that the user can
	check against while debugging.

Table 3.1: FPU Library Directory Structure Description

3.1 Build Options used to build the library

The current version (default build configuration) of the library was built with C28x Codegen Tools v6.2.4 with the following options:

```
-v28 -ml -mt --float_support=fpu32 -02 --diag_warning=225
--display_error_number --diag_wrap=off
```

The alternate build configuration uses TMU0 supported functions and has an additional compiler switch:

```
-v28 -ml -mt --float_support=fpu32 -02 --diag_warning=225 --tmu_support=tmu0 --display_error_number --diag_wrap=off
```

3.2 Header Files

A library header file is supplied in the <base>/include folder. This file contains structure definitions and function prototypes. The header file uses standard C99 data types and defines a new data type for complex variables.

4 Using the FPU Library

Library Build Configurations	9
Integrating the Library into your Project	.10

The source code and project(s) for the FPU libraries are provided. The user may import the library project(s) into CCSv5 (or later) and be able to view and modify the source code for all routines and lookup tables (see Fig. 4.1)



Figure 4.1: FPU Library Project View

4.1 Library Build Configurations

The current version of the library(s) has a two build configurations (Fig. 4.2): ISA_C28FPU32 and ISA_C28FPU32+TMU0. The ISA_C28FPU32 configuration is built with the -float_support=fpu32 run-time support option set to fpu32. Running a build on this configuration will generate the c28x_fpu_dsp_library.lib in the lib folder. ISA_C28FPU32+TMU0 adds TMU support to the default build configuration and will generate the c28x_fpu_dsp_library_tmu0.lib. Some of the original routines have alternate versions that can make use of the TMU accelerator's (on devices that have it) ability to speed up certain trigonometric and math operations.

NOTE: ATTEMPTING TO LINK IN THIS LIBRARY INTO A PROJECT THAT DOES NOT HAVE THE FLOAT_SUPPORT (AND TMU_SUPPORT FOR THE TMU0 ENABLED LIBRARY) ENABLED WILL RESULT IN A COMPILER ERROR ABOUT MISMATCHING INSTRUCTION SET ARCHITECTURES




Figure 4.2: Library Build Configurations

4.2 Integrating the Library into your Project

To begin integrating the library into your project follow these easy steps:

1. Go to the **Project Properties->Build->Variables(Tab)** and add a new variable (see Fig. 4.3), INSTALLROOT_TO_FPU, and point it to the root directory of the FPU library in controlsuite, this is usually the version folder.




Figure 4.3: Creating a new build variable

Add the new path, **INSTALLROOT_TO_FPU/include**, to the *Include Options* section of the project properties (Fig. 4.4). This option tells the compiler where to find the library header files.

Jan 30, 2014




Figure 4.4: Adding the Library Header Path to the Include Options

2. Set the **-float_support** option to fpu32 in the **Runtime Model Options** (Fig. 4.5).




Figure 4.5: Turning on FPU support

- - X Properties for c28x_fpu_dsp_library type filter text C2000 Compiler > Resource General Configuration: ISA_C28FPU32+TMU0 ▼ Manage Configurations... ■ Build C2000 Compiler Processor Options Optimization Command: "\${CG_TOOL_CL}" Include Options Command-line pattern: \$\{command\} \$\{flags --tmu_support=tmu0\} > Advanced Options > C2000 Archiver Summary of flags set: Debug -v28 -ml -mt --float_support=fpu32 -O2 -include_path="C:/ti/ccsv5/tools/compiler/c2000_6.2.4/include" -include_path="C:/Users/a0272561/Repositories/cs30_controlsuite/libs/dsp/FPU/ver sion/include" --diag_warning=225 --display_error_number --diag_wrap=off Show advanced settings OK Cancel

Additionally, add the **tmu_support** option to the compiler command line when using the TMU0 enabled version of the library (Fig. 4.6).

Figure 4.6: Turning on TMU support

NOTE: IN LATER VERSIONS OF THE CODEGEN TOOLS THE tmu_support OPTION WILL BE AVAILABLE AS A DROP-DOWN MENU SIMILAR TO THE FPU OPTION

3. Add the name of the library and its location to the **File Search Path** as shown in Fig. 4.7. If your device has a TMU accelerator it is recommended to use the **c28x_fpu_dsp_library_tmu0.lib** instead (Fig. 4.8).

NOTE: BE SURE TO TURN ON FLOAT_SUPPORT (AND TMU_SUPPORT FOR THE TMU0 ENABLED LIBRARY) IN YOUR PROJECT PROPERTIES

Jan 30, 2014




Figure 4.7: Adding the library and location to the file search path

Jan 30, 2014




Figure 4.8: Adding the library and location to the file search path

4. If using the TMU0 version of the library, add the symbol _TMS320C28XX_TMU0__ to the list of predefined symbols in the options (Fig. 4.9). This symbol allows the user to call the alternate TMU0 functions using the legacy names.




Figure 4.9: Adding the TMU0 symbol

Jan 30, 2014

5 Application Programming Interface (FPU)

DSP Routines	
Complex Fast Fourier Transform	
Complex Fast Fourier Transform (Unaligned)	. 23
Complex Fast Fourier Transform Magnitude	25
Complex Fast Fourier Transform Magnitude (Scaled)	. 27
Complex Fast Fourier Transform Phase	
Complex Fast Fourier Transform Twiddle Factors	. 31
Inverse Complex Fast Fourier Transform	.33
Real Fast Fourier Transform	. 36
Real Fast Fourier Transform (Unaligned)	39
Real Fast Fourier Transform with ADC Input	. 41
Real Fast Fourier Transform with ADC Input (Unaligned)	.44
Real Fast Fourier Transform Magnitude	.46
Real Fast Fourier Transform Magnitude (Scaled)	48
Real Fast Fourier Transform Phase	. 50
Real Fast Fourier Transform Twiddle Factors	52
Finite Impulse Response Filter	. 54
Vector and Matrix Routines	
Absolute Value of a Complex Vector	58
Absolute Value of an Even Length Complex Vector	
Absolute Value of a Complex Vector (TMU0)	
Addition (Element-Wise) of a Complex Scalar to a Complex Vector	
Addition of Two Complex Vectors	
Inverse Absolute Value of a Complex Vector	
Inverse Absolute Value of an Even Length Complex Vector	
Inverse Absolute Value of a Complex Vector (TMU0)	
Index of Maximum Value of an Even Length Real Array	
Mean of Real and Imaginary Parts of a Complex Vector	
Median of a Real Valued Array of Floats (Preserved Inputs)	
Median of a real array of floats	
Complex Multiply of Two Floating Point Numbers	
Complex Multiply of Two Complex Vectors	
Multiplication of a Complex Vector and the Complex Conjugate of another Vector	
Multiplication of a Real scalar and a Real Vector	
Multiplication of a Real Scalar, a Real Vector, and another Real Vector	
Multiplication of a Real Vector and a Complex Vector	
Multiplication of a Real Vector and a Real Vector	
Sort an Array of Floats	
Rounding (Unbiased) of a Floating Point Scalar	
Subtraction of a Complex Scalar from a Complex Vector	
Subtraction of a Complex Vector and another Complex Vector	
Math Routines	
Fast Square Root	00
Tast Square noot	. 03
Utility Routines	
Ontimized Mamory Cony	0.4

Application	Programming	Interface	(FPI I

Optimized Memo	ry Set					85
----------------	--------	--	--	--	--	----

The following functions are included in this release of the FPU Library. The source code for these functions can be found in the $source/C28x_FPU_LIB$ folder.

DSP							
CFFT f32	void CFFT_f32(CFFT_F32_STRUCT *);						
CFFT f32u	void CFFT_f32u(CFFT_F32_STRUCT *);						
CFFT_f32_mag	void CFFT_f32_mag(CFFT_F32_STRUCT *);						
CFFT_f32s_mag	void CFFT_f32s_mag(CFFT_F32_STRUCT *);						
CFFT_f32_phase	void CFFT_f32_phase(CFFT_F32_STRUCT *);						
CFFT_f32_sincostable	void CFFT_f32_sincostable(CFFT_F32_STRUCT *);						
ICFFT_f32	void ICFFT_f32(CFFT_F32_STRUCT *);						
RFFT f32	void RFFT_f32(RFFT_F32_STRUCT *);						
RFFT f32u	void RFFT f32u(RFFT F32 STRUCT*);						
RFFT_adc_f32	void RFFT_adc_f32(RFFT_ADC_F32_STRUCT *);						
RFFT adc f32u	void RFFT_adc_f32u(RFFT_ADC_F32_STRUCT *);						
RFFT_f32_mag	void RFFT_f32_mag(RFFT_F32_STRUCT *);						
RFFT_f32s_mag	void RFFT_f32s_mag(RFFT_F32_STRUCT *);						
RFFT_f32_phase	void RFFT_f32_phase(RFFT_F32_STRUCT *);						
RFFT_f32_sincostable	void RFFT_f32_sincostable(RFFT_F32_STRUCT *);						
	,						
	Filter						
FIR f32	void FIR FP calc(FIR FP handle);						
_							
	Matrix and Vector						
abs SP CV	void abs_SP_CV(float32 *, const complex_float *, const Uint16);						
abs SP CV 2	void abs_SP_CV_2(float32 *, const complex_float *, const						
	Uint16);						
abs_SP_CV_TMU0	void abs_SP_CV_TMU0(float32 *, const complex_float *, const						
	Uint16);						
add_SP_CSxCV	void add_SP_CSxCV(complex_float *, const complex_float *,						
	const complex_float, const Uint16);						
add_SP_CVxCV	void add_SP_CVxCV(complex_float *, const complex_float *,						
	const complex_float *, const Uint16);						
iabs_SP_CV	void iabs_SP_CV(float32 *, const complex_float *, const Uint16);						
iabs_SP_CV_2	void iabs_SP_CV_2(float32 *, const complex_float *, const						
	Uint16);						
iabs_SP_CV_TMU0	void iabs_SP_CV_TMU0(float32 *, const complex_float *, const						
	Uint16);						
maxidx_SP_RV_2	Uint16 maxidx_SP_RV_2(float32 *, Uint16);						
mean_SP_CV_2	complex_float mean_SP_CV_2(const complex_float *, const						
	Uint16);						
median_noreorder_SP_RV	float32 median_noreorder_SP_RV(const float32 *, Uint16);						
median_SP_RV	float32 median_SP_RV(float32 *, Uint16);						
mpy_SP_CSxCS	complex_float mpy_SP_CSxCS(complex_float, complex_float);						
mpy_SP_CVxCV	void mpy_SP_CVxCV(complex_float *, const complex_float *,						
00.07.07.0	const complex_float *, const Uint16);						
mpy_SP_CVxCVC	void mpy_SP_CVxCVC(complex_float *, const complex_float *,						
many CD DOVDV C	const complex_float *, const Uint16);						
mpy_SP_RSxRV_2	void mpy_SP_RSxRV_2(float32 *, const float32 *, const float32,						
	const Uint16);						
	Continued on next page						

Table 5.1 – continued from previous page								
mpy_SP_RSxRVxRV_2	void mpy_SP_RSxRVxRV_2(float32 *, const float32 *, const							
	float32 *, const float32, const Uint16);							
mpy_SP_RVxCV void mpy_SP_RVxCV(complex_float *, const complex_float								
	const float32 *, const Uint16);							
mpy_SP_RVxRV_2	void mpy_SP_RVxRV_2(float32 *, const float32 *, const float32							
	*, const Uint16);							
qsort_SP_RV	void qsort_SP_RV(void *, Uint16);							
rnd_SP_RS	float32 rnd_SP_RS(float32);							
sub_SP_CSxCV void sub_SP_CSxCV(complex_float *, const complex_flo								
	const complex_float, const Uint16);							
sub_SP_CVxCV	void sub_SP_CVxCV(complex_float *, const complex_float *,							
	const complex_float *, const Uint16);							
	Math							
ffsqrtf	inline static float32ffsqrtf(float32 x);							
Utility								
memcpy_fast	void memcpy_fast(void *, const void *, Uint16);							
memset_fast	void memset_fast(void*, int16, Uint16);							

Table 5.1: List of Functions

The examples for each was built using **CGT v6.2.4** with the following options:

```
-v28 -mt -ml -g --diag_warning=225 --float_support=fpu32
```

For the examples that use the TMU0 version of the library, additional options were enabled:

```
-v28 -ml -mt --float support=fpu32 --tmu support=tmu0 -q --define=CPU1
--define=_TMS320C28XX_TMU0__ --diag_warning=225
```

In order to highlight the interleaving ability of the compiler for the fast square root function, its example was built with the options

```
-v28 -mt -ml -g -O2 --diag_warning=225 --optimize_with_debug
--float_support=fpu32
```

Each example has a script SetupDebugEnv.js that can be used with the scripting console in CCS to setup the watch windows and graphs automatically in the debug session. Please see CCS4:Scripting Console for more information

Jan 30, 2014 19

5.1 Complex Fast Fourier Transform

Description:

This module computes a 32-bit floating-point complex FFT including input bit reversing. This version of the function requires input buffer memory alignment. If you do not wish to align the input buffer, then use the **CFFT_f32u** function.

Header File:

```
fpu cfft.h
```

Declaration:

```
void CFFT_f32 (CFFT_F32_STRUCT *)
```

Usage:

A pointer to the following structure is passed to the CFFT f32 function:

```
typedef struct {
 float32
         *InPtr;
 float32
            *OutPtr;
 float32
            *CoefPtr;
 float32
            *CurrentInPtr;
 float32
            *CurrentOutPtr;
 Uint16
            Stages;
 Uint16
            FFTSize;
} CFFT_F32_STRUCT;
```

Table 5.2 describes each element

Alignment Requirements:

The input buffer must be aligned to a multiple of the *2*FFTSize*sizeof(float)* i.e. *4*FFTSize*. For example, if the **FFTSize** is 128 you must align the buffer corresponding to **InPtr** to 4*128 = 512. An alignment to a smaller value will not work for the 128-pt complex FFT.

To align the input buffer, use the **DATA_SECTION** pragma to assign the buffer to a code section and then align the buffer to the proper offset in the linker command file. In this code example the buffer is assigned to the CFFTin1Buff section.

```
#define CFFT_STAGES 7
#define CFFT_SIZE (1 << CFFT_STAGES)

//Buffer alignment for the input array,
//CFFT_f32u (optional), CFFT_f32 (required)
//Output of FFT overwrites input if
//CFFT_STAGES is ODD
#pragma DATA_SECTION(CFFTin1Buff, "CFFTdata1");
float CFFTin1Buff[CFFT_SIZE*2];</pre>
```

In the project's linker command file, the **CFFTdata1** section is then aligned to a multiple of the FFTSize as shown below:

```
CFFTdata1 : > RAML4, PAGE = 1, ALIGN(512)
```

The buffers referenced by **InPtr** and **OutPtr** are used in ping-pong fashion. At the first stage of the FFT InPtr and CurrentInPtr both point to the input buffer and OutPtr and CurrentOutPtr point

Item	Description	Format	Comment
InPtr	Input data	Pointer to 32-bit float array	Input buffer alignment is required. Refer to
			the alignment section.
OutPtr	Output buffer	Pointer to 32-bit float array	
CoefPtr	Twiddle factors	Pointer to 32-bit float array	Calculate using CFFT_f32_cossintable ().
CurrentInPtr	Output Buffer	Pointer to 32-bit float array	Result of CFFT_f32. This buffer can then be
			used as the input to the magnitude and phase
			calculations. The output order for FFTSize =
			N is:
			CurrentInPtr[0] = real[0]
			CurrentInPtr[1] = imag[0]
			CurrentInPtr[2] = real[1]
			CurrentInPtr[N] = real[N/2]
			CurrentInPtr[N+1] = imag[N/2]
			CurrentInPtr[2N-3] = imag[N-2]
			CurrentInPtr[2N-2] = real[N-1]
			CurrentInPtr[2N-1] = imag[N-1]
CurrentOutPtr	Output Buffer	Pointer to 32-bit float array	Result of N-1 stage complex FFT.
Stages	Number of stages	Uint16	Stages = log2(FFTSize). Must larger than 3.
FFTSize	FFT size	Uint16	Must be a power of 2 greater than or equal to
			8.

Table 5.2: Elements of the Data Structure

to the same output buffer. After bit reversing the input and computing the stage 1 butterflies the output is stored at the location pointed to be cfft.CurrentOutPtr. The next step is to switch the pointer cfft.CurrentInPtr with cfft.CurrentOutPtr so that the output from the n^{th} stage becomes the input to the $n+1^{th}$ stage while the previous (n^{th}) stage's input buffer will be used as the output for the $n+1^{th}$ stage. In this manner the CurrentInPtr and CurrentOutPtr are switched successively for each FFT stage.Therefore, If the number of stages is odd then at the end of all the coputation we get:

currentInPtr=InPtr, currentOutPtr=OutPtr.

If number of stages is even then,

 $currentInPtr=OutPtr,\, currentOutPtr=InPtr.$

	Stage3	Stage4	Stage5	 Stag	ge N
				N = odd	N = even
InPtr (Buf1)	CurrentInPtr	CurrentOutPtr	CurrentInPtr	 CurrentInPtr	CurrentOutPtr
OutPtr (Buf2)	CurrentOutPtr	CurrentInPtr	CurrentOutPtr	 CurrentOutPtr	CurrentInPtr
Result Buf	Buf1	Buf2	Buf1	 Buf1	Buf2

Table 5.3: Input and Output Buffer Pointer Allocations

Notes:

- 1. This function is not re-entrant as it uses global variables to store arguments; these will be overwritten if the function is invoked while it is currently processing.
- 2. If the input buffer is not properly aligned, then the output will be unpredictable.
- 3. If you do not wish to align the input buffer, then you must use the CFFT_f32u function. This version of the function does not have any input buffer alignment requirements. Using CFFT_f32u will, however, result in lower cycle performance.
- 4. All buffers and stack are placed in internal memory (zero-wait states in data space).

Example:

The following sample code obtains the complex FFT of the input.

```
#include "fpu\_cfft.h"
#define CFFT_STAGES
                        7
#define CFFT_SIZE
                       (1 << CFFT_STAGES)
/* CFFTin1Buff section to 4*FFT SIZE in the linker file
#pragma DATA_SECTION(CFFTin1Buff, "CFFTdata1");
float CFFTin1Buff[CFFT SIZE*2];
#pragma DATA_SECTION(CFFToutBuff, "CFFTdata3");
float CFFToutBuff[CFFT_SIZE*2];
#pragma DATA_SECTION(CFFTF32Coef, "CFFTdata4");
float CFFTF32Coef[CFFT SIZE];
CFFT_F32_STRUCT cfft;
main()
  cfft.InPtr = CFFTin1Buff; /* Input data buffer
                                                             */
  cfft.OutPtr = CFFToutBuff; /* FFT output buffer
                                                             */
  cfft.CoefPtr = CFFTF32Coef; /* Twiddle factor buffer
                                                             */
  cfft.FFTSize = CFFT_SIZE;
                              /* FFT length
                                                             */
  cfft.Stages = CFFT_STAGES; /* FFT Stages
                                                             */
  CFFT_f32_sincostable(&cfft); /* Initialize twiddle buffer */
  CFFT f32(&cfft);
                               /* Calculate output
```

Benchmark Information:

The following table provides benchmark numbers for the function. Note that these include the cycles used in the call/return from the function

FFTSize	C-Callable ASM (Cycle Count)
32	1121
64	2331
128	5029
256	11023
512	24249
1024	53219

Table 5.4: Benchmark Information

5.2 Complex Fast Fourier Transform (Unaligned)

Description:

This module computes a 32-bit floating-point complex FFT including input bit reversing. This version of the function does not have any buffer alignment requirements. If you can align the input buffer, then use the **CFFT_f32** function for improved performance

Header File:

```
fpu cfft.h
```

Declaration:

```
void CFFT_f32u (CFFT_F32_STRUCT *)
```

Usage:

A pointer to the following structure is passed to the CFFT_f32 function. It is the same structure described in the CFFT_f32 section:

```
typedef struct {
  float32 *InPtr;
  float32 *OutPtr;
  float32 *CoefPtr;
  float32 *CurrentInPtr;
  float32 *CurrentOutPtr;
  Uint16 Stages;
  Uint16 FFTSize;
} CFFT_F32_STRUCT;
```

Table 5.2 describes each element describes each element with the exception that the **input buffer does not require alignment**.

Alignment Requirements:

None

Notes:

- 1. This function is not re-entrant as it uses global variables to store arguments; these will be overwritten if the function is invoked while it is currently processing.
- 2. If you can align the input buffer to a 4*FFTSize, then consider using the CFFT_f32 function which has input buffer alignment requirements, but it is more cycle efficient
- 3. All buffers and stack are placed in internal memory (zero-wait states in data space).

Example:

The following sample code obtains the complex FFT of the input.

```
#include "fpu\_cfft.h"
                        7
#define CFFT_STAGES
                       (1 << CFFT_STAGES)
#define CFFT_SIZE
float CFFTin1Buff[CFFT_SIZE*2];
float CFFTin2Buff[CFFT_SIZE*2];
float CFFToutBuff[CFFT_SIZE*2];
float CFFTF32Coef[CFFT SIZE];
CFFT_F32_STRUCT cfft;
main()
  cfft.InPtr = CFFTin1Buff; /* Input data buffer
                                                          */
  cfft.OutPtr = CFFToutBuff; /* FFT output buffer
  cfft.CoefPtr = CFFTF32Coef; /* Twiddle factor buffer
                                                          */
  cfft.FFTSize = CFFT_SIZE; /* FFT length
  cfft.Stages = CFFT_STAGES; /* FFT Stages
  . . . . . .
  CFFT_f32_sincostable(&cfft); /* Initialize twiddle
                               /* buffer
                                                          */
  CFFT_f32u(&cfft);
                               /* Calculate output
                                                          */
```

Benchmark Information:

The following table provides benchmark numbers for the function. Note that these include the cycles used in the call/return from the function

FFTSize	C-Callable ASM (Cycle Count)
32	1351
64	2785
128	5931
256	12821
512	27839
1024	60393

Table 5.5: Benchmark Information

5.3 Complex Fast Fourier Transform Magnitude

Description:

This module computes the complex FFT magnitude. The output from **CFFT_f32_mag** matches the magnitude output from the FFT found in common mathematics software and Code Composer Studio FFT graphs.

If instead a normalized magnitude like that performed by the fixed-point TMS320C28x IQmath FFT library is required, then the **CFFT_f32s_mag** function can be used. In fixed-point algorithms scaling is performed to avoid overflowing data. Floating-point calculations do not need this scaling to avoid overflow and therefore the CFFT_f32_mag function can be used instead.

Header File:

fpu_cfft.h

Declaration:

```
void CFFT_f32_mag (CFFT_F32_STRUCT *)
```

Usage:

A pointer to the following structure is passed to the CFFT_f32_mag function.It is the same structure described in the CFFT_f32 section:

```
typedef struct {
  float32 *InPtr;
  float32 *OutPtr;
  float32 *CoefPtr;
  float32 *CurrentInPtr;
  float32 *CurrentOutPtr;
  Uint16 Stages;
  Uint16 FFTSize;
} CFFT_F32_STRUCT;
```

Table 5.2 describes each element.

Alignment Requirements:

The Magnitude buffer requires no alignment but the input buffer to the complex FFT routine will need alignment if using the **CFFT** f32().

Notes:

- 1. All buffers and stack are placed in internal memory (zero-wait states in data space).
- 2. The magnitude calculation calls the sqrt function within the runtime-support library. The magnitude function has not been optimized at this time.
- The use of the sqrt function in the FPUfastRTS library will speed up this routine. The
 example for the CFFT has an alternate build configuration(Debug_FASTRTS) where
 the rts2800_fpu32_fast_supplement.lib is used in place of the standard runtime library rts2800_fpu32.lib.

Example:

The following sample code obtains the complex FFT magnitude.

```
#include "fpu\_cfft.h"
#define CFFT STAGES
                        7
#define CFFT_SIZE
                       (1 << CFFT_STAGES)
/* CFFTin1Buff section to 4*FFT_SIZE in the linker file */
#pragma DATA_SECTION(CFFTin1Buff, "CFFTdata1");
float CFFTin1Buff[CFFT_SIZE*2];
#pragma DATA SECTION(CFFTin2Buff, "CFFTdata2");
float CFFTin2Buff[CFFT_SIZE*2];
#pragma DATA_SECTION(CFFToutBuff, "CFFTdata3");
float CFFToutBuff[CFFT_SIZE*2];
#pragma DATA_SECTION(CFFTF32Coef, "CFFTdata4");
float CFFTF32Coef[CFFT SIZE];
CFFT_F32_STRUCT cfft;
main()
  cfft.InPtr
              = CFFTin1Buff; /* Input data buffer
  cfft.OutPtr = CFFToutBuff; /* FFT output buffer
                                                         */
  cfft.CoefPtr = CFFTF32Coef; /* Twiddle factor buffer
                                                         */
  cfft.FFTSize = CFFT_SIZE;
                              /* FFT length
                                                         */
  cfft.Stages = CFFT_STAGES; /* FFT Stages
                                                         */
  CFFT f32 sincostable(&cfft); /* Initialize twiddle
                              /* buffer
                                                         */
  CFFT_f32(&cfft);
                              /* Calculate output
                                                         */
  CFFT_f32_mag(&cfft);
                             /* Calculate Magnitude
```

Benchmark Information:

The following table provides benchmark numbers for the function. Note that these include the cycles used in the call/return from the function.

FFTSize	C-Callable ASM (Cycle Count)		
	Standard Runtime Lib	Fast Runtime Lib	
32	2717	1436	
64	5405	2844	
128	10781	5660	
256	21533	11292	
512	43037	22556	
1024	86045	45084	

Table 5.6: Benchmark Information

5.4 Complex Fast Fourier Transform Magnitude (Scaled)

Description:

This module computes the scaled complex FFT magnitude. The scaling is $\frac{1}{[2^{FFT}_STAGES-1]}$, and is done to match the normalization performed by the fixed-point TMS320C28x IQmath FFT library for overflow avoidance. Floating-point calculations do not need this scaling to avoid overflow and therefore the **CFFT_f32_mag** function can be used instead. The output from CFFT_f32_mag matches the magnitude output from the FFT found in common mathematics software and Code Composer Studio FFT graphs.

Header File:

fpu cfft.h

Declaration:

```
void CFFT_f32s_mag (CFFT_F32_STRUCT *)
```

Usage

A pointer to the following structure is passed to the CFFT_f32s_mag function. It is the same structure described in the CFFT_f32 section:

```
typedef struct {
  float32 *InPtr;
  float32 *OutPtr;
  float32 *CoefPtr;
  float32 *CurrentInPtr;
  float32 *CurrentOutPtr;
  Uint16 Stages;
  Uint16 FFTSize;
} CFFT_F32_STRUCT;
```

Table 5.2 describes each element

Alignment Requirements:

The Magnitude buffer requires no alignment but the input buffer to the complex FFT routine will need alignment if using the **CFFT f32()**.

Notes:

- 1. All buffers and stack are placed in internal memory (zero-wait states in data space).
- 2. The magnitude calculation calls the sqrt function within the runtime-support library. The magnitude function has not been optimized at this time.
- The use of the sqrt function in the FPUfastRTS library will speed up this routine. The
 example for the CFFT has an alternate build configuration (Debug_FASTRTS) where
 the rts2800_fpu32_fast_supplement.lib is used in place of the standard runtime library rts2800_fpu32.lib.

Example:

The following sample code obtains the scaled FFT magnitude.

```
#include "fpu\ cfft.h"
#define CFFT_STAGES
#define CFFT SIZE
                       (1 << CFFT STAGES)
/* CFFTin1Buff section to 4*FFT_SIZE in the linker file */
#pragma DATA SECTION(CFFTin1Buff, "CFFTdata1");
float CFFTin1Buff[CFFT_SIZE*2];
#pragma DATA SECTION(CFFTin2Buff, "CFFTdata2");
float CFFTin2Buff[CFFT_SIZE*2];
#pragma DATA_SECTION(CFFToutBuff, "CFFTdata3");
float CFFToutBuff[CFFT_SIZE*2];
#pragma DATA_SECTION(CFFTF32Coef, "CFFTdata4");
float CFFTF32Coef[CFFT_SIZE];
CFFT_F32_STRUCT cfft;
main()
  cfft.InPtr = CFFTin1Buff; /* Input data buffer
                                                         */
  cfft.OutPtr = CFFToutBuff; /* FFT output buffer
                                                         */
  cfft.CoefPtr = CFFTF32Coef; /* Twiddle factor buffer
                                                         */
  cfft.FFTSize = CFFT_SIZE; /* FFT length
                                                         */
  cfft.Stages = CFFT STAGES; /* FFT Stages
                                                         */
  . . . . . . .
  CFFT f32 sincostable(&cfft);/* Initialize twiddle
                                                         */
                             /* buffer
                                                         */
  CFFT_f32(&cfft);
                             /* Calculate output
                                                         */
  CFFT_f32s_mag(&cfft);
                             /* Calculate Magnitude
                                                         */
```

Benchmark Information:

The following table provides benchmark numbers for the function. Note that these include the cycles used in the call/return from the function.

FFTSize	C-Callable ASM (Cycle Count)			
	Standard Runtime Lib	Fast Runtime Lib		
32	2906	1534		
64	5760	3013		
128	11462	5964		
256	22860	11859		
512	45650	23642		
1024	91224	47201		

Table 5.7: Benchmark Information

5.5 Complex Fast Fourier Transform Phase

Description:

This module computes FFT Phase.

Header File:

fpu_cfft.h

Declaration:

```
void CFFT_f32_phase (CFFT_F32_STRUCT *)
```

Usage:

A pointer to the following structure is passed to the CFFT_f32_phase function.It is the same structure described in the CFFT f32 section:

```
typedef struct {
  float32 *InPtr;
  float32 *OutPtr;
  float32 *CoefPtr;
  float32 *CurrentInPtr;
  float32 *CurrentOutPtr;
  Uint16 Stages;
  Uint16 FFTSize;
} CFFT_F32_STRUCT;
```

Table 5.2 describes each element.

Alignment Requirements:

The Phase buffer requires no alignment but the input buffer to the complex FFT routine will need alignment if using the **CFFT_f32()**.

Notes:

- 1. All buffers and stack are placed in internal memory (zero-wait states in data space).
- 2. The phase function calls the atan2 function in the runtime-support library. The phase function has not been optimized at this time.
- 3. The use of the atan2 function in the FPUfastRTS library will speed up this routine. The example for the CFFT has an alternate build configuration (Debug_FASTRTS) where the rts2800_fpu32_fast_supplement.lib is used in place of the standard runtime library rts2800_fpu32.lib.

Example:

The following sample code obtains the Complex FFT phase.

```
#include "fpu\ cfft.h"
#define CFFT_STAGES
#define CFFT SIZE
                        (1 << CFFT_STAGES)</pre>
/\star CFFTin1Buff section to 4\starFFT_SIZE in the linker file \star/
#pragma DATA SECTION(CFFTin1Buff, "CFFTdata1");
float CFFTin1Buff[CFFT_SIZE*2];
#pragma DATA SECTION(CFFTin2Buff, "CFFTdata2");
float CFFTin2Buff[CFFT_SIZE*2];
#pragma DATA_SECTION(CFFToutBuff, "CFFTdata3");
float CFFToutBuff[CFFT_SIZE*2];
#pragma DATA_SECTION(CFFTF32Coef, "CFFTdata4");
float CFFTF32Coef[CFFT_SIZE];
CFFT_F32_STRUCT cfft;
main()
  cfft.InPtr = CFFTin1Buff; /* Input data buffer
                                                          */
  cfft.OutPtr = CFFToutBuff; /* FFT output buffer
                                                          */
  cfft.CoefPtr = CFFTF32Coef; /* Twiddle factor buffer
                                                          */
  cfft.FFTSize = CFFT SIZE; /* FFT length
                                                          */
  cfft.Stages = CFFT STAGES; /* FFT Stages
                                                          */
  . . . . . .
  CFFT f32 sincostable(&cfft);/* Initialize twiddle
                              /* buffer
                                                          */
  CFFT_f32(&cfft);
                              /* Calculate output
                                                          */
  CFFT_f32_mag(&cfft);
                              /* Calculate Magnitude
                                                          */
  cfft.CurrentOutPtr=CFFTin2Buff;/* Change output buffer*/
  CFFT_f32_phase(&cfft);
                                 /* Calculate phase
```

Benchmark Information:

The following table provides benchmark numbers for the function. Note that these include the cycles used in the call/return from the function.

FFTSize	C-Callable ASM (Cycle Count)		
	Standard Runtime Lib	Fast Runtime Lib	
32	29778	2141	
64	63279	4253	
128	110368	8477	
256	242669	16925	
512	485624	33821	
1024	1002380	67613	

Table 5.8: Benchmark Information

5.6 Complex Fast Fourier Transform Twiddle Factors

Description:

This module generates the twiddle factors used by the complex FFT.

Header File:

```
fpu_cfft.h
```

Declaration:

```
void CFFT_f32_sincostable (CFFT_F32_STRUCT *)
```

Usage:

A pointer to the following structure is passed to the CFFT_f32_sincostable function.It is the same structure described in the CFFT f32 section:

```
typedef struct {
  float32 *InPtr;
  float32 *OutPtr;
  float32 *CoefPtr;
  float32 *CurrentInPtr;
  float32 *CurrentOutPtr;
  Uint16 Stages;
  Uint16 FFTSize;
} CFFT_F32_STRUCT;
```

Table 5.2 describes each element.

Alignment Requirements:

None

Example:

The following sample code obtains the scaled FFT magnitude.

```
#include "fpu\_cfft.h"
#define CFFT STAGES
                        7
#define CFFT_SIZE
                       (1 << CFFT_STAGES)
/* CFFTin1Buff section to 4*FFT_SIZE in the linker file
                                                          */
#pragma DATA_SECTION(CFFTin1Buff, "CFFTdata1");
float CFFTin1Buff[CFFT_SIZE*2];
#pragma DATA_SECTION(CFFToutBuff, "CFFTdata3");
float CFFToutBuff[CFFT_SIZE*2];
#pragma DATA_SECTION(CFFTF32Coef, "CFFTdata4");
float CFFTF32Coef[CFFT_SIZE];
CFFT F32 STRUCT cfft;
main()
  cfft.InPtr = CFFTin1Buff; /* Input data buffer
                                                            */
  cfft.OutPtr = CFFToutBuff; /* FFT output buffer
                                                            */
  cfft.CoefPtr = CFFTF32Coef; /* Twiddle factor buffer
                                                            */
  cfft.FFTSize = CFFT_SIZE; /* FFT length
                                                            */
  cfft.Stages = CFFT_STAGES; /* FFT Stages
                                                            */
  CFFT_f32_sincostable(&cfft); /* Initialize twiddle buffer */
  CFFT_f32(&cfft);
                              /* Calculate output
}
```

Benchmark Information:

The CFFT f32 sincostable function is written in C and not optimized.

5.7 Inverse Complex Fast Fourier Transform

Description:

This module computes a 32-bit floating-point Inverse complex FFT. This version of the function requires input buffer memory alignment.

Header File:

```
fpu cfft.h
```

Declaration:

```
void ICFFT f32 (CFFT F32 STRUCT *)
```

Usage:

A pointer to the following structure is passed to the CFFT_f32 function:

```
typedef struct {
  float32 *InPtr;
  float32 *OutPtr;
  float32 *CoefPtr;
  float32 *CurrentInPtr;
  float32 *CurrentOutPtr;
  Uint16 Stages;
  Uint16 FFTSize;
} CFFT_F32_STRUCT;
```

Table 5.2 describes each element.

Alignment Requirements:

The input buffer must be aligned to a multiple of the *2*FFTSize*sizeof(float)* i.e. *4*FFTSize*. For example, if the **FFTSize** is 256 you must align the buffer corresponding to **InPtr** to 4*256 = 1024. A smaller alignment will not work for a 256 IFFT.

To align the input buffer, use the **DATA_SECTION** pragma to assign the buffer to a code section and then align the buffer to the proper offset in the linker command file. In this code example the buffer is assigned to the INBUF section.

```
#define CFFT_STAGES 8
#define CFFT_SIZE (1 << CFFT_STAGES)

// FFT input data buffer, alignment require
// Output of ICFFT overwrites input if
// CFFT_STAGES is ODD
#pragma DATA_SECTION(CFFTin1Buff, "CFFTdata1")
float32 CFFTin1Buff[CFFT_SIZE*2];</pre>
```

In the project's linker command file, the **INBUF** section is then aligned to a multiple of the FFTSize as shown below:

```
CFFTdata1 : > RAML4, PAGE = 1, ALIGN(1024)
```

The buffers referenced by **InPtr** and **OutPtr** are used in ping-pong fashion. At the first stage of the IFFT InPtr and CurrentInPtr both point to the input buffer and OutPtr and CurrentOutPtr point to the same output buffer. After bit reversing the input and computing the stage 1 butterflies the output is stored at the location pointed to be cfft.CurrentOutPtr. The next step is

to switch the pointer cfft.CurrentInPtr with cfft.CurrentOutPtr so that the output from the n^{th} stage becomes the input to the $n+1^{th}$ stage while the previous (n^{th}) stage's input buffer will be used as the output for the $n+1^{th}$ stage. In this manner the CurrentInPtr and CurrentOutPtr are switched successively for each IFFT stage.Therefore, If the number of stages is odd then at the end of all the coputation we get:

currentInPtr=InPtr, currentOutPtr=OutPtr.

If number of stages is even then,

currentInPtr=OutPtr, currentOutPtr=InPtr.

	Stage3	Stage4	Stage5	 Stage N	
				N = odd	N = even
InPtr (Buf1)	CurrentInPtr	CurrentOutPtr	CurrentInPtr	 CurrentInPtr	CurrentOutPtr
OutPtr (Buf2)	CurrentOutPtr	CurrentInPtr	CurrentOutPtr	 CurrentOutPtr	CurrentInPtr
Result Buf	Buf1	Buf2	Buf1	 Buf1	Buf2

Table 5.9: Input and Output Buffer Pointer Allocations

Notes:

- 1. This function is not re-entrant as it uses global variables to store arguments; these will be overwritten if the function is invoked while it is currently processing.
- 2. If the input buffer is not properly aligned, then the output will be unpredictable.
- 3. All buffers and stack are placed in internal memory (zero-wait states in data space).

Example:

The following sample code obtains the complex FFT of the input.

```
#include "fpu\_cfft.h"
#define CFFT STAGES
#define CFFT_SIZE
                      (1 << CFFT_STAGES)
/* CFFTin1Buff section to 4*FFT_SIZE in the linker file
                                                           */
#pragma DATA_SECTION(CFFTin1Buff, "CFFTdata1");
float CFFTin1Buff[CFFT_SIZE*2];
#pragma DATA SECTION(CFFToutBuff, "CFFTdata2");
float CFFTin2Buff[CFFT_SIZE*2];
#pragma DATA_SECTION(CFFTF32Coef, "CFFTdata4");
float CFFTF32Coef[CFFT_SIZE];
CFFT F32 STRUCT cfft;
main()
  cfft.InPtr = CFFTin1Buff; /* Input data buffer
                                                            */
  cfft.OutPtr = CFFToutBuff; /* FFT output buffer
                                                            */
  cfft.CoefPtr = CFFTF32Coef; /* Twiddle factor buffer
                                                            */
  cfft.FFTSize = CFFT_SIZE; /* FFT length
                                                            */
  cfft.Stages = CFFT_STAGES; /* FFT Stages
                                                            */
  CFFT_f32_sincostable(&cfft); /* Initialize twiddle buffer */
  CFFT_f32(&cfft); /* Calculate output
                                                            */
  . . . . . .
  ICFFT f32(&cfft);
                             /* Calculate Inverse FFT
                                                           */
```

Benchmark Information:

The following table provides benchmark numbers for the function. Note that these include the cycles used in the call/return from the function

FFTSize	C-Callable ASM (Cycle Count)
32	1370
64	2803
128	5948
256	12837
512	27854
1024	60411

Table 5.10: Benchmark Information

5.8 Real Fast Fourier Transform

Description:

This module computes a 32-bit floating-point real FFT including input bit reversing. This version of the function requires input buffer memory alignment. If you do not wish to align the input buffer, then use the **RFFT_f32u** function.

Header File:

```
fpu rfft.h
```

Declaration:

```
void RFFT_f32 (RFFT_F32_STRUCT *)
```

Usage:

A pointer to the following structure is passed to the RFFT f32 function:

```
typedef struct {
  float32 *InBuf;
  float32 *OutBuf;
  float32 *CosSinBuf;
  float32 *MagBuf;
  float32 *PhaseBuf;
  Uint16 FFTSize;
  Uint16 FFTStages;
} RFFT_F32_STRUCT;
```

Table 5.11 describes each element.

Alignment Requirements:

The input buffer must be aligned to a multiple of the 2*FFTSize. For example, if the FFTSize is 256 you must align the buffer corresponding to **InBuf** to 2*256 = 512. A smaller alignment will not work for a 256 RFFT.

To align the input buffer, use the **DATA_SECTION** pragma to assign the buffer to a code section and then align the buffer to the proper offset in the linker command file. In this code example the buffer is assigned to the **INBUF** section.

```
#define RFFT_STAGES 8
#define RFFT_SIZE (1 << RFFT_STAGES)

//Buffer alignment for the input array,
//RFFT_f32u (optional), RFFT_f32 (required)
//Output of FFT overwrites input if
//RFFT_STAGES is ODD
#pragma DATA_SECTION(RFFTin1Buff, "RFFTdata1");
float32 RFFTin1Buff[RFFT_SIZE];</pre>
```

In the project's linker command file, the **RFFTdata1** section is then aligned to a multiple of the **FFTSize** as shown below:

```
RFFTdata1 : > RAML4, PAGE = 1, ALIGN(512)
```

Item	Description	Format	Comment
InBuf	Input data	Pointer to 32-bit float array	Input buffer alignment is required. Re-
			fer to the alignment section.
OutBuf	Output buffer	Pointer to 32-bit float array	Result of RFFT_f32. This buffer can
			then be used as the input to the magni-
			tude and phase calculations. The out-
			put order for FFTSize = N is:
			OutBuf[0] = real[0]
			OutBuf[1] = real[1]
			OutBuf[2] = real[2]
			• • •
			OutBuf[N/2] = real[N/2]
			OutBuf[N/2+1] = imag[N/2-1]
			• • •
			OutBuf[N-3] = imag[3]
			OutBuf[N-2] = imag[2]
			OutBuf[N-1] = imag[1]
CooCimPut	Tividalla factava	Deinter to 20 hit fleet error	Coloulata
CosSinBuf	Twiddle factors	Pointer to 32-bit float array	Calculate using
FFTSize	FFT size	Uint16	RFFT_f32_sincostable().
FFTSIZE	FFT SIZE	UINTIB	Must be a power of 2 greater than or
FFTCtoroo	Niveshau of atomos	Uint16	equal to 32.
FFTStages	Number of stages	=	Stages = log2(FFTSize)
MagBuf	Magnitude buffer	Pointer to 32-bit float array	Output from the magnitude calculation
			if the magnitude functions is called.
DhasaDirt	Dhasa buffer	Deinter to 00 hit fleet	FFTSize/2 in length.
PhaseBuf	Phase buffer	Pointer to 32-bit float array	Output from the phase calculation if the
			phase function is called. FFTSize/2 in
			length.

Table 5.11: Elements of the Data Structure

Notes:

- 1. If the input buffer is not properly aligned, then the output will be unpredictable.
- 2. If you do not wish to align the input buffer, then you must use the RFFT_f32u function. This version of the function does not have any input buffer alignment requirements. Using RFFT_f32u will, however, result in a lower cycle performance.
- 3. All buffers and stack are placed in internal memory (zero-wait states in data space).

The following sample code obtains the FFT of the real input.

```
#include "fpu\_rfft.h"
#define RFFT STAGES
#define RFFT_SIZE
                       (1 << RFFT_STAGES)
/* RFFTin1Buff section to 2*FFT_SIZE in the linker file
                                                                */
#pragma DATA_SECTION(RFFTin1Buff, "RFFTdata1");
float32 RFFTin1Buff[RFFT_SIZE];
#pragma DATA SECTION(RFFToutBuff, "RFFTdata2");
float32 RFFToutBuff[RFFT_SIZE];
#pragma DATA_SECTION(RFFTmagBuff, "RFFTdata3");
float32 RFFTmagBuff[RFFT_SIZE/2+1];
#pragma DATA_SECTION(RFFTF32Coef, "RFFTdata4");
float32 RFFTF32Coef[RFFT SIZE];
RFFT_F32_STRUCT rfft;
main()
    rfft.FFTSize
                 = RFFT SIZE;
    rfft.FFTStages = RFFT_STAGES;
    rfft.InBuf
                 = &RFFTin1Buff[0]; /* Input buffer
                 = &RFFToutBuff[0]; /* Output buffer
    rfft.OutBuf
                                                                */
    rfft.CosSinBuf = &RFFTF32Coef[0]; /* Twiddle factor buffer */
                = &RFFTmagBuff[0]; /* Magnitude buffer
    rfft.MagBuf
    RFFT_f32_sincostable(&rfft); /* Calculate twiddle factor */
    RFFT f32(&rfft);
                                    /* Calculate output
                                                                */
```

Benchmark Information:

The following table provides benchmark numbers for the function. Note that these include the cycles used in the call/return from the function.

FFTSize	C-Callable ASM (Cycle Count)
32	611
64	1277
128	2775
256	6145
512	13675
1024	30357
2048	67007

Table 5.12: Benchmark Information

5.9 Real Fast Fourier Transform (Unaligned)

Description:

This module computes a 32-bit floating-point real FFT including input bit reversing. This version of the function does not have any buffer alignment requirements. If you can align the input buffer, then use the **RFFT_f32** function for improved performance.

Header File:

```
fpu rfft.h
```

Declaration:

```
void RFFT_f32u (RFFT_F32_STRUCT *)
```

Usage:

A pointer to the following structure is passed to the RFFT_f32u function. It is the same structure described in the RFFT_f32 section:

```
typedef struct {
  float32 *InBuf;
  float32 *OutBuf;
  float32 *CosSinBuf;
  float32 *MagBuf;
  float32 *PhaseBuf;
  Uint16 FFTSize;
  Uint16 FFTStages;
} RFFT_F32_STRUCT;
```

Table 5.11 describes each element with the exception that the **input buffer does not require alignment**.

Alignment Requirements:

None

Notes:

- 1. If you can align the input buffer to a 2*FFTSize, then consider using the RFFT_f32 function which has input buffer alignment requirements, but it is more cycle efficient
- 2. All buffers and stack are placed in internal memory (zero-wait states in data space).

The following sample code obtains the FFT of the real input.

```
#include "fpu\_rfft.h"
#define RFFT STAGES
#define RFFT_SIZE
                       (1 << RFFT_STAGES)
/* RFFTin1Buff section to 2*FFT_SIZE in the linker file
                                                                */
#pragma DATA_SECTION(RFFTin1Buff, "RFFTdata1");
float32 RFFTin1Buff[RFFT_SIZE];
#pragma DATA SECTION(RFFToutBuff, "RFFTdata2");
float32 RFFToutBuff[RFFT_SIZE];
#pragma DATA_SECTION(RFFTmagBuff, "RFFTdata3");
float32 RFFTmagBuff[RFFT_SIZE/2+1];
#pragma DATA_SECTION(RFFTF32Coef, "RFFTdata4");
float32 RFFTF32Coef[RFFT SIZE];
RFFT_F32_STRUCT fft;
main()
    rfft.FFTSize
                 = RFFT SIZE;
    rfft.FFTStages = RFFT_STAGES;
    rfft.InBuf
                 = &RFFTin1Buff[0]; /* Input buffer
                 = &RFFToutBuff[0]; /* Output buffer
    rfft.OutBuf
                                                                */
    rfft.CosSinBuf = &RFFTF32Coef[0]; /* Twiddle factor buffer */
                = &RFFTmagBuff[0]; /* Magnitude buffer
    rfft.MagBuf
    RFFT_f32_sincostable(&rfft); /* Calculate twiddle factor
                                                                */
    RFFT_f32u(&rfft);
                                   /* Calculate output
                                                                */
```

Benchmark Information:

The following table provides benchmark numbers for the function. Note that these include the cycles used in the call/return from the function.

FFTSize	C-Callable ASM (Cycle Count)
32	667
64	1389
128	2999
256	6593
512	14571
1024	32149
2048	70591

Table 5.13: Benchmark Information

5.10 Real Fast Fourier Transform with ADC Input

Description:

This module computes a 32-bit floating-point real FFT with 12-bit ADC input including input bit reversing. This version of the function requires input buffer memory alignment. If you do not wish to align the input buffer, then use the **RFFT_adc_f32u** function.

Header File:

fpu rfft.h

Declaration:

```
void RFFT_adc_f32 (RFFT_ADC_F32_STRUCT *)
```

Usage:

A pointer to the following structure is passed to the RFFT adc f32 function:

```
typedef struct {
 Uint16
         *InBuf;
 void
           *Tail;
} RFFT_ADC_F32_STRUCT;
typedef struct {
 float32 *InBuf;
 float32 *OutBuf;
 float32 *CosSinBuf;
 float32 *MagBuf;
 float32 *PhaseBuf;
          FFTSize;
 Uint16
 Uint16
           FFTStages;
} RFFT_F32_STRUCT;
```

Table 5.14 describes each element of the structure RFFT_ADC_F32_STRUCT and table 5.15 describes the elements of RFFT_F32_STRUCT, but note that its **InBuf** pointer is not used.

Item	Description	Format	Comment
InBuf	Input data	Pointer to 16-bit Uint16 array	Input buffer alignment is required. Refer to the alignment section.
Tail	Input structure	Null pointer to RFFT_F32_STRUCT	Null pointer is passed to OutBuf of RFFT_F32_STRUCT.

Table 5.14: Elements of the Data Structure RFFT_ADC_F32_STRUCT

Alignment Requirements:

The input buffer must be aligned to a multiple of the 2*FFTSize. For example, if the FFTSize is 512 you must align the buffer corresponding to **InBuf** to 2*512 = 1024. A smaller alignment will not work.

To align the input buffer, use the **DATA_SECTION** pragma to assign the buffer to a code section and then align the buffer to the proper offset in the linker command file. In this code example the buffer is assigned to the **INBUF** section.

Item	Description	Format	Comment
InBuf	Input data	Pointer to 32-bit float array	Not Used.
OutBuf	Output buffer	Pointer to 32-bit float array	Result of RFFT_adc_f32. This buffer is then used as the input to the magni-
			tude and phase calculations. The output order for FFTSize = N is:
			OutBuf[0] = real[0] OutBuf[1] = real[1]
			OutBuf[2] = real[2]
			OutBuf[N/2] = real[N/2]
			OutBuf[$N/2$] = rear[$N/2$] OutBuf[$N/2+1$] = imag[$N/2-1$]
			OutBuf[N-3] = imag[3]
			OutBuf $[N-2] = imag[2]$
			OutBuf[N-1] = imag[1]
CosSinBuf	Twiddle factors	Pointer to 32-bit float array	Calculate using
			RFFT_f32_sincostable().
FFTSize	FFT size	Uint16	Must be a power of 2 greater than or
			equal to 32.
FFTStages	Number of stages	Uint16	Stages = log2(FFTSize)
MagBuf	Magnitude buffer	Pointer to 32-bit float array	Output from the magnitude calculation
			if the magnitude functions is called. FFTSize/2 in length.
PhaseBuf	Phase buffer	Pointer to 32-bit float array	Output from the phase calculation if the
			phase function is called. FFTSize/2 in length.

Table 5.15: Elements of the Data Structure RFFT_F32_STRUCT

```
#define RFFT_STAGES 9
#define RFFT_SIZE (1 << RFFT_STAGES)

//Buffer alignment for the input array,
//RFFT_adc_f32u (optional) RFFT_adc_f32 (required)
//Output of FFT overwrites input if
//RFFT_STAGES is ODD
#pragma DATA_SECTION(RFFTin1Buff, "RFFTdata1");
float32 RFFTin1Buff[RFFT_SIZE];</pre>
```

In the project's linker command file, the **RFFTdata1** section is then aligned to a multiple of the **FFTSize** as shown below:

```
RFFTdata1 : > RAML4, PAGE = 1, ALIGN(1024)
```

Notes:

- 1. If the input buffer is not properly aligned, then the output will be unpredictable.
- 2. If you do not wish to align the input buffer, then you must use the RFFT_adc_f32u function which does not have any input buffer alignment requirements. Using RFFT_adc_f32u will, however, result in a lower cycle performance.
- 3. All buffers and stack are placed in internal memory (zero-wait states in data space).

The following sample code obtains the FFT of the real input.

```
#include "fpu\_rfft.h"
#define RFFT STAGES
#define RFFT_SIZE
                       (1 << RFFT_STAGES)
RFFT_ADC_F32_STRUCT rfft_adc;
RFFT_F32_STRUCT rfft;
/* RFFTin1Buff section to 2*FFT SIZE in the linker file
                                                                      */
#pragma DATA_SECTION(RFFTin1Buff, "RFFTdata1");
float32 RFFTin1Buff[RFFT_SIZE];
#pragma DATA_SECTION(RFFToutBuff, "RFFTdata2");
float32 RFFToutBuff[RFFT_SIZE];
#pragma DATA SECTION(RFFTmagBuff, "RFFTdata3");
float32 RFFTmagBuff[RFFT_SIZE/2+1];
#pragma DATA_SECTION(RFFTF32Coef, "RFFTdata4");
float32 RFFTF32Coef[RFFT_SIZE];
main()
{
  rfft_adc.Tail = &rfft.OutBuf; /* Tail is passed to OutBuf
                                                                      */
  rfft.FFTSize = RFFT_SIZE;
                                    /* FFT size
                                                                      */
  rfft.FFTStages = RFFT_STAGES;
                                   /* FFT stages
                                                                      */
  rfft_adc.InBuf = &RFFTin1Buff[0]; /* Input buffer 12-bit ADC input */
  rfft.OutBuf = &RFFToutBuff[0]; /* Output buffer
                                                                      */
  rfft.CosSinBuf = &RFFTF32Coef[0]; /* Twiddle factor
                                                                      */
  rfft.MagBuf = &RFFTmagBuff[0]; /* Magnitude output buffer
                                                                      */
  . . . . . . .
  RFFT_f32_sincostable(&rfft) /* Initialize twiddle buffer
                                                                      */
  RFFT_adc_f32(&rfft);
                                    /* Calculate output
                                                                      */
```

Benchmark Information:

The following table provides benchmark numbers for the function:

FFTSize	C-Callable ASM (Cycle Count)
32	628
64	1290
128	2764
256	6054
512	13360
1024	29466
2048	64709

Table 5.16: Benchmark Information

5.11 Real Fast Fourier Transform with ADC Input (Unaligned)

Description:

This module computes a 32-bit floating-point real FFT with 12-bit ADC input including input bit reversing. This version of the function does not have any buffer alignment requirements. If you can align the input buffer, then use the **RFFT_adc_f32** function for improved performance.

Header File:

fpu rfft.h

Declaration:

```
void RFFT_adc_f32u (RFFT_F32_STRUCT *)
```

Usage:

A pointer to the following structure is passed to the RFFT adc f32u function:

```
typedef struct {
 Uint16 *InBuf;
 void
           *Tail;
} RFFT_ADC_F32_STRUCT;
typedef struct {
 float32 *InBuf;
 float32 *OutBuf;
 float32 *CosSinBuf;
 float32 *MagBuf;
 float32 *PhaseBuf;
          FFTSize;
 Uint16
 Uint16
          FFTStages;
} RFFT_F32_STRUCT;
```

Table 5.14 describes each element of the structure RFFT_ADC_F32_STRUCT and table 5.15 describes the elements of RFFT_F32_STRUCT, but note that its **InBuf** pointer is not used.

Alignment Requirements:

None

Notes:

- 1. If you can align the input buffer to a 2*FFTSize, then consider using the RFFT_adc_f32 function. This version of the function has input buffer alignment requirements, but it is more cycle efficient
- 2. All buffers and stack are placed in internal memory (zero-wait states in data space).

The following sample code obtains the FFT of the real input.

```
#include "fpu\_rfft.h"
#define RFFT STAGES
#define RFFT_SIZE
                       (1 << RFFT_STAGES)
RFFT_ADC_F32_STRUCT rfft_adc;
RFFT_F32_STRUCT rfft;
/* RFFTin1Buff section to 2*FFT SIZE in the linker file
                                                                      */
#pragma DATA_SECTION(RFFTin1Buff, "RFFTdata1");
float32 RFFTin1Buff[RFFT_SIZE];
#pragma DATA_SECTION(RFFToutBuff, "RFFTdata2");
float32 RFFToutBuff[RFFT_SIZE];
#pragma DATA SECTION(RFFTmagBuff, "RFFTdata3");
float32 RFFTmagBuff[RFFT_SIZE/2+1];
#pragma DATA_SECTION(RFFTF32Coef, "RFFTdata4");
float32 RFFTF32Coef[RFFT_SIZE];
main()
{
  rfft_adc.Tail = &rfft.OutBuf; /* Tail is passed to OutBuf
                                                                      */
  rfft.FFTSize = RFFT_SIZE;
                                    /* FFT size
                                                                      */
  rfft.FFTStages = RFFT_STAGES;
                                    /* FFT stages
                                                                      */
  rfft_adc.InBuf = &RFFTin1Buff[0]; /* Input buffer 12-bit ADC input */
  rfft.OutBuf = &RFFToutBuff[0]; /* Output buffer
                                                                      */
  rfft.CosSinBuf = &RFFTF32Coef[0]; /* Twiddle factor
                                                                      */
  rfft.MagBuf = &RFFTmagBuff[0]; /* Magnitude output buffer
                                                                      */
  . . . . . . .
  RFFT_f32_sincostable(&rfft) /* Initialize twiddle buffer
                                                                      */
  RFFT_adc_f32u(&rfft);
                                    /* Calculate output
                                                                      */
```

Benchmark Information:

The following table provides benchmark numbers for the function:

FFTSize	C-Callable ASM (Cycle Count)
32	698
64	1444
128	3102
256	6792
512	14962
1024	31387
2048	68549

Table 5.17: Benchmark Information

5.12 Real Fast Fourier Transform Magnitude

Description:

This module computes the real FFT magnitude. The output from **RFFT_f32_mag** matches the magnitude output from the FFT found in common mathematics software and Code Composer Studio FFT graphs.

If instead a normalized magnitude like that performed by the fixed-point TMS320C28x IQmath FFT library is required, then the **RFFT_f32s_mag** function can be used. In fixed-point algorithms scaling is performed to avoid overflowing data. Floating-point calculations do not need this scaling to avoid overflow and therefore the **RFFT_f32_mag** function can be used instead.

Header File:

fpu_rfft.h

Declaration:

```
void RFFT_f32_mag (RFFT_F32_STRUCT *)
```

Usage:

A pointer to the following structure is passed to the RFFT_f32_mag function. It is the same structure described in the RFFT_f32 section:

```
typedef struct {
  float32 *InBuf;
  float32 *OutBuf;
  float32 *CosSinBuf;
  float32 *MagBuf;
  float32 *PhaseBuf;
  Uint16 FFTSize;
  Uint16 FFTStages;
} RFFT_F32_STRUCT;
```

Table 5.11 describes each element.

Alignment Requirements:

None

Notes:

- 1. All buffers and stack are placed in internal memory (zero-wait states in data space).
- 2. The magnitude calculation calls the sqrt function within the runtime-support library. The magnitude function has not been optimized at this time.
- 3. The use of the sqrt function in the FPUfastRTS library will speed up this routine. The example for the CFFT has an alternate build configuration (Debug_FASTRTS) where the rts2800_fpu32_fast_supplement.lib is used in place of the standard runtime library rts2800_fpu32.lib.

The following sample code obtains the FFT magnitude.

```
include "fpu\_rfft.h"
#define RFFT STAGES
#define RFFT_SIZE
                       (1 << RFFT_STAGES)
/* RFFTin1Buff section to 2*FFT_SIZE in the linker file
                                                                */
#pragma DATA_SECTION(RFFTin1Buff, "RFFTdata1");
float32 RFFTin1Buff[RFFT_SIZE];
#pragma DATA SECTION(RFFToutBuff, "RFFTdata2");
float32 RFFToutBuff[RFFT_SIZE];
#pragma DATA_SECTION(RFFTmagBuff, "RFFTdata3");
float32 RFFTmagBuff[RFFT_SIZE/2+1];
#pragma DATA_SECTION(RFFTF32Coef, "RFFTdata4");
float32 RFFTF32Coef[RFFT SIZE];
RFFT_F32_STRUCT rfft;
main()
    rfft.FFTSize = RFFT SIZE;
    rfft.FFTStages = RFFT_STAGES;
    rfft.InBuf = &RFFTin1Buff[0]; /* Input buffer
    rfft.OutBuf = &RFFToutBuff[0]; /* Output buffer
                                                                */
    rfft.CosSinBuf = &RFFTF32Coef[0]; /* Twiddle factor buffer */
    rfft.MagBuf = &RFFTmagBuff[0]; /* Magnitude buffer
    RFFT_f32_sincostable(&rfft); /* Calculate twiddle factor */
    RFFT_f32(&rfft);
                                  /* Calculate output
                                                                */
                                  /* Calculate magnitude
    RFFT_f32_mag(&rfft)
                                                                */
```

Benchmark Information:

The following table provides benchmark numbers for the function. Note that these include the cycles used in the call/return from the function.

FFTSize	C-Callable ASM (Cycle Count)		
	Standard Runtime Lib	Fast Runtime Lib	
32	1324	694	
64	2654	1382	
128	5342	2758	
256	10718	5510	
512	21470	11014	
1024	42974	22022	
2048	85982	44038	

Table 5.18: Benchmark Information

5.13 Real Fast Fourier Transform Magnitude (Scaled)

Description:

This module computes the scaled real FFT magnitude. The scaling is $\frac{1}{[2^{FFT}_STAGES-1]}$, and is done to match the normalization performed by the fixed-point TMS320C28x IQmath FFT library for overflow avoidance. Floating-point calculations do not need this scaling to avoid overflow and therefore the **RFFT_f32_mag** function can be used instead. The output from **RFFT_f32s_mag** matches the magnitude output from the FFT found in common mathematics software and Code Composer Studio FFT graphs.

Header File:

fpu rfft.h

Declaration:

```
void RFFT_f32s_mag (RFFT_F32_STRUCT *)
```

Usage

A pointer to the following structure is passed to the RFFT_f32s_mag function. It is the same structure described in the **RFFT f32** section:

```
typedef struct {
  float32 *InBuf;
  float32 *OutBuf;
  float32 *CosSinBuf;
  float32 *MagBuf;
  float32 *PhaseBuf;
  Uint16 FFTSize;
  Uint16 FFTStages;
} RFFT_F32_STRUCT;
```

Table 5.11 describes each element.

Alignment Requirements:

None

Notes:

- 1. All buffers and stack are placed in internal memory (zero-wait states in data space).
- 2. The magnitude calculation calls the sqrt function within the runtime-support library. The magnitude function has not been optimized at this time.
- The use of the sqrt function in the FPUfastRTS library will speed up this routine. The
 example for the CFFT has an alternate build configuration (Debug_FASTRTS) where
 the rts2800_fpu32_fast_supplement.lib is used in place of the standard runtime library rts2800_fpu32.lib.

The following sample code obtains the FFT magnitude.

```
include "fpu\_rfft.h"
#define RFFT STAGES
#define RFFT_SIZE
                       (1 << RFFT_STAGES)
/* RFFTin1Buff section to 2*FFT_SIZE in the linker file
                                                                */
#pragma DATA_SECTION(RFFTin1Buff, "RFFTdata1");
float32 RFFTin1Buff[RFFT_SIZE];
#pragma DATA SECTION(RFFToutBuff, "RFFTdata2");
float32 RFFToutBuff[RFFT_SIZE];
#pragma DATA_SECTION(RFFTmagBuff, "RFFTdata3");
float32 RFFTmagBuff[RFFT_SIZE/2+1];
#pragma DATA_SECTION(RFFTF32Coef, "RFFTdata4");
float32 RFFTF32Coef[RFFT SIZE];
RFFT_F32_STRUCT rfft;
main()
    rfft.FFTSize = RFFT SIZE;
    rfft.FFTStages = RFFT_STAGES;
    rfft.InBuf
                 = &RFFTin1Buff[0]; /* Input buffer
    rfft.OutBuf
                 = &RFFToutBuff[0]; /* Output buffer
                                                                */
    rfft.CosSinBuf = &RFFTF32Coef[0]; /* Twiddle factor buffer */
    rfft.MagBuf = &RFFTmagBuff[0]; /* Magnitude buffer
    RFFT_f32_sincostable(&rfft); /* Calculate twiddle factor */
    RFFT_f32(&rfft);
                                  /* Calculate output
                                                                */
                                  /* Calculate magnitude
    RFFT_f32s_mag(&rfft)
```

Benchmark Information:

The following table provides benchmark numbers for the function. Note that these include the cycles used in the call/return from the function.

FFTSize	C-Callable ASM (Cycle Count)		
	Standard Runtime Lib	Fast Runtime Lib	
32	1367	737	
64	2749	1447	
128	5507	2861	
256	11017	5683	
512	22031	11321	
1024	44053	22591	
2048	88091	45125	

Table 5.19: Benchmark Information

5.14 Real Fast Fourier Transform Phase

Description:

This module computes FFT Phase.

Header File:

fpu_rfft.h

Declaration:

```
void RFFT_f32_phase (RFFT_F32_STRUCT *)
```

Usage:

A pointer to the following structure is passed to the RFFT_f32_phase function. It is the same structure described in the **RFFT f32** section:

```
typedef struct {
  float32 *InBuf;
  float32 *OutBuf;
  float32 *CosSinBuf;
  float32 *MagBuf;
  float32 *PhaseBuf;
  Uint16 FFTSize;
  Uint16 FFTStages;
} RFFT_F32_STRUCT;
```

Table 5.11 describes each element.

Alignment Requirements:

None

Notes:

- 1. All buffers and stack are placed in internal memory (zero-wait states in data space).
- 2. The phase function calls the atan2 function in the runtime-support library. The phase function has not been optimized at this time.
- 3. The use of the atan2 function in the FPUfastRTS library will speed up this routine. The example for the CFFT has an alternate build configuration (Debug_FASTRTS) where the rts2800_fpu32_fast_supplement.lib is used in place of the standard runtime library rts2800_fpu32.lib.

The following sample code obtains the FFT phase.

```
include "fpu\_rfft.h"
#define RFFT STAGES
#define RFFT_SIZE
                      (1 << RFFT_STAGES)
/* RFFTin1Buff section to 2*FFT_SIZE in the linker file
                                                               */
#pragma DATA_SECTION(RFFTin1Buff, "RFFTdata1");
float32 RFFTin1Buff[RFFT_SIZE];
#pragma DATA_SECTION(RFFToutBuff, "RFFTdata2");
float32 RFFToutBuff[RFFT_SIZE];
#pragma DATA_SECTION(RFFTmagBuff, "RFFTdata3");
float32 RFFTphaseBuff[RFFT_SIZE/2+1];
#pragma DATA_SECTION(RFFTF32Coef, "RFFTdata4");
float32 RFFTF32Coef[RFFT SIZE];
main()
   rfft.FFTSize = RFFT_SIZE;
   rfft.FFTStages = RFFT_STAGES;
    rfft.InBuf
                 = &RFFTin1Buff[0]; /* Input buffer
                                                               */
    rfft.OutBuf
                 = &RFFToutBuff[0]; /* Output buffer
    rfft.CosSinBuf = &RFFTF32Coef[0]; /* Twiddle factor buffer */
    rfft.PhaseBuf = &RFFTphaseBuff[0];/* Phase buffer
   RFFT_f32_sincostable(&rfft); /* Calculate twiddle factor */
                                  /* Calculate output
   RFFT f32(&rfft);
                                                               */
   RFFT_f32_phase(&rfft)
                                  /* Calculate phase
                                                               */
```

Benchmark Information:

The following table provides benchmark numbers for the function. Note that these include the cycles used in the call/return from the function.

FFTSize	C-Callable ASM (Cycle Count)		
	Standard Runtime Lib	Fast Runtime Lib	
32	14909	1105	
64	29096	2152	
128	59381	4239	
256	106114	8406	
512	237106	16733	
1024	479424	33380	
2048	852535	66667	

Table 5.20: Benchmark Information

5.15 Real Fast Fourier Transform Twiddle Factors

Description:

This module generates the twiddle factors used by the real FFT.

Header File:

fpu_rfft.h

Declaration:

```
void RFFT_f32_sincostable (RFFT_F32_STRUCT *)
```

Usage:

A pointer to the following structure is passed to the RFFT_f32_sincostable function. It is the same structure described in the **RFFT f32** section:

```
typedef struct {
  float32 *InBuf;
  float32 *OutBuf;
  float32 *CosSinBuf;
  float32 *MagBuf;
  float32 *PhaseBuf;
  Uint16 FFTSize;
  Uint16 FFTStages;
} RFFT_F32_STRUCT;
```

Table 5.11 describes each element.

Alignment Requirements:

None

The following sample code obtains the FFT phase.

```
#include "fpu\_rfft.h"
#define RFFT STAGES
#define RFFT_SIZE
                      (1 << RFFT_STAGES)
/* RFFTin1Buff section to 2*FFT_SIZE in the linker file
                                                                */
#pragma DATA_SECTION(RFFTin1Buff, "RFFTdata1");
float32 RFFTin1Buff[RFFT_SIZE];
#pragma DATA_SECTION(RFFToutBuff, "RFFTdata2");
float32 RFFToutBuff[RFFT_SIZE];
#pragma DATA_SECTION(RFFTmagBuff, "RFFTdata3");
float32 RFFTmagBuff[RFFT_SIZE/2+1];
#pragma DATA_SECTION(RFFTF32Coef, "RFFTdata4");
float32 RFFTF32Coef[RFFT SIZE];
RFFT_F32_STRUCT rfft;
main()
    rfft.FFTSize = RFFT SIZE;
    rfft.FFTStages = RFFT_STAGES;
    rfft.InBuf = &RFFTin1Buff[0]; /* Input buffer
    rfft.OutBuf = &RFFToutBuff[0]; /* Output buffer
                                                                */
    rfft.CosSinBuf = &RFFTF32Coef[0]; /* Twiddle factor buffer */
    rfft.MagBuf = &RFFTmagBuff[0]; /* Magnitude buffer
    RFFT_f32_sincostable(&rfft); /* Calculate twiddle factor */
    RFFT_f32(&rfft);
                                  /* Calculate output
                                                                */
```

Benchmark Information:

The RFFT f32 sincostable function is written in C and not optimized.

5.16 Finite Impulse Response Filter

Description:

This routine implements the non-recursive difference equation of an all-zero filter (FIR), of order N. All the coefficients of all-zero filter are assumed to be less than 1 in magnitude. This routine requires the -c2xlp_src_compatible option to be enabled in the file specific properties.

Header File:

fpu filter.h

Declaration:

```
void FIR_FP_calc(FIR_FP_handle)
```

Usage:

A pointer to the following structure is passed to the FIR_f32 function:

```
typedef struct {
  float *coeff_ptr;
  float *dbuffer_ptr;
  int cbindex;
  int order;
  float input;
  float output;
  void (*init)(void *);
  void (*calc)(void *);
}FIR_FP;
```

Table 5.21 describes each element

Item	Description	Format	Comment
coeff_ptr	Pointer to Filter coefficient	Pointer to 32-bit float array	Place the coefficients in a section (e.g.
			"coeffilt") aligned to 2x number of coef-
			ficients
dbuffer_ptr	Delay buffer ptr	Pointer to 32-bit float array	Place the Delay in a section (e.g.
			"firldb") aligned to an even number of
			words
cbindex	Circular Buffer Index	Uint16	Index to the delay buffer
order	Order of the Filter	Uint16	Order is number of coefficients minus
			one
input	Latest Input sample	32-bit float	can be assigned to an ADC input
output	Filter Output	32-bit float	
*init	Pointer to Init funtion	n/a	Points to FIR_FP_init
*calc	Pointer to calc funtion	n/a	Points to FIR_FP_calc

Table 5.21: Elements of the Data Structure

Alignment Requirements:

The delay and coefficients buffer must be aligned to a minimum of $2 \times (\text{order} + 1)$ words. For example, if the filter order is 31, it will have 32 taps or coefficients each a 32-bit floating point value. A minimum of $(2 \times 32) = 64$ words will need to be allocated for the delay and coefficients buffer.

To align the buffer, use the **DATA_SECTION** pragma to assign the buffer to a code section and then align the buffer to the proper offset in the linker command file. In this code example the buffer is assigned to the **firldb** section while the coefficients are assigned to the **coefffilt** section.

```
#define FIR_ORDER 31
#pragma DATA_SECTION(dbuffer, "firldb")
float dbuffer[FIR_ORDER+1];

#pragma DATA_SECTION(coeff, "coefffilt");
float const coeff[FIR_ORDER+1] = FIR_FP_LPF32;
```

In the project's linker command file, the **firldb** section is then aligned to a value greater or equal to the minimum required as shown below:

```
firldb ALIGN(0x100) > RAML0 PAGE = 0 coefffilt ALIGN(0x100) > RAML2 PAGE = 0
```

Notes:

1. All buffers and stack are placed in internal memory (zero-wait states in data space).

The following sample code obtains the FIR response to a sample input.

```
#include fpu\_filter.h
#define FIR ORDER
                           31
#define SIGNAL_LENGTH
                         (FIR\_ORDER + 1) *2*2
#pragma DATA_SECTION(firFP, "firfilt")
FIR_FP firFP = FIR_FP_DEFAULTS;
#pragma DATA SECTION(dbuffer, "firldb")
float dbuffer[FIR_ORDER+1];
#pragma DATA_SECTION(sigIn, "sigIn");
#pragma DATA_SECTION(sigOut, "sigOut");
float sigIn[SIGNAL LENGTH];
float sigOut[SIGNAL_LENGTH];
#pragma DATA_SECTION(coeff, "coefffilt");
float const coeff[FIR_ORDER+1] = FIR_FP_LPF32;
float
        RadStep = 0.062831853071f;
float RadStep2 = 2.073451151f;
float Rad
             = 0.0f;
float Rad2
               = 0.0f;
float xn, yn;
int count = 0;
void main()
    unsigned int i;
    /* FIR Generic Filter Initialisation
    firFP.order=FIR_ORDER;
    firFP.dbuffer_ptr=dbuffer;
    firFP.coeff_ptr=(float *)coeff;
    firFP.init(&firFP);
    for(i=0; i < SIGNAL_LENGTH; i++)</pre>
      xn=0.5*sin(Rad) + 0.5*sin(Rad2); //Q15
      sigIn[i]=xn;
      firFP.input= xn;
      firFP.calc(&firFP);
      yn = firFP.output;
      sigOut[i]=yn;
      Rad = Rad + RadStep;
      Rad2 = Rad2 + RadStep2;
}
```

Benchmark Information:

The number of cycles is given by the following equation:

$$Number\ of\ Cycles\ =\ filter_order + 52$$

The following table provides benchmark numbers for the function. Note that these include the cycles used in the call/return from the function.

FIR order	C-Callable ASM (Cycle Count)
31	82
63	114
127	178
255	306
511	562

Table 5.22: Benchmark Information

5.17 Absolute Value of a Complex Vector

Description:

This module computes the absolute value of a complex vector. If N is even, use abs_SP_CV_2() for better performance.

$$Y[i] = \sqrt{(X_{re}[i]^2 + X_{im}[i]^2)}$$

Header File:

fpu_vector.h

Declaration:

```
void abs_SP_CV(float32 *y, const complex_float *x, const Uint16 N)
Usage:
   abs_SP_CV(x, y, N);
```

float32 *y

output array

complex_float *x

input array

Uint16 N

length of x and y arrays

The type "complex_float" is defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part

Alignment Requirements:

None

Example:

```
#include "fpu\_vector.h"
#define N 10
float32 y[N];
complex_float x[N];

main()
{
   abs_SP_CV(y, x, N);  // complex absolute value}
```

Benchmark Information:

Number of Cycles = 28*N+9 cycles (including the call and return)

5.18 Absolute Value of an Even Length Complex Vector

Description:

This module computes the absolute value of an even length complex vector.

$$Y[i] = \sqrt{(X_{re}[i]^2 + X_{im}[i]^2)}$$

Header File:

fpu_vector.h

Declaration:

```
void abs_SP_CV_2(float32 *y, const complex_float *x, const Uint16 N)
```

Usage:

```
abs_SP_CV_2(x, y, N);

float32 *y
output array

complex_float *x
input array

Uint16 N
length of x and y arrays
```

The type "complex float" is defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part

Alignment Requirements:

None

Notes:

1. N must be EVEN

Example:

```
#include "fpu\_vector.h"
#define N 10
float32 y[N];
complex_float x[N];

main()
{
   abs_SP_CV_2(y, x, N);  // complex absolute value}
```

Benchmark Information:

Number of Cycles = 18*N+22 cycles (including the call and return)

5.19 Absolute Value of a Complex Vector (TMU0)

Description:

This module computes the absolute value of a complex vector using the TMU Type 0 Accelerator to speed up its calculation.

$$Y[i] = \sqrt{(X_{re}[i]^2 + X_{im}[i]^2)}$$

This function is optimized for N>=8. It is less cycle efficient when N<8. For very small N (e.g., N=1, 2, maybe 3) the user might consider using the TMU intrinsics in the compiler instead of this function.

Header File:

fpu_vector.h

Declaration:

```
void abs_SP_CV_TMU0(float32 *y, const complex_float *x, const Uint16 N)
Usage:
    abs_SP_CV_TMU0(x, y, N);

float32 *y
    output array
    complex_float *x
    input array
```

Uint16 N

length of x and y arrays

The type "complex float" is defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part

Alignment Requirements:

None

Example:

```
#include "fpu\_vector.h"
#define N 10
float32 y[N];
complex_float x[N];

main()
{
   abs_SP_CV_TMU0(y, x, N);  // complex absolute value}
```

Benchmark Information:

```
Number of Cycles = 30 , N = 1 (including the call and return) 7.5*(N)+21 , 1<N<8 and N even 7.5*(N-1)+38 , 1<N<8 and N odd 4*(N-6)+56 , N>=8 and N even 4*(N-7)+73 , N>=8 and N odd
```

5.20 Addition (Element-Wise) of a Complex Scalar to a Complex Vector

Description:

This module adds a complex scalar element-wise to a complex vector.

$$Y_{re}[i] = X_{re}[i] + C_{re}$$
$$Y_{im}[i] = X_{im}[i] + C_{im}$$

Header File:

fpu_vector.h

Declaration:

Usage:

```
add_SP_CSxCV(y, w, c, N);
```

complex_float *y
 result complex array

complex float *x

input complex array

complex float c

input complex scalar

Uint16 N

length of x and y arrays

The inputs and return value are of type "complex_float" defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part

Alignment Requirements:

None

Notes:

1. N must be at least 2

Example:

```
#include "fpu\_vector.h"
#define N 4
complex_float c, x[N], y[N];
main()
{
   add_SP_CSxCV(y, x, c, N);
}
```

Benchmark Information:

Number of Cycles = 4*N + 18 cycles (including the call and return)

5.21 Addition of Two Complex Vectors

Description:

This module adds two complex vectors.

$$Y_{re}[i] = W_{re}[i] + X_{re}[i]$$

 $Y_{im}[i] = W_{im}[i] + X_{im}[i]$

Header File:

fpu_vector.h

Declaration:

Usage:

```
add\_SP\_CVxCV(y,\,w,\,x,\,N);
```

complex_float *y

result complex array

complex_float *w

input complex array 1

complex float *x

input complex array 2

Uint16 N

length of w, x, and y arrays

The inputs and return value are of type "complex float" defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part.

Alignment Requirements:

None

Notes:

1. N must be at least 2

Example:

```
#include "fpu\_vector.h"
#define N 4
complex_float w[N], x[N], y[N];
main()
{
   add_SP_CVxCV(y, w, x, N);
}
```

Benchmark Information:

Number of Cycles = 6*N + 15 cycles (including the call and return)

5.22 Inverse Absolute Value of a Complex Vector

Description:

This module computes the inverse absolute value of a complex vector.

$$Y[i] \ = \ \frac{1}{\sqrt(X_{re}[i]^2 + X_{im}[i]^2)}$$

Header File:

fpu_vector.h

Declaration:

```
void iabs_SP_CV(float32 *y, const complex_float *x, const Uint16 N)
```

Usage:

```
iabs_SP_CV(y, x, N);
```

float32 *y

output array

complex_float *x

input complex array

Uint16 N

length of x and y arrays

The type "complex_float" is defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part.

Alignment Requirements:

None

Notes:

1. N must be at least 2

Example:

Benchmark Information:

Number of Cycles = 25*N + 13 cycles (including the call and return)

5.23 Inverse Absolute Value of an Even Length Complex Vector

Description:

This module calculates the inverse absolute value of an even length complex vector.

$$Y[i] = \frac{1}{\sqrt(X_{re}[i]^2 + X_{im}[i]^2)}$$

Header File:

fpu_vector.h

Declaration:

```
void iabs_SP_CV_2(float32 *y, const complex_float *x, const Uint16 N)
```

Usage:

```
iabs_SP_CV_2(y, x, N);
```

float32 *y

output array

complex_float *x

input complex array

Uint16 N

length of x and y arrays (must be even)

The type "complex_float" is defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part.

Alignment Requirements:

None

Notes:

1. N must be EVEN

Example:

```
#include "fpu\_vector.h"
#define N   4
float32 y[N];
complex_float x[N];

main()
{
   iabs_SP_CV_2(y, x, N);  // inverse complex absolute value}
```

Benchmark Information:

Number of Cycles = 15*N + 22 cycles (including the call and return)

Inverse Absolute Value of a Complex Vector (TMU0) 5.24

Description:

This module computes the inverse absolute value of a complex vector using the TMU Type 0 Accelerator to speed up its calculation.

$$Y[i] \ = \ \frac{1}{\sqrt(X_{re}[i]^2 + X_{im}[i]^2)}$$

This function is optimized for N>=8. It is less cycle efficient when N<8. For very small N (e.g., N=1, 2, maybe 3) the user might consider using the TMU intrinsics in the compiler instead of this function.

Header File:

fpu_vector.h

Declaration:

```
void iabs_SP_CV_TMU0(float32 *y, const complex_float *x, const Uint16 N)
```

Usage:

```
iabs_SP_CV_TMU0(y, x, N);
float32 *y
    output array
complex float *x
```

input complex array

Uint16 N

length of x and y arrays

The type "complex_float" is defined as

```
typedef struct{
 float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part.

Alignment Requirements:

None

Notes:

1. N must be at least 2

Example:

```
#include "fpu\_vector.h"
#define N 4
float32 y[N];
complex_float x[N];
main()
  iabs_SP_CV_TMU0(y, x, N); // inverse complex absolute value
```

Jan 30, 2014 65

Benchmark Information:

Number of Cycles = 35 , N = 1 (including the call and return)

10*(N)+24 , 1<N<8 and N even 10*(N-1)+46 , 1<N<8 and N odd 5*(N-6)+67 , N>=8 and N even 5*(N-7)+89 , N>=8 and N odd

5.25 Index of Maximum Value of an Even Length Real Array

Description:

This module finds the index of the maximum value of an even length real array.

Header File:

fpu_vector.h

Declaration:

```
Uint16 maxidx_SP_RV_2(float32 *x, Uint16 N)
```

Usage:

```
index = maxidx_SP_RV_2(x, N);

float32 x
    input array
Uint16 N
    length of x
Uint16 index
```

Note:

1. N must be even.

index of maximum value in x

2. If more than one instance of the max value exists in x[], the function will return the index of the first occurence (lowest index value)

Alignment Requirements:

None

Example:

```
#include "fpu\_vector.h"
#define N 10
float32 x[N];

Uint16 index;

main()
{
   index = maxidx_SP_RV_2(x, N);
}
```

Benchmark Information:

Number of Cycles = 3*N + 21 cycles (including the call and return)

5.26 Mean of Real and Imaginary Parts of a Complex Vector

Description:

This module calculates the mean of real and imaginary parts of a complex vector.

$$Y_{re} = \frac{\Sigma X_{re}}{N}$$

$$Y_{im} = \frac{\Sigma X_{im}}{N}$$

Header File:

fpu_vector.h

Declaration:

```
complex_float mean_SP_CV_2(const complex_float *x, const Uint16 N)
```

Usage:

```
y = mean_SP_CV_2(x, N);
complex float *x
```

input complex array

Uint16 N

length of x array

complex_float y

result

The type "complex_float" is defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part.

Alignment Requirements:

None

Notes:

1. N must be EVEN and a minimum of 4.

Example:

```
#include "fpu\_vector.h"
#define N 4
complex_float y;
complex_float x[N];

main()
{
    y = mean_SP_CV_2(x, N);
}
```

Benchmark Information:

Number of Cycles = 2*N + 34 cycles (including the call and return)

5.27 Median of a Real Valued Array of Floats (Preserved Inputs)

Description:

This module computes the median of a real valued array of floats. The input array is preserved. If input array preservation is not required, use median_SP_RV() for better performance. This function calls median_SP_RV() and memcpy_fast().

```
Header File:
```

fpu vector.h

Declaration:

```
float32 median_noreorder_SP_RV(const float32 *x, Uint16 N)
```

Usage:

```
y = median_noreorder_SP_CV(x, N);

float32 *x
    pointer to array of real input values

Uint16 N
    size of x array

float32 y
    the median of x[]
```

Alignment Requirements:

None

Notes:

- 1. This function simply makes a local copy of the input array, and then calls median_SP_CV() using the copy
- 2. The length of the copy of the input array is allocated at compile time by the constant "K" defined in the code. If the passed parameter N is greated than K, memory corruption will result. Be sure to recompile the library with an appropriate value K >= N before executing this code. The library uses K = 256 as the default value.

```
#include "fpu\_vector.h"
#define N 256
float32 x[N];
float32 y;

main()
{
  y = median_noreorder_SP_RV(x, N);
}
```

Benchmark Information:

The cycles for this function are data dependent and therefore the benchmark cannot be provided.

5.28 Median of a real array of floats

Description:

This module computes the median of a real array of floats. The Input array is NOT preserved. If input array preservation is required, use median_noreorder_SP_RV().

Header File:

```
fpu vector.h
```

Declaration:

```
float32 median SP RV(float32 *, Uint16)
```

Usage:

```
z = median_SP_RV(x, N);

float32 *x
    input array

Uint16 N
    length of x array

float32 y
    result
```

Alignment Requirements:

None

Notes:

- 1. This function is destructive to the input array x in that it will be sorted during function execution. If this is not allowable, use median_noreorder_SP_CV().
- 2. This function should be compiled with -o4, -mf5, and no -g compiler options for best performance.

Example:

```
#include "fpu\_vector.h"
#define N 256
float32 x[N];
float32 y;

main()
{
   y = median_SP_RV(x, N);
}
```

Benchmark Information:

The cycles for this function are data dependent and therefore the benchmark cannot be provided.

5.29 Complex Multiply of Two Floating Point Numbers

Description:

This module multiplies two floating point complex values.

$$Y_{re} = W_{re} * X_{re} - W_{im} * X_{im}$$

$$Y_{im} = W_{re} * X_{im} + W_{im} * X_{re}$$

Header File:

fpu_vector.h

Declaration:

```
complex_float mpy_SP_CSxCS(complex_float w, complex_float x)
```

Usage:

```
y = mpy_SP_CSxCS(w,x);
complex_float w
    input 1
complex_float x
    input 2
complex_float y
    result
```

The type "complex_float" is defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part.

Alignment Requirements:

None

Example:

```
#include "fpu\_vector.h"
complex_float w,x,y;

main()
{
   y = mpy_SP_CSxCS(w,x); // complex multiply
}
```

Benchmark Information:

Number of Cycles = 19 cycles (including the call and return)

5.30 Complex Multiply of Two Complex Vectors

Description:

This module performs complex multiplication on two input complex vectors.

$$Y_{re}[i] = W_{re}[i] * X_{re}[i] - W_{im}[i] * X_{im}[i]$$

 $Y_{im}[i] = W_{re}[i] * X_{im}[i] + W_{im}[i] * X_{re}[i]$

Header File:

fpu_vector.h

Declaration:

Usage:

```
mpy_SP_CVxCV(y, w, x, N);

complex_float *y
    result complex array

complex_float *w
    input complex array 1

complex_float *x
    input complex array 2
```

Uint16 N

length of w, x, and y arrays

The type "complex_float" is defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part.

Alignment Requirements:

None

Example:

```
#include "fpu\_vector.h"
#define N 4
complex_float w[N], x[N], y[N];
main()
{
   mpy_SP_CVxCV(y, w, x, N);
}
```

Benchmark Information:

Number of Cycles = 10*N + 16 cycles (including the call and return)

5.31 Multiplication of a Complex Vector and the Complex Conjugate of another Vector

Description:

This module multiplies a complex vector (w) and the complex conjugate of another complex vector (x).

$$\begin{array}{lcl} X_{re}^*[i] & = & X_{re}[i] \\ X_{im}^*[i] & = & -X_{im}[i] \\ Y_{re}[i] & = & W_{re}[i] * X_{re}[i] - W_{im}[i] * X_{im}^*[i] \\ Y_{im}[i] & = & W_{re}[i] * X_{im}^*[i] + W_{im}[i] * X_{re}[i] \end{array}$$

Header File:

fpu_vector.h

Declaration:

Usage:

```
mpy_SP_CVxCVC(y, w, x, N);

complex_float *y
    result complex array

complex_float *w
    input complex array 1

complex_float *x
    input complex array 2

Uint16 N
    length of w, x, and y arrays
```

The type "complex float" is defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part.

Alignment Requirements:

None

Example:

```
#include "fpu\_vector.h"
#define N 4
complex_float w[N], x[N], y[N];
main()
{
    mpy_SP_CVxCVC(y, w, x, N);
}
```

Benchmark Information:

Number of Cycles = 11*N + 16 cycles (including the call and return)

5.32 Multiplication of a Real scalar and a Real Vector

Description:

This module multiplies a real scalar and a real vector.

$$Y[i] = C * X[i]$$

Header File:

fpu vector.h

Declaration:

Usage:

```
mpy_SP_RSxRV_2(y, x, c, N);

float32 *y
    result real array

float32 *x
    input real array

float32 c
    input real scalar

Uint16 N
    length of x and y array
```

Alignment Requirements:

None

Notes:

1. N must be EVEN and a minimum of 4.

Example:

```
#include "fpu\_vector.h"
#define N 10
float32 x[N], y[N];
float32 c;

main()
{
    mpy_SP_RSxRV_2(y, x, c, N);
}
```

Benchmark Information:

Number of Cycles = 2*N + 15 cycles (including the call and return)

5.33 Multiplication of a Real Scalar, a Real Vector, and another Real Vector

Description:

This module multiplies a real scalar with a real vector. and another real vector.

$$Y[i] = C * W[i] * X[i]$$

Header File:

fpu_vector.h

Declaration:

Usage:

```
mpy_SP_RSxRVxRV_2(y, w, x, c, N);

float32 *y
    result real array

float32 *w
    input real array 1

float32 *x
    input real array 2

float32 c
    input real scalar

Uint16 N
    length of w, x and y arrays
```

Alignment Requirements:

None

Notes:

1. N must be EVEN and a minimum of 4.

Example:

```
#include "fpu\_vector.h"
#define N 4
float32 w[N], x[N], y[N];
float32 c;

main()
{
   mpy_SP_RSxRVxRV_2(y, w, x, c, N);
}
```

Benchmark Information:

Number of Cycles = 3*N + 22 cycles (including the call and return)

Multiplication of a Real Vector and a Complex Vector 5.34

Description:

This module multiplies a real vector and a complex vector.

$$Y_{re}[i] = X[i] * W_{re}[i]$$

 $Y_{im}[i] = X[i] * W_{im}[i]$

Header File:

fpu vector.h

Declaration:

```
void mpy_SP_RVxCV(complex_float *y, const complex_float *w,
                        const float32 *x, const Uint16 N)
```

Usage:

```
mpy_SP_RVxCV(y, x, c, N);
complex float *y
    result complex array
complex float *w
    input complex array
float32 *x
```

input real array

Uint16 N

length of w, x, and y arrays

The type "complex_float" is defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part.

Alignment Requirements:

None

Notes:

1. N must be at least 2

Example:

```
#include "fpu\_vector.h"
#define N
float32 x[N];
complex_float w[N], y[N];
main()
    mpy_SP_RVxCV(y, w, x, N);
```

Benchmark Information:

Number of Cycles = 5*N + 15 cycles (including the call and return)

5.35 Multiplication of a Real Vector and a Real Vector

Description:

This module multiplies two real vectors.

```
Y[i] = W[i] * X[i]
```

Header File:

fpu vector.h

Declaration:

Usage:

```
ge:
mpy_SP_RVxRV_2(y, w, x, N);
float32 *y
```

result real array float32 *w

input real array 1

float32 *x

input real array 2

Uint16 N

length of w, x and y arrays

The type "complex_float" is defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part.

Alignment Requirements:

None

Notes:

1. N must be EVEN and a minimum of 4.

Example:

```
#include "fpu\_vector.h"
#define N 4
float32 w[N], x[N], y[N];
float32 c;
main()
{
   mpy_SP_RVxRV_2(y, w, x, N);
}
```

Benchmark Information:

Number of Cycles = 3*N + 17 cycles (including the call and return)

5.36 Sort an Array of Floats

Description:

This module sorts an array of floats. This function is a partially optmized version of qsort.c from the C28x cgtools lib qsort() v6.0.1.

```
Header File:
```

```
fpu_vector.h
```

Declaration:

```
void qsort_SP_RV(void *x, Uint16 N)
```

Usage:

```
qsort_SP_RV(x, N);

void *x

input array of floats

Uint16 N

size of x array
```

Alignment Requirements:

None

Notes:

1. Performance is best with -o1, -mf3 compiler options (cgtools v6.0.1)

Example:

```
#include "fpu\_vector.h"
#define N 4
float32 x[N];
main()
{
    qsort_SP_RV(x,N);
}
```

Benchmark Information:

The cycles for this function are data dependent and therefore the benchmark cannot be provided.

5.37 Rounding (Unbiased) of a Floating Point Scalar

Description:

This module performs the unbiased rounding of a floating point scalar.

```
Header File:
    fpu_vector.h

Declaration:
    float32 rnd_SP_RS(float32 x)

Usage:
    y = rnd_SP_RS(x);

float32 x
    input value
float32 y
```

Alignment Requirements:

result

None

Notes:

```
1. numerical examples:

rnd_SP_RS(+4.4) = +4.0

rnd_SP_RS(-4.4) = -4.0

rnd_SP_RS(+4.5) = +5.0

rnd_SP_RS(-4.5) = -5.0

rnd_SP_RS(+4.6) = +5.0

rnd_SP_RS(-4.6) = -5.0
```

Example:

```
#include "fpu\_vector.h"
float32 x,y;

main()
{
    y = rnd_SP_RS(x);
}
```

Benchmark Information:

Number of Cycles = 18 cycles (including the call and return)

5.38 Subtraction of a Complex Scalar from a Complex Vector

Description:

This module subtracts a complex scalar from a complex vector.

$$Y_{re}[i] = X_{re}[i] - C_{re}$$

$$Y_{im}[i] = X_{im}[i] - C_{im}$$

Header File:

fpu_vector.h

Declaration:

Usage:

```
sub_SP_CSxCV(y, w, c, N);
```

complex_float *y

result complex array

complex_float *x

input complex array

complex float c

input complex scalar

Uint16 N

length of x and y arrays

The type "complex float" is defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part.

Alignment Requirements:

None

Notes:

1. N must be at least 2

Example:

```
#include "fpu\_vector.h"
#define N 4
complex_float c, x[N], y[N];
main()
{
   sub_SP_CSxCV(y, x, c, N);
}
```

Benchmark Information:

Number of Cycles = 4*N + 18 cycles (including the call and return)

5.39 Subtraction of a Complex Vector and another Complex Vector

Description:

This module subtracts a complex vector from another complex vector.

$$Y_{re}[i] = W_{re}[i] - X_{re}[i]$$

 $Y_{im}[i] = W_{im}[i] - X_{im}[i]$

Header File:

fpu_vector.h

Declaration:

Usage:

```
sub_SP_CVxCV(y, w, x, N);
```

complex_float *y

result complex array

complex_float *w

input complex array 1

complex float *x

input complex array 2

Uint16 N

length of w, x and y arrays

The type "complex float" is defined as

```
typedef struct{
  float32 dat[2];
}complex_float;
```

Element dat[0] is the real part, dat[1] is the imaginary part.

Alignment Requirements:

None

Notes:

1. N must be at least 2

Example:

```
#include "fpu\_vector.h"
#define N 4
complex_float w[N], x[N], y[N];
main()
{
   sub_SP_CVxCV(y, w, x, N);
}
```

Benchmark Information:

Number of Cycles = 6*N + 15 cycles (including the call and return)

5.40 Fast Square Root

Description:

This function is an inline optmized fast square root function using two iterations of the newton raphson method to achieve an accurate result.

```
Header File:
```

```
fpu math.h
```

Declaration:

```
inline static float32 __ffsqrtf(float32 x)
```

Usage:

```
ffsqrtf(x);
```

float32 x

input variable

Alignment Requirements:

None

Notes:

1. Performance is best with -o2, -mn compiler options (cgtools v6.0.1)

Example:

```
#include "fpu\_math.h"
float32 x,y;
main()
{
    y = __ffsqrtf(x);
}
```

Benchmark Information:

A single invocation of the __ffsqrtf function takes 22 cycles to complete. Inspection of the generated assembly code would reveal 11 NOP's used as delay slots between instructions. If the user were to chain back-to-back invocations of the __ffsqrtf function, and then subsequently use the results in either arithmetic or assignment statements, the compiler will interleave the instructions of both functions, effectively resulting in 11 cycles per function call. The compiler will not interleave the instructions of back-to-back functions if their results are subsequently used in logical statements.

5.41 Optimized Memory Copy

Description:

Header File:

fpu_vector.h

Declaration:

This module performs optimized memory copies.

```
void memcpy_fast(void* dst, const void* src, Uint16 N)
```

Usage:

```
memcpy_fast(dst, src, N);

void* dst
    pointer to destination

const void* src
    pointer to source

Uint16 N
    number of 16-bit words to copy
```

Alignment Requirements:

None

Notes:

1. The function checks for the case of N=0 and just returns if true.

Example:

```
#include "fpu\_vector.h"
#define N 256

float32 y[N];
float32 x[N];

main()
{
   memcpy_fast(x, y, N<<1);
}</pre>
```

Benchmark Information:

Number of Cycles = 1 cycle per copy + 20 cycles of overhead (including the call and return). This assumes src and dst are located in different internal RAM blocks.

5.42 Optimized Memory Set

Description:

This module performs optimized memory sets.

```
Header File:
```

```
fpu_vector.h
```

Declaration:

```
void memset_fast(void* dst, int16 value, Uint16 N)
```

Usage:

```
memset_fast(dst, value, N);

void* dst
    pointer to destination
int16 value
    initialization value
Uint16 N
    number of 16-bit words to initialize
```

Alignment Requirements:

None

Notes:

1. The function checks for the case of N=0 and just returns if true.

Example:

```
#include "fpu\_vector.h"
#define N 10
int x[N];
main()
{
   memset_fast(x, 4, N);
}
```

Benchmark Information:

Number of Cycles = 1 cycle per copy + 20 cycles of overhead (including the call and return). This assumes src and dst are located in different internal RAM blocks.

6 Benchmarks

The benchmarks were obtained with the following compiler settings for the libraries:

```
-v28 -mt -ml -g --diag_warning=225 --float_support=fpu32
```

In the case where the TMU Type 0 version of the library is used, the additional compiler switch $-tmu_support=tmu0$ is enabled. Table. 6.1 summarizes the performance metrics for all the library routines. These numbers were obtained by profiling the code in the examples_ccsv5 directory.

Library	Function	Cycles ¹
FPU	CFFT f32	1121, N = 32
170	0111_132	2331, N = 64
		5029, N = 128
		11023, N = 256
		24249, N = 512
		53219, N = 1024
	CFFT_f32u	1351, N = 32
	0.1.10_0	2785, N = 64
		5931, N = 128
		12821, N = 256
		27839, N = 512
		60393, N = 1024
	CFFT_f32_sincostable ²	N/A
	CFFT_f32_mag ³	2717 / 1436, N =32
		5405 / 2844, N = 64
		10781 / 5660, N = 128
		21533 / 11292, N = 256
		43047 / 22556, N = 512
		86045 / 45084, N = 1024
	CFFT_f32s_mag ⁻³	2906 / 1534, N =32
		5760 / 3013, N = 64
		11462 / 5964, N = 128
		22860 / 11859, N = 256
		45650 / 23642, N = 512
	2555 (22) 2	91224 / 47201, N = 1024
	CFFT_f32_phase ³	29778 / 2141, N =32
		63279 / 4253, N = 64
		110368 / 8477, N = 128
		242669 / 16925, N = 256
		485624 / 33821, N = 512
	ICEET 100	1002380 / 67613, N = 1024
	ICFFT_f32	1370, N = 32 2803, N = 64
		2803, N = 64 5948, N = 128
		12837, N = 126
		27854, N = 512
		60411, N = 1024
	L	Continued on next page
		Continued on next page

Table 6.1 – continued from previous page

		from previous page
Library	Function	Cycles
	RFFT f32	611, N = 32
	_	1277, N = 64
		2775, N = 128
		6145, N = 256
		13675, N = 512
		30357, N = 1024
		67007, N = 2048
	RFFT f32u	667, N = 32
	11111_1020	1389, N = 64
		2999, N = 128
		6593, N = 256
		14571, N = 512
		32149, N = 1024
		70591, N = 2048
	RFFT adc f32	628, N = 32
	hrri_auc_isz	1290, N = 64
		2764, N = 128
		6054, N = 256
		13360, N = 512
		29466, N = 1024
		64709, N = 2048
	RFFT_adc_f32u	698, N = 32
		1444, N = 64
		3102, N = 128
		6792, N = 256
		14962, N = 512
		31387, N = 1024
	2	68549, N = 2048
	RFFT_f32_mag ³	1324 / 694, N =32
		2654 / 1382, N = 64
		5342 / 2758, N = 128
		10718 / 5510, N = 256
		21470 / 11014, N = 512
		42974 / 22022, N = 1024
	2	85982 / 44038, N = 1024
	RFFT_f32s_mag ³	1367 / 737, N =32
		2749 / 1447, N = 64
		5507 / 2861, N = 128
		11017 / 5683, N = 256
		22031 / 11321, N = 512
		44053 / 22591, N = 1024
	DEET (00	88091 / 45125, N = 1024
	RFFT_f32_phase ³	14909 / 1105, N =32
		29096 / 2152, N = 64
		59381 / 4239, N = 128
		106114 / 8406, N = 256
		237106 / 16733, N = 512
		479424 / 33380, N = 1024
		Continued on next page

Table 6.1 – continued from previous page

Library		Cycles
		-
		852535 / 66667, N = 1024
	RFFT_f32_sincostable ²	N/A
	abs_SP_CV	28*N + 9 (N - vector size)
	abs_SP_CV_2	18*N + 22 (N - vector size)
	abs_SP_CV_TMU0	30, N = 1 (N - vector size)
		7.5*(N)+21 , 1 <n<8 and="" even<="" n="" th=""></n<8>
		7.5*(N-1)+38, 1 <n<8 and="" n="" odd<="" th=""></n<8>
		4*(N-6)+56 , N>=8 and N even
		4*(N-7)+73, N>=8 and N odd
	add_SP_CSxCV	4*N + 18 (N - vector size)
	add_SP_CVxCV	6*N + 15 (N - vector size)
	iabs_SP_CV	25*N + 13 (N - vector size)
	iabs_SP_CV_2	15*N + 22 (N - vector size)
	iabs_SP_CV_TMU0	35, N = 1 (N - vector size)
		10*(N)+24 , 1 <n<8 and="" even<="" n="" th=""></n<8>
		10*(N-1)+46, 1 <n<8 and="" n="" odd<="" th=""></n<8>
		5*(N-6)+67, N>=8 and N even
		5*(N-7)+89 , N>=8 and N odd
	maxidx_SP_RV_2	3*N + 21 (N - vector size)
	mean_SP_CV_2	2*N + 34 (N - vector size)
	median_noreorder_SP_RV 4	N/A
	median_SP_RV ⁴	N/A
	memcpy_fast 5	N + 20 (N - memory size)
	memset_fast ⁵	N + 20 (N - memory size)
	mpy_SP_CSxCS	19
	mpy_SP_CVxCV	10*N + 16 (N - vector size)
	mpy_SP_CVxCVC	11*N + 16 (N - vector size)
	mpy_SP_RSxRV_2	2*N + 15 (N - vector size)
	mpy_SP_RSxRVxRV_2	3*N + 22 (N - vector size)
	mpy_SP_RVxCV	5*N + 15 (N - vector size)
	mpy_SP_RVxRV_2	3*N + 17 (N - vector size)
	qsort_SP_RV ⁴	N/A
	rnd_SP_RS	18
	sub_SP_CSxCV	4*N + 18 (N - vector size)
	sub_SP_CVxCV	6*N + 15 (N - vector size)
	ffsqrt ⁶	22
	FIR_FP_calc 7	N + 55 (N is filter order)

Table 6.1: Benchmark for the FPU Library Routines.

¹Includes call and return instructions.

²This function is written in C and not optimized.

³Numbers to the left of / were obtained using the standard run time support library while those to the right were with the fast runtime support library.

⁴The cycles for this function are data dependent and therefore the benchmark cannot be provided.

⁵This assumes source and destination are located in different internal RAM blocks.
⁶Two back to back calls to the __ftsqrt can yield a cycle count of 11 per square root. Please refer to the API chapter for more details.

 $^{^{7}}$ N is the order of the FIR filter. For e.g. N = 31, cycle count = 85.

7 Revision History

V1.40.00.00: Moderate Update

- Revised documentation
- Re-factored all library and example projects to use CGT v6.2.4
- Updated all examples to work with CCS v5
- Added TMU0 build configuration to the library and an example to demonstrate functions that use the TMU
- Corrected circular buffer limitation (256 words) for the FIR filter implementation by using C2xLP addressing mode which permits a circular buffer up to a maximum size of 65536 words

V1.31: Minor Update

- Revised documentation
- Updated median_SP_RV() routine

V1.30: Moderate Update

- Added vector and matrix functions and examples
- Added Inverse complex FFT and example
- Revised benchmark numbers
- Revised alignment requirements for FFT's

V1.20: Moderate Update

Added equiripple FIR filter function

V1.10: Moderate Update

Includes the complex FFT and real FFT with 12-bit ADC fixed-point input supporting functions

V1.00: Initial Release

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

Products

Amplifiers Data Converters DLP® Products DSP Clocks and Timers Interface Logic Power Mgmt Microcontrollers

RF/IF and ZigBee® Solutions

amplifier.ti.com dataconverter.ti.com www.dlp.com dsp.ti.com www.ti.com/clocks interface.ti.com logic.ti.com power.ti.com microcontroller.ti.com www.ti-rfid.com www.ti.com/lprf

Applications Audio Automotive Broadband Digital Control Medical Military

Optical Networking Security Telephony Video & Imaging Wireless

www.ti.com/audio www.ti.com/automotive

www.ti.com/broadband www.ti.com/digitalcontrol www.ti.com/medical

www.ti.com/military

www.ti.com/opticalnetwork www.ti.com/security

www.ti.com/telephony www.ti.com/video

www.ti.com/wireless

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2014, Texas Instruments Incorporated