

Working with Mobile Operations	1
Installing Mobile Operations	2
Starting and ending Mobile Operations	3
User interface of start page	4
Display on small and large screen	5
Synchronizing data	6
Resolving conflicts	7
Working with the "Work packages" tile	8
Working with the "Events" tile	9
Creating redlinings	10
Pin favorites to starting page	11
Live feed tiles	12
"Find" tile	13
Editing settings	14
Administration	15

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 DANGER
indicates that death or severe personal injury will result if proper precautions are not taken.
 WARNING
indicates that death or severe personal injury may result if proper precautions are not taken.
 CAUTION
indicates that minor personal injury can result if proper precautions are not taken.
NOTICE
indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

 WARNING
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of contents

1	Working with Mobile Operations.....	7
2	Installing Mobile Operations.....	9
3	Starting and ending Mobile Operations.....	11
3.1	Opening the app and logging in.....	11
3.2	Logging into another server.....	12
3.3	Logging out.....	12
4	User interface of start page.....	15
5	Display on small and large screen.....	17
6	Synchronizing data.....	19
7	Resolving conflicts.....	21
8	Working with the "Work packages" tile.....	23
8.1	User interface of the "Work packages" tile.....	23
8.2	Requirements for displaying work packages.....	24
8.3	Displaying work packages.....	24
8.4	Display activities.....	25
8.5	Editing work packages.....	26
8.6	Adding activities.....	27
8.7	Attaching attachments.....	28
9	Working with the "Events" tile.....	29
9.1	User interface of the "Events" tile.....	29
9.2	Requirements for events that can be synchronized.....	30
9.3	Displaying events.....	30
9.4	Adding events.....	31
9.5	Editing events.....	32
9.6	Linking objects.....	32
9.7	Attaching attachments.....	33

10	Creating redlinings.....	35
11	Pin favorites to starting page.....	37
12	Live feed tiles.....	39
13	"Find" tile.....	41
14	Editing settings.....	43
14.1	General settings.....	43
14.2	Settings for work packages.....	43
14.3	Settings for the live feed tile.....	43
14.4	Settings for the search.....	44
15	Administration.....	45
15.1	Server requirements.....	45
15.2	Installing and configuring COMOS Web Server for Mobile Operations.....	46

The "Mobile Operations" app supports you, among other things, in carrying out the following activities on mobile devices:

- Maintenance
- Corrective maintenance
- Inspection
- Commissioning
- Inventory control
- Redlining

Mobile Operations is based on COMOS Web. You can access the same data via COMOS Web and Mobile Operations because data is automatically synchronized between the databases. Concepts as well as the administration of Mobile Operations are the same as or similar to those in COMOS Web.

In contrast to COMOS Web, you can work both online and offline in the app.

- Android operating system 5.0 or higher
- Mobile terminal with at least 5" diagonal
- You are familiar with the basics of operating Android systems.
- Your administrator has configured the COMOS Web server for Mobile Operations.
See also chapter Installing and configuring COMOS Web Server for Mobile Operations (Page 46).
- The server meets the requirements for Mobile Operations.
See also chapter Server requirements (Page 45).

Note

The "COMOS Mobile Operations" app is only suitable for one user.

However, you can log into different servers and can thus have several logins.

Working with Mobile Operations

The following text describes the main application of Mobile Operations.

Application	User	Activity
COMOS	Maintenance engineer	Prepares COMOS work packages with activities. The objects are synchronized with Mobile Operations.
Mobile Operations	Field engineer	Logs on to Mobile Operations on a tablet. The device automatically downloads the current data from the server.
		- Edits the work packages assigned to the engineer on the tablet. The tablet can be offline during editing. - Creates redlining - Creates new activities
		Creates new events, if necessary The tablet can be offline during editing.
		Synchronizes the data on the tablet with the server once tablet is online again. The data on the server is automatically synchronized with COMOS.

Installing Mobile Operations

Requirement

See chapter AUTOHOTSPOT.

Procedure

1. Download the Mobile Operations app from the Google Play Store.
2. Install the app on your tablet or smartphone.
3. Allocate all access authorizations to the app that it requests.

Result

Mobile Operations is installed.

See also

Starting and ending Mobile Operations (Page 11)

Starting and ending Mobile Operations

3.1 Opening the app and logging in

Requirement

The administrator has installed COMOS Web on a server and configured it for Mobile Operations. See also chapter Installing and configuring COMOS Web Server for Mobile Operations (Page 46).

Procedure

1. Tap the COMOS Mobile Operations app.
2. When you log in for the first time, you enter the address of the server of COMOS Web on which the desired database is installed in the "Server address" field.
Example: `http://192.168.111.xx`
3. Click "Save".
4. If you are not logged in automatically, you are prompted to enter your user name and password. When specifying the user name, also enter the domain name, depending on the configuration at the server end.
You thus enter your user name in one of the following formats:
 - Domain\User name
 - Password
5. Select the desired user interface language.
6. Click "OK".

Result

You are logged in. The user interface of Mobile Operations is displayed.

See also

Logging out (Page 12)

Logging into another server (Page 12)


3.2 Logging into another server

Requirement

You have already logged into the app once. See also chapter Opening the app and logging in (Page 11).

Procedure

1. Log out of the app. See also chapter Logging out (Page 12).
2. Open the login mask of the app.
3. Tap the "Change server address" link.



4. Enter a different server address.
5. Tap "OK".
6. Log into the new server with your user data.

3.3 Logging out

Requirement

You are logged into COMOS Mobile Solutions.

See section Opening the app and logging in (Page 11).

Procedure

1. Tap your user name in the menu bar.
2. Tap "Log out"

Result


You are logged out. The login window is displayed.

3.3 Logging out

User interface of start page

User interface

The starting page is displayed once you have logged into COMOS Mobile Solutions. The arrangement of the tiles can differ on your device. It is dependent on the screen size.



1	The button is displayed regardless of where you are located in COMOS Mobile Solutions. When you click this button, you return to the starting page.
2	The title indicates where you are located in COM Mobile Solutions.
3	The "Edit" button activates the edit mode of the page. When the edit mode is activated, you can delete or move pinned tiles.
4	The "Sync" button synchronizes the data on your device with the server.
5	The currently logged in user is displayed. This is where you log off. See section Logging out (Page 12).
6	The button calls the full-screen mode. The address bar of the browser is hidden.
7	The "Maintenance" tile group contains the tiles for maintenance tasks and the settings for Mobile Operations.
8	The "Events" tile group contains the tiles for maintenance tasks and the settings for Mobile Operations.

Display on small and large screen

You can use COMOS Mobile Operations on smartphones and tablets. The arrangement of the user interface elements changes automatically in accordance with the screen size.

This manual deals with the display on tablets.


Recommendation: Use your tablet in landscape format.

Differences to the display on a smartphone

- Arrangement of the tiles on the starting page:
On tablets the tiles of a tile group are normally displayed one under the other
On smartphones the tiles are displayed next to each other.
- User interfaces with several sections:
On tablets several sections are displayed at the same time. For example, the "Work packages" tile displays the three sections "Filter", work packages of the selected filter and the details of a selected work package at the same time.



On smartphones only one section is displayed.
In order to access the next section select an entry in the current section.



You use the Left arrow to move to the previous section.

Synchronizing data

The data on your device is automatically synchronized with the server when you log on to the app. Data is not automatically synchronized while you are working with the app.

The following data can generally be downloaded to your device and synchronized with the server:

- Work packages
- Activities
- Events
- Attachments
- Linked objects
- COMOS objects for which synchronization was configured in scripts

Requirement


You can connect to the Mobile Operations server.

Procedure

1. To synchronize data, tap "Sync" in the main menu bar.



A window shows when the data was last synchronized.



2. Tap "Sync now".

Result

The data is synchronized as follows:

- If your data was not edited in COMOS / COMOS Web since the last synchronization:
Mobile Operations -> Server
- If your data was edited in COMOS / COMOS Web as well as in Mobile Operations:
You are notified of the conflict and can decide which data should be adopted. See also chapter Resolving conflicts (Page 21).

Resolving conflicts

Conflicts occur when work packages, events or activities were changed on both the server as well as on your device since your last synchronization.

The data on your server can be changed in the following ways:

- A user edits data in COMOS
- A user edits data in COMOS Web
- A user edits data in Mobile Operations and synchronizes their data with the server

"Conflict handling" window

The window shows a row in the table for every conflict. In it you see the old and new value as well as the modification dates.

Column	Description
"Local"	Shows the data on your device: • Name of the dataset for which a conflict occurred • Date of the last change
"Remote"	Shows the data on the server. • Name of the dataset for which a conflict occurred • Date of the last change

Requirement

A conflict occurred during the synchronization. See also chapter Synchronizing data (Page 19).

Procedure

- To transfer the value of a conflict from your device to the server, tap "Overwrite remote value".
- To transfer the value of all conflicts from your device to the server, tap "Overwrite all remote values".
- To keep the value on the server and transfer it to your device, tap "Keep remote value".
- To keep all the values on the server and transfer them to your device, tap "Keep all remote values".


Working with the "Work packages" tile

The "Work packages" tile displays all the work packages that were created in COMOS or in the Task Management of COMOS Web and have the "Planned" status.

You can do the following:

- Viewing work packages
- Editing work packages
- Starting work packages

8.1 User interface of the "Work packages" tile



Section	Description
1	"Filter" section Filters that group work packages in accordance with specific filter criteria.
2	Work packages of the selected filter
3	Detail view of a selected work package

Filters

The filters are based on queries that are provided in the COMOS database by default.

Filter name	Description
"All work packages"	Displays all work packages
"Planned"	Displays work packages with "Open" status that have a planned start date.
"Assigned"	Displays work packages that are assigned to a person responsible.
"In progress"	Displays work packages with "In progress" status.
"Completed"	Displays work packages with "Closed" status.

8.2 Requirements for displaying work packages

Work packages are only displayed in Mobile Operations when a user has created a work package that can be synchronized in COMOS. Work packages can be synchronized when an administrator has configured synchronization at the base object.

- An administrator has set up automatic creation of new work packages and activities. You can find additional information on this topic in the manual "Mobile Solutions", keyword "Having work packages and activities created".
- A user with advanced user rights has set up the continuous synchronization of the properties of synchronized activities.
You can find additional information on this topic in the manual "Mobile Solutions", keyword "Continuously synchronizing properties of linked tasks".
- The COMOS Web Server is started and Mobile Operations can communicate with COMOS.
- You are using at least COMOS 10.2.3.
- You have installed and configured the COMOS Web Server version 10.2.3 or higher.

Scenarios for creating tasks that can be synchronized

The following scenarios show you the order in which work packages and activities must be created so that they can be synchronized:

- "Mobile Solutions" manual, keyword "Scenario: User creates an activity in COMOS".
- "Mobile Solutions" manual, keyword "Scenario: User creates an activity in Mobile Operations".

8.3 Displaying work packages

Your settings determine which work packages are synchronized by the COMOS Web server with your device. See also chapter Settings for work packages (Page 43).

Requirement

- They meet the requirements for display of work packages. See also chapter Requirements for displaying work packages (Page 24).
- Work packages have been created in COMOS after the administrator had configured the synchronization of the work packages.

Procedure

1. Tap "Work packages".
The user interface opens. See also chapter User interface of the "Work packages" tile (Page 23).
2. Tap on a filter.
3. The work packages of the selected filter are displayed.
4. Tap on a work package.

Result

The properties of the work package are displayed.

Tab	Description
"Details"	Displays the properties of the work package.
"Activities"	Displays a list of all activities of the work package.
"Related Objects"	Displays links to COMOS objects.
"Attachments"	Displays attached images or documents.

See also

Editing work packages (Page 26)

8.4 Display activities

Requirement

- The properties of a work package are displayed. See also chapter Displaying work packages (Page 24).
- The work package contains activities.

8.5 Editing work packages

Procedure

1. Select the "Activities" tab.
Displays a list of all activities of the work package.
2. To show the details of an activity, tap the following icon:



Result

The activity is expanded. Its properties are displayed.

8.5 Editing work packages

Requirement

The properties of a work package are displayed. See also chapter Displaying work packages (Page 24).

Procedure

1. To edit the properties, tap "Edit" in the menu bar.
The properties are displayed in edit mode.
See also chapter User interface of the "Work packages" tile (Page 23).
2. Edit the properties as desired.
3. Optional: Add activities. See also chapter Adding activities (Page 27).
4. Optional: Link COMOS objects in the "Related Objects" tab:
 - Maintenance plans
 - Equipment
 - A unit
 - An engineering object
5. Optional: Upload a file in the "Attachments" tab. See also chapter Attaching attachments (Page 28).
6. Tap "Save" to save and exit the edit mode.
7. Tap "Sync" to synchronize your changes with the server. See also chapter Synchronizing data (Page 19).

8.6 Adding activities

Requirement

The properties of a work package are displayed. See also chapter Displaying work packages (Page 24).

Procedure

1. Tap the "Add activity" button in the menu bar.
The "Add activity" window is displayed.
2. Enter at least the title of the activity.
Optional: Edit the remaining properties.
 - "Work instruction" field: Enter a work instruction.
 - "Progress (%)" field: Enter the progress of the activity in percent. Use whole numbers only. Do not enter the % sign.
 - "Completed" option: The activity is already complete.
 - "Not necessary" option: The activity is not necessary to complete the work package.
 - "Additionally necessary" option: The activity is added later.
 - "Work execution" field: Enter what you have done so far to complete the task.
3. Tap "OK" to save the activity.
4. Tap "Sync" to synchronize your changes with the server. See also chapter Synchronizing data (Page 19).

Result

An activity is created under the linked work package in COMOS and linked with the activity from Mobile Operations. The linking is necessary so that attributes of the task can later be continuously synchronized.

Note

Do not delete the link to the linked COMOS object

Do not delete the link to the synchronized COMOS object. If you delete the link, the synchronization is irrevocably damaged and cannot be restored.

Which attributes are continuously synchronized depends on the settings of the administrator.

8.7 Attaching attachments

Requirement

You have opened a work package in edit mode. See also chapter Editing work packages (Page 26).

Procedure

1. Select the "Attachments" tab.
2. To attach an existing photo, tap the button with the photo symbol.
3. To take a new photo and attach it, tap the button with the camera symbol.
4. To attach a file, tap the button with the plus sign.
5. To delete an attachment select the attachment. Tap the button with the wastebasket symbol.
6. Tap "Save" to exit edit mode and save it.

Working with the "Events" tile


You can create new events in Mobile Operations.

If configured by the administrator, events can be synchronized between the Mobile Operations server and COMOS. See also chapter Requirements for events that can be synchronized (Page 30).

See also

Adding events (Page 31)

9.1 User interface of the "Events" tile



Section	Description
1	"Filter" section Filters that group events according to defined filter criteria.
2	Events of the selected filter
3	Detail view of a selected event

Filters

The filters are based on queries that are based on the possible status of work packages. The queries are available in the COMOS database by default.

Filter name	Description
"All events"	Shows all events
"New events"	Shows events with the corresponding status.
"Confirmed"	Shows events with the corresponding status.
"Information"	Shows events with the corresponding status.
"Completed"	Shows events with the corresponding status.
"Assigned"	Shows events with the corresponding status.

9.2 Requirements for events that can be synchronized

Events from COMOS are synchronized with Mobile Operations when an administrator has configured synchronization at the base object.

- An administrator has set up automatic creation of new events. You can find additional information on this topic in the manual "Mobile Solutions", keyword "Having new events created".
- A user with advanced user rights has set up the continuous synchronization of the properties of synchronized events.
You can find additional information on this topic in the manual "Mobile Solutions", keyword "Continuously synchronizing properties of linked tasks".
- The COMOS Web Server is started and Mobile Operations can communicate with COMOS.
- You are using at least COMOS 10.2.3.
- You have installed and configured the COMOS Web Server version 10.2.3 or higher.

See also

Displaying events (Page 30)

9.3 Displaying events

Requirement

You have created events. See also chapter Adding events (Page 31).

Procedure

1. Tap the "Events" tile.
The user interface opens. See also chapter User interface of the "Events" tile (Page 29).
2. Tap on a filter.

3. The events of the selected filter are displayed.
4. Tap on an event.

Result

The properties of the event are displayed.

Tab	Description
"Details"	Displays the properties of the event.
"Related Objects"	Displays links to COMOS objects.
"Attachments"	Displays attached images or documents.

See also

Requirements for events that can be synchronized (Page 30)
Editing events (Page 32)

9.4 Adding events

Requirement

- If you want to synchronize events: See chapter Requirements for events that can be synchronized (Page 30).
- You are using at least COMOS 10.2.3.
- You have installed and configured the COMOS Web Server version 10.2.3 or higher.

Procedure

1. You have the following options for creating an event:
 - Tap the "New event" tile.
 - Click the "Add" button in the "Events" tile.
2. Enter the title of the event in the "Title" field
3. Optional: Edit the remaining properties.
4. To also have the event created in COMOS, link it to an equipment from COMOS. See also chapter Linking objects (Page 32).
5. Optional: Upload a file in the "Attachments" tab. See also chapter Attaching attachments (Page 33).
6. Tap "Save".
7. Tap "Sync" to synchronize your changes with the server. See also chapter Synchronizing data (Page 19).

Result

- The event is created.
- If you have linked equipment, an event is created under the equipment in COMOS.

9.5 Editing events

Requirement

The properties of an event are displayed. See also chapter Displaying events (Page 30).

Procedure

1. To edit the properties, tap "Edit" in the menu bar.
The properties are displayed in edit mode.
2. Edit the properties as desired.
3. Optional: Add the attachments. See also chapter Attaching attachments (Page 33).
4. Optional: Link COMOS objects in the "Related Objects" tab. See also chapter Linking objects (Page 32)
5. Tap "Save".
6. To discard the changes and exit the edit mode, tap "Cancel".
7. Tap "Sync" to synchronize your changes with the server. See also chapter Synchronizing data (Page 19).

9.6 Linking objects

The "Related Objects" tab displays links to COMOS objects. By default, the "Objects" link field is preconfigured so that the information about new links is communicated to COMOS.

If you link an equipment here for which the administrator has configured synchronization, an event is automatically created under the equipment in COMOS. See also chapter Requirements for events that can be synchronized (Page 30).

Requirement

You have opened an event in edit mode. See also chapter Editing events (Page 32).

Procedure

1. Select the "Related Objects" tab.
2. Tap "Assign".
3. To start a search, enter a search term or scan the QR code of a component to find it in your device.

4. Select an object.
5. Tap "OK".

Result

The object is linked to the event.

Note

Do not delete the link to the COMOS equipment

Do not delete the link to the COMOS object. If you delete the link, the synchronization of the event is irrevocably damaged and cannot be restored.

If you have linked equipment, an event is created under the equipment in COMOS. The event is linked with the event from Mobile Operations.

Edit the event as needed. Which attributes are continuously synchronized depends on the settings of the administrator.

9.7 Attaching attachments

Requirement

You have opened an event in edit mode. See also chapter Editing events (Page 32).

Procedure

1. Select the "Attachments" tab.
2. To attach an existing photo, tap the button with the photo symbol.
3. To take a new photo and attach it, tap the button with the camera symbol.
4. To attach a file, tap the button with the plus sign.
5. To delete an attachment select the attachment. Tap the button with the wastebasket symbol.
6. Tap "Save" to exit edit mode and save it.

Creating redlinings

If you have attached revisions in PDF format to activities or events, you can create redlinings in the Mobile Operations user interface.

You can find additional information on this topic in the "Mobile Solutions" manual, keyword "Creating redlinings in COMOS Web".

Pin favorites to starting page

When you are working in the "Work packages" or "Events" tile, you can pin filters or individual tasks to the starting side. The pinned element is shown as a tile. The tile provides you with quick access to files that are required often.

Requirement

You have selected a filter or a task in the "Work packages" or "Events" tile.

Procedure

1. Tap the button with the pin symbol.
2. Enter a name in the "Tile name" field.
3. In the "Group" list, select the control group on the starting page in which the tile is to be displayed.
4. Select the size of the tile.
5. Tap "Pin to starting page".

Result

A new tile is created. It opens the pinned element.


Delete pinned tile

1. To delete a pinned tile, activate edit mode on the starting page.
2. Select the tile.
3. Tap "Delete link" in the context bar.
4. Tap "Save".

Live feed tiles

Live feed tiles are dynamic and show a list of specific tasks.

Example:



Live feed tiles are available for the following types of tasks in Mobile Operations:

- Work packages
- Events

You specify the tasks that are to be displayed in the settings, see also chapter Settings for the live feed tile (Page 43).

Opening tasks from live tiles

You open a work package or an event by tapping an entry in one of the live tiles.

"Find" tile

You can now search for data that is stored locally on your device.

Searched specific properties of objects:

- Description
- Name
- Label
- COMOS UID
- ID of the task in Mobile Operations
- COMOS database

Searched properties of work packages and events:

- Name

Procedure

1. To limit the search to specific hierarchical or functional classifications, edit the properties of the search. See also chapter Settings for the search (Page 44).
2. To start a search, enter a search term or scan the QR code of a component to find it in your device.

Result

The search results are displayed. The properties are opened when you select an entry.

Editing settings

14.1 General settings

Procedure

1. Open the "Settings" tile.
2. Select the "General settings" group.
3. Change the user interface language of Mobile Operations in the "Language" list.

14.2 Settings for work packages

This is used to control which work packages are to be downloaded from the Mobile Operations server to your device when you tap "Sync".

Procedure

1. Open the "Settings" tile.
2. Select the "Work packages" group.
3. With the "Days in the future" control, define the latest planned end date of work packages. Work packages with a later end date will not be synchronized.
4. With the "Days in the past" control, define the earliest planned start date of work packages. Work packages with an earlier start date will not be synchronized.
5. In the "Size of attachments" area, select the maximum size of attachments in work packages.

See also

Working with the "Work packages" tile (Page 23)

14.3 Settings for the live feed tile

This is used to control which work packages and events are to be displayed in the live feed tiles on the starting page.

Procedure

1. Open the "Settings" tile.
2. Select the "Settings for live feed tiles" group.
3. Select whether you want to display all jobs or only jobs with a specific status.

See also

Live feed tiles (Page 39)

14.4 Settings for the search

This limits the search to specific hierarchical or functional classifications.

Procedure

- Enter one or more classification keys in the "Hierarchical classification" field. Separate multiple key entries with a comma.
- Enter one or more classification keys in the "Function classification" field. Separate multiple key entries with a comma.

Result

All classification keys have an OR relationship with each other. Only those objects that have a specified classification key are displayed in the search results.

If you do not enter a classification key, objects are displayed independent of their classification.

See also

"Find" tile (Page 41)

Administration

15.1 Server requirements

Overview

- You use one of the following Windows Server versions:
 - Windows Server 2012 R2
 - Windows Server 2008 R2
 - Windows Server 2016
- You use one of the following Web server versions:
 - IIS 8.5 Web server
 - IIS 7.5 Web server
 - IIS 10 Web server
- .NET Framework 4.0 is installed in addition to the standard .NET Framework 3.5 SP2. Frameworks are supplied as standard with the COMOS installation. Activate the required framework as a service on the Web server.
- COMOS is installed on the server.
- Make sure that the desired port is released on the server for the Client Gateway Service. You can find additional information on this topic in the manual "Mobile Solutions", keyword "Setting up IIS for the Client Gateway Service".
- The user under whom the IIS application pool runs must have read and write access to the COMOS document directory.

Note

Using UNC address

Use the UNC address to address the document directory of the database.

Correct: \\<Server_name>\<COMOS_document_directory>

Incorrect: O:\<COMOS_document_directory>

- The user under whom the IIS application pool runs must have access to the COMOS database and must be registered as administrator in the database.
- The database that is to be used in COMOS Mobile Solutions or COMOS Mobile Operations must additionally be configured for CVS 3G. You can find additional information on this in manual "Installation and Configuration", keyword "Installing CVS 3G".

COMOS license

You need Version 1.6.0 of the COMOS license server. You cannot use COMOS Mobile Solutions or C Mobile Operations with local licenses.

Temporary files

COMOS Mobile Solutions and COMOS Mobile Operations store temporary files, such as icons, in the temporary directory of the user under whom the IIS application pool is running.

SSL

Use COMOS Mobile Solutions or COMOS Mobile Operations only with SSL, so that the files can be transferred without encoding. You can find additional information on this topic in the manual "Mobile Solutions", keyword "Setting up SSL".

Note

Data security

If you use COMOS Mobile Solutions or COMOS Mobile Operations without SSL, the data are transferred unencrypted between the client and the server.

15.2 Installing and configuring COMOS Web Server for Mobile Operations

The installation procedure of COMOS Mobile Operations is similar to that of COMOS Web.

The needed internal service is different from COMOS Web.

Requirement

See also chapter Server requirements (Page 45).

Procedure

In order to use Mobile Operations, configure at least the following services:

- Client Gateway Service
- COMOS Gateway Service
- Users Service
- Event Service
- Task Service
- Composite UI Service

You can find additional information on this topic in the manual "Mobile Solutions", keyword "Setting up COMOS Web Server".