




Parts List				
Item	Qty	Part Name	Part Number	Material
1	1	Housing Inlet v6	V2	Invar 36
2	2	Housing Center v3	V1	Invar 36
3	1	Housing Outlet v4	V3	Invar 36
4	1	Valve Orifice v3	V4	Invar 36
5	2	Bellows v2	I718-159-72-430	Inconel 718