

1. **Drill large central hole** with a $59/64$," drill bit.
2. **Drill small inlet hole** from the -Z direction with an $1/8$ " drill bit.