

SJ1: select address of Eeprom
SJ2: enable/diable external Antenna
SJ3: select address of Movement Sensor
SJ4: select address of Temperature Sensor







E2PROM



MCU



Radio





Light intensity



Movement



Temperature / Humidity



Light UV



Light RGB