

Cleaning and Maintenance Schedule for Advance Analytik Products

1. VizSens pH (Analog) Sensor

- Clean weekly with distilled water and soft cloth.
 - Soak in pH 4 buffer for 10 minutes if fouled.
 - Do not scrub glass bulb or reference junction.
 - Store in pH storage solution when not in use.
 - Replace sensor every 12–18 months depending on use.
-

2. VizSens ODO (Optical Dissolved Oxygen) Sensor

- Inspect weekly for fouling, clean with soft sponge.
 - Do not touch optical membrane with bare fingers.
 - Use mild soap and water; rinse thoroughly.
 - Replace membrane cap annually or if calibration drift is noticed.
 - Verify readings monthly against reference DO meter.
-

3. VizSens SS (Suspended Solids/Sludge) Sensor

- Wipe sensor body weekly with soft cloth.
 - Enable automatic cleaning (if equipped) every 4–6 hours.
 - Perform manual cleaning monthly for marine growth or scaling.
 - Check lens clarity and remove debris if present.
 - Recalibrate quarterly.
-

4. Viz Eco Duo / Viz Eco Multi Transmitters

- Clean touchscreen and housing monthly with dry cloth.
- Inspect cable entries for tightness and corrosion.

- Verify analog and digital outputs quarterly.
 - Backup data from memory card every 3 months.
 - Update firmware annually, if applicable.
-

5. FRP Mounting Panel

- Inspect twice a year for structural wear or UV degradation.
 - Clean with mild detergent as needed.
 - Tighten all mounting bolts quarterly.
-

6. SS Flow-through Chamber (Viz-Eco-EQMS only)

- Flush with clean water weekly.
 - Clean with 5% HCl or other mild acid solution monthly to remove scaling.
 - Inspect seals and sensor ports quarterly.
 - Check for leaks and flow blockages every 2 months.
-

General Maintenance Notes

- Always disconnect power before maintenance.
- Use only recommended cleaning agents and tools.
- Maintain a log of all cleaning and service activities.
- Replace damaged or worn parts without delay.