

### Example: Evaluation of beam crosssections under shear and bending loads

 $\bullet$  two different cross-sections of the exact same area are proposed for a cantilever beam of length L under shear load  $S_{\nu}$ 



- assume that the shear load is applied through the shear center in both cases (hence no twisting of the cross-section)
- section 1: "T" or "blade" section




- locate origin at neutral axis
- determine neutral axis location (y):

$$\overline{y} = \frac{h_1 t_1 \frac{h_1}{2} + b_1 t_1 \frac{t_1}{2}}{h_1 t_1 + b_1 t_1} = \frac{h_1^2}{2(h_1 + b_1)}$$

determine moment of inertia I<sub>xx</sub>

$$I_{xx} = \frac{t_1 h_1^3}{12} + t_1 h_1 \left(\frac{h_1}{2} - y\right)^2 + b_1 t_1 y^2$$

note simplifications in  $\overline{y}$  and  $I_{xx}$  due to negligible  $t_1$ 




- one axis (y) is an axis of symmetry; so  $I_{xy}=0$
- then, from eq (5.7)

$$q_{s} = -\frac{S_{x}}{I_{yy}} \int_{0}^{s} tx ds - \frac{S_{y}}{I_{xx}} \int_{0}^{s} ty ds$$

• and since S<sub>x</sub>=0:

$$q_s = -\frac{S_y}{I_{xx}} \int_0^s ty ds$$

- select a convenient location for origin of s; for an open cross-section, this would be a free end such as point 1
- section 1-2: y=- $\overline{y}$ ; Then,  $q_{12} = -\frac{S_y}{I_{xx}} \int_0^s t \left(-\overline{y}\right) ds = \frac{S_y}{I_{xx}} t_1 \overline{y} s$



$$q_{12} = -\frac{S_y}{I_{xx}} \int_0^s t \left(-\overline{y}\right) ds = \frac{S_y}{I_{xx}} t_1 \overline{y} s$$


- the shear flow at point 2 will consist of a contribution from  $q_{12}$  and  $q_{42}$ ; by symmetry,  $q_{12}=q_{42}$
- therefore:

$$q_2 = 2q_{12} \left( s = \frac{b_1}{2} \right) = \frac{S_y}{I_{xx}} t_1 \overline{y} b_1$$

• section 2-3: y=s-y


$$q_{23} = q_2 - \frac{S_y}{I_{xx}} \int_0^s t \left( s - \overline{y} \right) ds = \frac{S_y}{I_{xx}} t_1 \overline{y} b_1 - \frac{S_y}{I_{xx}} t_1 \left( \frac{s^2}{2} - \overline{y} s \right) \Longrightarrow q_{23} = \frac{S_y}{I_{xx}} t_1 \left( \overline{y} b_1 + \overline{y} s - \frac{s^2}{2} \right)$$

• check: if q<sub>23</sub> is correct then at point 3 must have q<sub>23</sub>=0




$$q_{23}(s = h_1) = \frac{S_y t_1}{I_{xx}} \left[ \frac{h_1^2}{2(h_1 + b_1)} b_1 + \frac{h_1^3}{2(h_1 + b_1)} - \frac{h_1^2}{2} \right] = \frac{S_y t_1}{2I_{xx}(h_1 + b_1)} \left( h_1^2 b_1 + h_1^3 - h_1^2 (h_1 + b_1) \right) = 0$$


• in order to compare the two cross-sections, need to find the critical (= most positive or most negative) value of the shear flow in the cross-section



$$q_{12} = -\frac{S_y}{I_{xx}} \int_0^s t \left(-\overline{y}\right) ds = \frac{S_y}{I_{xx}} t_1 \overline{y} s$$


$$q_{23} = \frac{S_y}{I_{xx}} t_1 \left( \overline{y} b_1 + \overline{y} s - \frac{s^2}{2} \right)$$





• the shear flow at point 2 is the sum of the contributions from  $q_{12}$  and  $q_{42}$ :

$$q_2 = \frac{S_y}{I_{xx}} t_1 \overline{y} b_1$$





$$q_{12} = -\frac{S_{y}}{I_{xx}} \int_{0}^{s} t \left(-\frac{y}{y}\right) ds = \frac{S_{y}}{I_{xx}} t_{1} \overline{y} s$$

$$q_{2} = \frac{S_{y}}{I_{xx}} t_{1} \overline{y} b_{1}$$

$$q_{23} = \frac{S_{y}}{I_{xx}} t_{1} \left(\overline{y} b_{1} + \overline{y} s - \frac{s^{2}}{2}\right)$$

• The question is: Does q<sub>23</sub> attain a higher value in section 2-3 or does it decrease monotonically to 0?






$$q_{23} = \frac{S_y}{I_{xx}} t_1 \left( \overline{y} b_1 + \overline{y} s - \frac{s^2}{2} \right)$$

one way is to check if q<sub>23</sub> has a minimum or a maximum between 0 and h<sub>1</sub>:

$$\frac{dq_{23}}{ds} = 0 \Rightarrow \overline{y} - s = 0 \Rightarrow s = \overline{y}$$


- so a max or a min occurs at  $s=\bar{y}$ ; by substituting y for s in  $q_{23}$  (or taking the second derivative) we can find that there is a maximum there
- therefore, the max shear flow for the cross section is


$$q_{\text{max}} = q_{23\text{max}} = \frac{S_y}{I_{xx}} t_1 \left( \overline{y} b_1 + \overline{y} \overline{y} - \frac{\overline{y}^2}{2} \right) \Rightarrow q_{\text{max}} = \frac{S_y}{I_{xx}} t_1 \overline{y} \left( b_1 + \frac{\overline{y}}{2} \right)$$



- the maximum bending moment (at the root of the beam) is  $M_{x \max} = S_y L$
- and the corresponding maximum normal stress is (see eq 2.6 or 2.7)

$$\sigma_{z \max} = \frac{M_{x \max} y_{\max}}{I_{xx}}$$






• therefore,

$$\sigma_{\text{max compr}} = \frac{S_{y}L(h_{1} - y)}{I_{xx}}$$

$$\sigma_{\text{max tension}} = \frac{S_{y}L\overline{y}}{I_{xx}}$$

section 2: "C" or "channel" section




note: (a)  $S_y$  is acting through the shear center (b) simplifications in y and  $I_{xx}$  due to negligible  $t_2$ 

- locate origin at neutral axis
- determine neutral axis location (y):

$$\overline{y} = \frac{h_2 t_2 \frac{h_2}{2} + t_2 \frac{b_2}{2} h_2}{h_2 t_2 + 2t_2 \frac{b_2}{2}} = \frac{h_2}{2}$$

determine moment of inertia I<sub>xx</sub>

$$I_{xx} = \frac{t_2 h_2^3}{12} + 2\frac{b_2}{2}t_2 \left(\frac{h_2}{2}\right)^2 \Rightarrow I_{xx} = \frac{t_2 h_2^2}{4} \left(\frac{h_2}{3} + b_2\right)$$



- one axis (x) is an axis of symmetry; so  $I_{xy}=0$


$$q_s = -\frac{S_x}{I_{yy}} \int_0^s tx ds - \frac{S_y}{I_{xx}} \int_0^s ty ds$$

• and since S<sub>x</sub>=0:

$$q_s = -\frac{S_y}{I_{xx}} \int_0^s ty ds$$

- select a convenient location for origin of s; for an open cross-section, this would be a free end such as point 1
- section 1-2: y=-y; Then,

$$q_{12} = -\frac{S_y}{I_{xx}} \int_0^s t \left(-\frac{y}{y}\right) ds = \frac{S_y}{I_{xx}} t_2 \frac{h_2}{2} s$$




$$q_{12} = -\frac{S_y}{I_{xx}} \int_0^s t \left(-\frac{y}{y}\right) ds = \frac{S_y}{I_{xx}} t_2 \frac{h_2}{2} s$$

$$q_2 = \frac{S_y}{I_{xx}} t_2 \frac{b_2 h_2}{4}$$

• section 2-3: y=s-y

$$q_{23} = q_2 - \frac{S_y}{I_{xx}} \int_0^s t \left( s - \overline{y} \right) ds = \frac{S_y}{I_{xx}} t_2 \frac{b_2 h_2}{4} - \frac{S_y}{I_{xx}} t_2 \left( \frac{s^2}{2} - \overline{y} s \right) \Rightarrow q_{23} = \frac{S_y}{I_{xx}} t_2 \left( \frac{h_2 b_2}{4} + \overline{y} s - \frac{s^2}{2} \right)$$




$$q_{23} = \frac{S_y}{I_{xx}} t_2 \left( \frac{h_2 b_2}{4} + y s - \frac{s^2}{2} \right)$$

$$q_3 = q_{23}(s = h_2) = \frac{S_y}{I_{xx}} t_2 \left( \frac{h_2 b_2}{4} + y h_2 - \frac{h_2^2}{2} \right)$$

• but, we showed earlier that  $\bar{y} = \frac{h_2}{2}$  Substituting:

$$q_3 = \frac{S_y}{I_{xx}} t_2 \left( \frac{h_2}{4} b_2 + \frac{h_2}{2} h_2 - \frac{h_2^2}{2} \right) \Longrightarrow q_3 = \frac{S_y}{I_{xx}} t_2 \frac{h_2 b_2}{4}$$

which is exactly the same as  $q_2$ , as it should because of symmetry




- section 3-4:  $y=+y=h_2/2$

$$q_{34} = q_3 - \frac{S_y}{I_{xx}} \int_0^s t \, \overline{y} ds = \frac{S_y}{I_{xx}} t_2 \frac{h_2 b_2}{4} - \frac{S_y}{I_{xx}} t_2 \frac{h_2}{2} s$$

SO

$$q_4 = q_{34} \left( s = \frac{b_2}{2} \right) = \frac{S_y}{I_{xx}} t_2 \frac{h_2 b_2}{4} - \frac{S_y}{I_{xx}} t_2 \frac{h_2 b_2}{2} = 0$$

• the max shear flow in the cross-section will be either q<sub>2</sub> or the highest value of q in section 2-3



$$q_{23} = \frac{S_y}{I_{xx}} t_2 \left( \frac{h_2 b_2}{4} + y s - \frac{s^2}{2} \right)$$

 as for the case of the "T" cross-section,

$$\frac{dq_{23}}{ds} = 0 \Rightarrow \overline{y} - s = 0 \Rightarrow s = \overline{y}$$


• and using the fact that  $\bar{y} = h_2/2$ :

$$q_{23\max} = \frac{S_y}{I_{xx}} t_2 \left( \frac{h_2 b_2}{4} + \frac{h_2}{2} \frac{h_2}{2} - \frac{h_2^2}{8} \right) \Rightarrow q_{23\max} = \frac{S_y}{I_{xx}} \frac{t_2 h_2}{4} \left( b_2 + \frac{h_2}{2} \right)$$

which is greater than  $q_2$  and thus is the highest shear flow in the cross-section




 as for the "T" cross-section, there are also normal stresses caused by the moment S<sub>v</sub>L



• the equations are the same as for the "\tau" stiffener


$$\sigma_{\text{max compr}} = \frac{S_y L(h_2 - \overline{y})}{I_{xx}}$$

$$\sigma_{\text{max}tension} = \frac{S_y L \overline{y}}{I_{xx}}$$




• which, using the fact that  $y=h_2/2$ , simplify to:

$$\sigma_{\max compr} = \sigma_{\max tension} = \frac{S_y L h_2}{2I_{xx}}$$




# Example: Evaluation of beam cross-sections under shear and bending loads



# Example: Evaluation of beam cross-sections under shear and bending loads

- note that the magnitude of the max compressive stress for the "T" section is bigger than the max tensile stress
- for the "C" section, the magnitudes of max compressive and tensile stresses are the same




# Example: Relative magnitude of shear and normal stresses


- in general, to determine failure one would have to find where in each cross-section, the shear and normal stresses combine to give the worst von Mises stress
- it turns out that for most beams (L>>h,b>>t) the shear stresses are very small compared to the normal stresses and it suffices to do the strength check using only the max normal stress (tensile or compressive depending on the relative values of the tensile or compressive yield strengths of the material)

# Example: Relative magnitude of shear and normal stresses

 a way to check this is to take the ratio of maximum shear stress to maximum normal stress for each cross-section; after simplification we get:




$$\frac{\tau_{\text{max}}}{\sigma_{\text{max}}} = \frac{1}{4} \frac{\left(h_1 + 2b_1\right)^2}{\left(h_1 + b_1\right)L} = \frac{1}{4} \frac{\left(\frac{h_1}{b_1} + 2\right)^2}{\left(\frac{h_1}{b_1} + 1\right)\frac{L}{b_1}}$$




$$\frac{\tau_{\text{max}}}{\sigma_{\text{max}}} = \frac{1}{4} \frac{\left(h_2 + 2b_2\right)}{L} = \frac{1}{4} \frac{\left(\frac{h_2}{b_2} + 2\right)}{\frac{L}{b_2}}$$


# Example: Relative magnitude of shear and normal stresses



## Combined closed and open section beams



# Combined open and closed sections under bending




• normal stresses are still given by eq. (2.5)

$$\sigma_z = \frac{I_{xx}M_y - I_{xy}M_x}{I_{xx}I_{yy} - I_{xy}^2} x + \frac{I_{yy}M_x - I_{xy}M_y}{I_{xx}I_{yy} - I_{xy}^2} y$$


determine neutral axis, I<sub>xx</sub>, etc for the entire cross-section and apply eq (2.5); alternatively, find which portion of M is taken by which member an@5do simpler analysis

# Combined open and closed sections under shear



• two cases depending on whether S<sub>y</sub> acts through the shear center or not

# Combined open and closed sections under shear




- S<sub>v</sub> through the shear center
- analysis proceeds as for closed and open section beams with equations (5.6) and (5.8), (5.10)

$$q_{s} = -\frac{I_{xx}S_{x} - I_{xy}S_{y}}{I_{xx}I_{yy} - I_{xy}^{2}} \int_{0}^{s} txds - \frac{I_{yy}S_{y} - I_{xy}S_{x}}{I_{xx}I_{yy} - I_{xy}^{2}} \int_{0}^{s} tyds$$
(5.6)


$$q_{s} - q_{s0} = -\frac{I_{xx}S_{x} - I_{xy}S_{y}}{I_{xx}I_{yy} - I_{xy}^{2}} \int_{0}^{s} txds - \frac{I_{yy}S_{y} - I_{xy}S_{x}}{I_{xx}I_{yy} - I_{xy}^{2}} \int_{0}^{s} tyds$$
 (5.8)

$$\int_{S} pq_b ds + 2Aq_{s0} = 0 \tag{5.10}_{27}$$


## Combined open and closed sections



- S<sub>v</sub> not through the shear center
- break the problem in two, one with the shear load through the shear center and one with an applied torque equal to the shear load times the distance from the shear center
- superposition of the two problems gives the answer




- we have shown in lecture 4 that open cross-sections have very small J
- so if we combine a closed and an open section, the contribution of the open portion to the torsional rigidity is negligible (see example below) and one can approximate J of the entire cross-section with J of the closed section
- still, shear stresses develop also in the open section and have to be checked for failure



Determine the rate of twist and the maximum shear stress in open and closed sections under torque T


• first, some points are necessary to put things in perspective




• we know from lecture 5 that the shear flow in the closed portion under pure torque is constant, so:

$$q_{34} = q_{45} = q_{56} = q_{63} = q$$


• Consider now vertical equilibrium: Since  $q_{45}$  and  $q_{63}$  have the same magnitude and opposite directions, they cancel each other. This leaves only  $q_{12}$ 




- this means that if  $q_{12}$ =const then  $q_{12}$ =0; otherwise  $q_{12}$  just integrates to zero
- similarly, horizontal equilibrium shows that, since  $q_{34}$  balances  $q_{56}$ ,  $q_{23}$  is either 0 or integrates to zero



- in lecture 4 we found that for a narrow rectangular cross section,  $\tau_{yz}$  is linear through the thickness and  $\tau_{xz} \approx 0$  (except near the top and bottom ends 1 and 2)
- this means that our standard definition q=tτ, which assumes τ is const through the thickness, is no longer valid



- the exact same reasoning applies to segment 2-3 but now  $\tau_{xz}$  varies linearly through the thickness and  $\tau_{vz} \approx 0$
- so, while q in segments 1-2 and 2-3 is not well-defined, the shear stresses due to torsion do exist and should be checked for failure




- let the subscripts "c", "o", and "T" denote the closed portion, open portion and total cross-section
- then, from the basic torque equation (3.25):

$$T_c = (GJ)_c \left(\frac{d\theta}{dz}\right)_c$$
 but also,  $T_T = T_c + T_o$ 

$$T_o = (GJ)_o \left(\frac{d\theta}{dz}\right)_o$$

$$T_T = (GJ)_T \left(\frac{d\theta}{dz}\right)_T$$




using the first 3 to substitute in the last equation:

$$(GJ)_T \left(\frac{d\theta}{dz}\right)_T = (GJ)_c \left(\frac{d\theta}{dz}\right)_c + (GJ)_o \left(\frac{d\theta}{dz}\right)_o$$


 but the rate of twist is the same for each portion and equal to the overall rate of twist

$$\left(\frac{d\theta}{dz}\right)_T = \left(\frac{d\theta}{dz}\right)_c = \left(\frac{d\theta}{dz}\right)_o$$




- combining:  $(GJ)_T = (GJ)_c + (GJ)_o$
- and if the same material is used for the closed and open portions of the cross-section:  $G_T = G_c = G_o = G$
- we obtain:

$$J_T = J_c + J_o$$



- for the open portion, using eq. (4.11):  $J = \frac{1}{3} \sum_{i=1}^{N} s_i t_i^3$  we get  $J_o = a \frac{(2t)^3}{3} + a \frac{(2t)^3}{3} = \frac{16}{3} a t^3$
- for the closed section we have from eq. (5.12):  $\frac{d\theta}{dz} = \frac{1}{2A} \int \frac{q_s}{tG} ds$
- for q<sub>s</sub>=const=q and using (3.44), T=2Aq:  $\frac{d\theta}{dz} = \frac{T_c}{4A^2} \int \frac{ds}{Gt}$




• and using (3.31), 
$$T = GJ \frac{d\theta}{dz}$$
 we get
$$\frac{d\theta}{dz} = \frac{GJ_c}{4A^2} \frac{d\theta}{dz} \oint \frac{ds}{Gt} \Rightarrow J_c = \frac{4A^2}{\int \frac{ds}{t}}$$

and substituting values:

$$J_c = \frac{4\left(a^2\right)^2 t}{4a} = a^3 t$$

• therefore,  $J_T = a^3 t + \frac{16}{3} a t^3$ 

note that the contribution from the open portion,  $J_o$  is negligible compared to the contribution from the closed portion




- solving now for the rate of twist:  $\frac{d\theta}{dz} = \frac{T}{GJ_T} = \frac{T}{G\left(a^3t + \frac{16}{3}at^3\right)}$ 
  - the shear flow q in the closed portion is given by combining the rate of twist just found with

$$T_{c} = GJ_{c} \frac{d\theta}{dz}$$

$$T_{c} = 2Aq = 2a^{2}q$$

$$T_{c} = \frac{2a^{2}q}{dz} = G\left(a^{3}t\right) \frac{T}{G\left(a^{3}t + \frac{16}{3}at^{3}\right)} \Rightarrow q = \frac{Tat}{2\left(a^{3}t + \frac{16}{3}at^{3}\right)}$$


$$T_{c} = \frac{16at}{2}$$



• the resulting shear stress  $\tau$  in the closed portion can be found from  $\tau=q/t$ :

$$\tau = \frac{Ta}{2\left(a^3t + \frac{16}{3}at^3\right)}$$


• finally, the max shear stress in the open portion is found from eq (4.4)  $\tau_{yz} = 2Gx \frac{d\theta}{dz}$  which gives  $\tau_{yz} = 2G\frac{2t}{2}\frac{d\theta}{dz} = 2Gt \frac{d\theta}{dz^4}$ 



combining, the max shear stress in the open portion is

$$\tau_{yz} = 2G \frac{2t}{2} \frac{d\theta}{dz} = 2Gt \frac{T}{G\left(a^3t + \frac{16}{3}at^3\right)} = \frac{2T}{\left(a^3 + \frac{16}{3}at^2\right)}$$

• note that if the thicknesses in 1-2 and 2-3 were not the same, one would have to also check the max shear stress in segment 2-3



- determine now the value of t so that there is no failure
- compare shear stress in closed and open portion
- find highest
- set that equal to  $\tau_y$  and solve for t noting that t<<a href="#">t =  $\frac{T}{2a^2\tau_y}$  43