






Microcontroller




Sheetfile: microcontroller.kicad_sch

Sensors and memory




Sheetfile: sensors_and_flash.kicad_sch




nRF module solder points

Servos and connectors




File: servo_connectors.kicad_sch


Power and ESC



File: power_and_esc.kicad_sch




Mounting holes



Decoupling capacitors

Sheet: /Schematic/ File: MCU.kicad_sch		
Title:		
Size: A3	Date:	Rev:
KiCad E.D.A. 10.0.1	Id: 2/6	



Sheet: /Schematic/Power and ESC/
File: power_and_esc.kicad_sch

Title:


Size: A4

Date:


KiCad E.D.A. 10.0.1

Rev:


Id: 3/6




User LEDs




Crystal oscillator



RESET button




BOOT0 jumper




Microcontroller

-22R to 47R For UART_TX, UART_RX, SWO, SWDIO, SWCLK
-The 0 Ohm resistors soldered close to the MCU



SWD, UART and ESD protection



Sheet: /Schematic/Microcontroller/
File: microcontroller.kicad_sch

Title:


Size: A4 Date:


KiCad E.D.A. 10.0.1

Rev:

Id: 4/6

User button







Sheet: /Schematic/Sensors and memory/
File: sensors_and_flash.kicad_sch

Title:

Size: A4
KiCad E.D.A. 10.0.1

Date:

Rev:
Id: 5/6



Sheet: /Schematic/Servos and connectors/
File: servo_connectors.kicad_sch

Title:

Size: A4 Date:

KiCad E.D.A. 10.0.1

Rev:
Id: 6/6