## Arduino-examples

## 1. Basics

Rewrite of the Arduino core examples using Cosa

## Contents

- AnalogReadSerial
- BareMinimum
- Blink
- BlinkAlternative
- BlinkRTTDelay
- BlinkWatchdogDelay
- DigitalReadSerial
- Fade
- VoltageReadSerial

## AnalogReadSerial

```
// Analog Pin Instance for A0
AnalogPin sensor(Board::A0);
IOStream ios(&uart);
                                       // TOStream Instance connected UART
void setup()
  uart.begin(9600);
                                       // Start UART and use 9600 baud
 AnalogPin::powerup();
                                      // Start ADC module
 Watchdog::begin();
                                       // Start Watchdog and use default 16 ms tick
void loop()
                                       // Print analog pin reading
  ios << sensor << endl;
  delay(100);
                                       // Low-power delay
```